SHARP

KZ-SU14-W3

Grill
Сэндвичница
ساندویچ ساز
صانع ساندويتش

Please read these instructions carefully before operating the appliance

OPERATION MANUAL

Safety Notices

Please follow this instruction manual strictly to operate this unit correctly.

To avoid personal injury and property loss, please comply with the following safety notices. Accidents may occur if the user doesn't comply with the safety notices and operate the unit incorrectly.

- Before commissioning this device please read the instruction manual carefully.
- Please keep these instructions, the guaranty certificate, the sales receipt and, if possible, the carton with the inner packaging.
- The device is intended exclusively for private and not for commercial use!
- Always remove the plug from the socket whenever the device is not in use, when attaching accessory parts, cleaning the device or whenever a disturbance occurs. Switch off the device before. Pull on the plug, not on the cable.
- In order to protect children from the dangers of electrical appliances, never leave them unsupervised with the device. Consequently, when selecting the location for your device, do so in such a way that children do not have access to the device. Take care to ensure that the cable does not hang down.
- Test the device and the cable regularly for damage. If there is damage of any kind, the device should not be used.
- Do not repair the device yourself, but take this to nearest authorized service station.
- Keep the device and the cable away from heat, direct sunlight, moisture, sharp edges and such like.
- Never use the device unsupervised! Switch off the device whenever you are not using it, even if this is only for a moment.
- Do not use the device outdoors.
- Under no circumstances must the device be placed in water or other liquid, or come into contact with such. Do not use the device with wet or moist hands.
- Should the device become moist or wet, remove the mains plug from the socket immediately. Do not reach into the water.
- Use the device only for the intended purpose.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

  Children should be supervised to ensure that they do not play with the appliance.

  If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard

supervised. Keep the appliance and its cord out of reach of children less than 8 years.
- The baking surfaces get very hot. Touch the handles only.
- Put the unit down onto a heat-resistant surface or mat.
- In order to prevent heat from building up, do not put the unit directly underneath a cupboard. Ensure that there is enough space all around.
- Beware of steam coming out when you open the baking section.
- The steak can burn, so never use the toaster near or below curtains and other inflammable materials.
- A risk of fire and electrical shock exists in all electrical appliances and may cause personal injury or death. Please follow all safety instructions.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- Do not immerse the appliance in any liquid.
- The temperature of accessible surfaces may be high when the appliance is operating.
- Charcoal or similar combustible fuels must not be used with this appliance.

Important Information
The appliance are not intended to be operated by means of an external timer or separate remote-control system
This appliances is intended to be used in household and similar applications such as: -Staff kitchen areas in shops, offices and others working environments -Farm houses -by clients in hotels, motels and other residential type environments -bed and breakfast type environments

If you have any concerns regarding the performance and use of your appliance, please visit www.sharpmea.com

Ensure the above safety precautions are understood. Read carefully and save all the instructions provided with an appliance.

This Icon means surface are liable to get hot during use.

Know your product

1.Power Indicator Light (Red Cover)
2.Ready Indicator Light(Green Cover)
3.Handle Lock
4.Standing Leg
5.Sandwich/Grill/Waffle Plates
6.Push buttons

Technical Data

Model:KZ-SU14-W3
Voltage:220-240V
Frequency:50-60Hz
Rated Power:1200-1400W

Operation Method

Starting-up the unit
NON-STICK COATING
Lightly grease the baking surfaces before the unit is used for the first time. Use the appliance for about 10 minutes with the toasting surfaces closed (see "using the unit"). Then wipe it down with a damp cloth.
Please do not eat the first pieces of toast you make.

Using the unit

1. Put the plug into an earthed 220-240V/50/60Hz mains socket, the power is 680-820W.
   The Red Neon (POWER) and the Green Neon light up.
   Red Neon indicates connection into the electric power supply.
   Green Neon indicates heating of the cooking plates.
2. Keep the baking unit closed during the warming-up time.
   When the cooking plates are heated to the operating temperature, the Green Neon will be turned off.
   Note: the Green Neon keeps turning on and off while the power is turned on. This means that the operating temperature of cooking plates is constantly maintained.
3. Open the cover and place some sandwich. Then close the lid gently. Block the handle with the hinge. The sandwich will be finished after 3 to 5 minutes.
   Note: The cooking time depends on the type of bread, filling and your preferred toasting level.

4. Open the lid and remove the slices of sandwich with a wooden fork or the like. Do not use pointed or sharp objects to avoid damaging the coating of the baking surfaces.
5. The baking section should always be closed in the intervals between baking. Before cooking another sandwich, close the sandwich maker and wait until the green indicator light is turned off. After you finish using the product, please make sure the power is completely turned off.

Cleaning and Maintenance

- Pull out the mains plug and allow the unit to cool down.
- Brush away remains of crumbs from the baking surfaces
- Clean the machine only with a slightly damp cloth.
- Do not use abrasive detergents.
- This appliance conforms with the CE directives for radio interference suppression and low-voltage safety and has been built to meet current safety requirements. Subject to technical changes without prior notice.

Distributors in GCC:

Saudi Arabia:
Abdul Latif Jameel Electronics and Air-Conditioning Co. Ltd.
10, Al Mukhmal Tower, Rawdah Street.
Al Khalidiya District
Jeddah | Kingdom of Saudi Arabia
Toll Free # 800 127 9999 www.alelectronics.com.sa

UAE:
International Traders (ME) Limited
ITL House, Cosmos Lan, Al Fahidi Street, Bur Dubai
P.O.Box 6, Dubai, UAE
Tel: +971 4352 1155

Kuwait:
AL Yousifi United General Trading
Kuwait City, Abdullah Salem Street,
P.O.Box 126 Safat- 13002, Kuwait
Tel: +965 24844925

Qatar:
Al Muftah Trading & Contracting CO.W.L.L
P.O. Box 875, Doha, State of Qatar
Tel: +974 4446868

Bahrain:
Reuben's Store W.L.L
P.O.Box 233, Muharraq, Kingdom of Bahrain
Tel: +973 17227770

Oman:
Muscat Electronics L.L.C
Mezzanine Floor, Gulf House Building, CBD Area, Ruwi,
P.O.Box 1009. Postal code 114, Jibroo, Muscat, Sultanate of Oman
Tel: +968 24796231

Yemen:
Sydney Store
P.O.Box 5865, Al Tafeer Street, Taiz, Republic of Yemen
Tel: +967 4252231

In GCC Countries, please contact:
SHARP MIDDLE EAST FZE
P.O.Box 17215, Jebel Ali,
Dubai, United Arab Emirates
Tel: +971 4- 8815331
Fax: +971 4- 8816692

الأجهزة عن في دول الخليج
الموزع في المملكة العربية السعودية
شركة عبد اللطيف جميل للكترونيات وأجهزة التكييف المحدودة
برج المخمل، شارع الروضة ١٠
هذا المملكة العربية السعودية ٢١٤٣١٠، ص.ب
جدة | المملكة العربية السعودية ٠٨٠٠١٢٧٩٩٩٩
الموقع الكتروني www.alelectronics.com.sa
الامارات العربية المتحدة
شركة التجار الدولية (الشرق الأوسط) المحدودة
إي تي آي هاوس، معر ظرجوب، شارع الفهيدي، بر دبي
الامارات العربية المتحدة دبي، ص.ب ٦
تليفون: ٠٠٩٧١٤٣٥٢١٥٥
الكويت
شركة اليوسفي العامة للتجارة العامة
مدينة الكويت شارع عبدالله السالم
الصفاة، ١٣٠٠٢ الكويت ٢٤٩ ص.ب
تليفون: ٠٠٩٦٥٢٤٨٤٩٢٥
قطر
شركة المفتاح للتجارة والمقاولات ذ.م.م
ص.ب ٨٧٥ الدوحة دولة قطر
تليفون: ٠٠٩٧٤٤٤٤٦٨٦٨
البحرين
ردوس ستورز ذ.م.م
ص.ب ٢٣٣، المحافظة، مملكة البحرين
تليفون: ٠٠٩٧٣١٧٢٢٧٧٠
عمان
مسقط للالكترونيات ذ.م.م
طابق الميزانين، مبنى بيت الخليج، منطقة سي بي دي، روي
ص.ب ١٠٠٩، الرمز البريدي ١١٤، جبرو، مسقط، سلطنة عمان
تليفون: ٠٠٩٦٨٢٤٧٩٦٢٣١
اليمن
مخازن سيدني
ص.ب ٥٨٦٥، شارع التحرير، تعز، الجمهورية اليمنية
تليفون: ٠٠٩٦٧٤٢٥٢٢٣١
للاتصال بمكتب دبي الخليج الأتصال ب
شارب الشرق الأوسط
ص.ب ١٦٧١٧، جبل علي
ذبي، الامارات العربية المتحدة
تليفون: ٠٠٩٧١٤٨٨١٥٣١١
فاكس: ٠٠٩٧١٤٨٨١٦٦٩٢

SHARP

KZ-SU14-W3

Сэндвичница

Внимательно прочитайте это руководство, прежде чем использовать прибор

РУКОВОДСТВО ПО ЭКСПЛУАТАЦИИ

Правила техники безопасности

Чтобы правильно работать с данным прибором, строго соблюдайте настоящее руководство по эксплуатации.

Чтобы предотвратить травмы персонала и ущерб собственности, необходимо соблюдать следующие правила техники безопасности.

При несоблюдении правил техники безопасности и при неправильной эксплуатации прибора могут произойти несчастные случаи.

- Перед началом использования этого устройства внимательно прочитайте руководство.
- Сохраните это руководство, гарантийный талон, квитанцию о продаже и, по возможности, коробку с внутренней упаковкой.
- Устройство предназначено исключительно для частного, а не для коммерческого использования.
- Вынимайте вилку из розетки, если устройство не используется, при подключении дополнительных компонентов, чистке устройства, а также в случае его неисправности. Сначала выключите устройство. Держите за вилку, а не за кабель.
- Чтобы защитить детей от опасности поражения электрическим током от электроприборов, не следует оставлять их с устройством без присмотра. Поэтому выбирайте такое место для вашего устройства, куда дети не имеют доступ. Следите за тем, чтобы кабель не свисал.
- Регулярно проверяйте устройство и кабель на наличие повреждений. Устройство не следует использовать при наличии каких-либо повреждений.
- Не ремонтируйте устройство самостоятельно, обратитесь в ближайший авторизованный сервисный центр.
- Держите устройство и кабель вдали от источников тепла, прямого солнечного света, влаги, острых краев и т. п.
- Никогда не оставляйте устройство без присмотра во время использования! Выключайте устройство, когда вы им не пользуетесь, даже ненадолго.
- Не используйте устройство вне помещения.
- Ни при каких обстоятельствах не допускается попадание на устройство воды или другой жидкости, а также запрещается погружать устройство в воду или другую жидкость. Не используйте устройство с мокрыми или влажными руками.
- Если на устройство попала жидкость или вода, немедленно выньте вилку из розетки. Не используйте воду.
- Используйте устройство только по назначению.
- Допускается использование прибора детьми 8 лет и старше, а также лицами с ограниченными физическими, сенсорными или умственными способностями, лицами,

не имеющими опыта и знания, необходимых при обращении с такими изделиями, при условии, что за ними осуществляется соответствующий надзор или они ознакомлены с инструкциями, касающимися безопасного использования прибора и объясняющими риски, возникающие в ходе его использования. Дети могут осуществлять очистку и уход за прибором, только если они старше 8 лет и только под присмотром взрослых. Храните прибор и шнур в месте, недоступном для детей младше 8 лет.
- Нагревательные пластины очень горячие. Беритесь только за ручки.
- Ставьте устройство на жаростойкую поверхность или коврик.
- Чтобы избежать тепловой пробки, не устанавливайте прибор непосредственно под шкафами. Позаботьтесь о том, чтобы было достаточно места.
- При открывании полуформ остерегайтесь выходящего пара.
- Мясо может подгореть, по этой причине ни в коем случае не ставьте тостер вблизи или под занавесками или другими легковоспламеняющимися предметами!
- Все электрические приборы представляют риск пожара и поражения электрическим током, что может привести к травмам или смерти. Следуйте всем инструкциям по технике безопасности.
- Если сетевой шнур поврежден, его необходимо заменить у производителя, или в авторизованном сервисном центре либо обратиться к аналогичному квалифицированному персоналу во избежание опасности.
- Не погружайте прибор в какую-либо жидкость.
- Во время работы температура доступной поверхности прибора может быть очень высокой.
- Запрещается использовать древесный уголь или другое подобное горючее с этим прибором.

Если у вас возникли вопросы, относящиеся к эксплуатационным характеристикам и использованию прибора, посетите наш сайт www.sharpmea.com

Убедитесь, что вы поняли вышеупомянутые инструкции по технике безопасности.

Внимательно прочитайте и сохраните все инструкции, поставляемые в комплекте с прибором.

This Icon means surface are liable to get hot during use.

Знай свой продукт

1.Power Indicator Light (Red Cover)
2.Ready Indicator Light(Green Cover)
3.Handle Lock
4.Standing Leg
5.Sandwich/Grill/Waffle Plates
6.Push buttons

Технические данные

Модель: KZ-SU14-W3
Напряжение: 220-240 В
Частота: 50-60 Гц
Номинальная мощность: 1200-1400 Вт

Наименование деталей:-

Запуск устройства

АНТИПРИГАРНОЕ ПОКРЫТИЕ
Слегка смажьте нагревательные поверхности прежде, чем использовать устройство в первый раз. Используйте прибор около 10 минут с закрытыми поверхностями для подрумянивания (см. «Эксплуатация»). Затем протрите его влажной тряпкой.
Не ешьте первые кусочки тостa, который вы сделали.

Эксплуатация

1. Вставьте вилку в розетку с заземлением 220-240 В, 50/60Hz Гц, потребляемая мощность 680-820Вт. Загорится красный неоновый индикатор питания (POWER), затем зеленый неоновый индикатор.

2. Не открывайте нагревательное устройство во время разогрева.
3. Откройте крышку и положите сэндвич. Затем аккуратно закройте крышку. Зафиксируйте ручку защелкой. Стейк готовится 3-5 минут.
4. Откройте крышку и извлеките сэндвич помощью деревянной вилки или аналогичного прибора. Не используйте острые предметы, чтобы не повредить покрытие нагревательных поверхностей.

5. Не следует оставлять открытыми полуформы в перерывах между готовкой.

Чистка и техническое обслуживание:-

- Выньте вилку сетевого шнура и дайте устройству остыть.
- Удалите остатки крошек с нагревательных поверхностей.
- Протирайте прибор только слегка влажной тряпкой.
- Не используйте абразивные моющие средства.
- Данное устройство соответствует CE Директиве о подавлении радиопомех и низковольтной безопасности, а также было произведено с соблюдением требований по безопасному использованию тока. Подлежит техническим изменениям без предварительного уведомления.

SHARP

KZ-SU14-W3

Grill
Сэндвичница
ساندویچ ساز
صانع ساندويتش

Please read these instructions carefully before operating the appliance

OPERATION MANUAL

Safety Notices

Please follow this instruction manual strictly to operate this unit correctly.

To avoid personal injury and property loss, please comply with the following safety notices. Accidents may occur if the user doesn't comply with the safety notices and operate the unit incorrectly.

- Before commissioning this device please read the instruction manual carefully.
- Please keep these instructions, the guaranty certificate, the sales receipt and, if possible, the carton with the inner packaging.
- The device is intended exclusively for private and not for commercial use!
- Always remove the plug from the socket whenever the device is not in use, when attaching accessory parts, cleaning the device or whenever a disturbance occurs. Switch off the device before. Pull on the plug, not on the cable.
- In order to protect children from the dangers of electrical appliances, never leave them unsupervised with the device. Consequently, when selecting the location for your device, do so in such a way that children do not have access to the device. Take care to ensure that the cable does not hang down.
- Test the device and the cable regularly for damage. If there is damage of any kind, the device should not be used.
- Do not repair the device yourself, but take this to nearest authorized service station.
- Keep the device and the cable away from heat, direct sunlight, moisture, sharp edges and such like.
- Never use the device unsupervised! Switch off the device whenever you are not using it, even if this is only for a moment.
- Do not use the device outdoors.
- Under no circumstances must the device be placed in water or other liquid, or come into contact with such. Do not use the device with wet or moist hands.
- Should the device become moist or wet, remove the mains plug from the socket immediately. Do not reach into the water.
- Use the device only for the intended purpose.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

  Children should be supervised to ensure that they do not play with the appliance.

  If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard

supervised. Keep the appliance and its cord out of reach of children less than 8 years.
- The baking surfaces get very hot. Touch the handles only.
- Put the unit down onto a heat-resistant surface or mat.
- In order to prevent heat from building up, do not put the unit directly underneath a cupboard. Ensure that there is enough space all around.
- Beware of steam coming out when you open the baking section.
- The steak can burn, so never use the toaster near or below curtains and other inflammable materials.
- A risk of fire and electrical shock exists in all electrical appliances and may cause personal injury or death. Please follow all safety instructions.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- Do not immerse the appliance in any liquid.
- The temperature of accessible surfaces may be high when the appliance is operating.
- Charcoal or similar combustible fuels must not be used with this appliance.

Important Information
The appliance are not intended to be operated by means of an external timer or separate remote-control system
This appliances is intended to be used in household and similar applications such as: -Staff kitchen areas in shops, offices and others working environments -Farm houses -by clients in hotels, motels and other residential type environments -bed and breakfast type environments

If you have any concerns regarding the performance and use of your appliance, please visit www.sharpmea.com

Ensure the above safety precautions are understood. Read carefully and save all the instructions provided with an appliance.

This Icon means surface are liable to get hot during use.

Know your product

1.Power Indicator Light (Red Cover)
2.Ready Indicator Light(Green Cover)
3.Handle Lock
4.Standing Leg
5.Sandwich/Grill/Waffle Plates
6.Push buttons

Technical Data

Model:KZ-SU14-W3
Voltage:220-240V
Frequency:50-60Hz
Rated Power:1200-1400W

Operation Method

Starting-up the unit
NON-STICK COATING
Lightly grease the baking surfaces before the unit is used for the first time. Use the appliance for about 10 minutes with the toasting surfaces closed (see "using the unit"). Then wipe it down with a damp cloth.
Please do not eat the first pieces of toast you make.

Using the unit

1. Put the plug into an earthed 220-240V/50/60Hz mains socket, the power is 680-820W.
   The Red Neon (POWER) and the Green Neon light up.
   Red Neon indicates connection into the electric power supply.
   Green Neon indicates heating of the cooking plates.
2. Keep the baking unit closed during the warming-up time.
   When the cooking plates are heated to the operating temperature, the Green Neon will be turned off.
   Note: the Green Neon keeps turning on and off while the power is turned on. This means that the operating temperature of cooking plates is constantly maintained.
3. Open the cover and place some sandwich. Then close the lid gently. Block the handle with the hinge. The sandwich will be finished after 3 to 5 minutes.
   Note: The cooking time depends on the type of bread, filling and your preferred toasting level.

4. Open the lid and remove the slices of sandwich with a wooden fork or the like. Do not use pointed or sharp objects to avoid damaging the coating of the baking surfaces.
5. The baking section should always be closed in the intervals between baking. Before cooking another sandwich, close the sandwich maker and wait until the green indicator light is turned off. After you finish using the product, please make sure the power is completely turned off.

Cleaning and Maintenance

- Pull out the mains plug and allow the unit to cool down.
- Brush away remains of crumbs from the baking surfaces
- Clean the machine only with a slightly damp cloth.
- Do not use abrasive detergents.
- This appliance conforms with the CE directives for radio interference suppression and low-voltage safety and has been built to meet current safety requirements. Subject to technical changes without prior notice.

Distributors in GCC:

Saudi Arabia:
Abdul Latif Jameel Electronics and Air-Conditioning Co. Ltd.
10, Al Mukhmal Tower, Rawdah Street.
Al Khalidiya District
Jeddah | Kingdom of Saudi Arabia
Toll Free # 800 127 9999 www.alelectronics.com.sa

UAE:
International Traders (ME) Limited
ITL House, Cosmos Lan, Al Fahidi Street, Bur Dubai
P.O.Box 6, Dubai, UAE
Tel: +971 4352 1155

Kuwait:
AL Yousifi United General Trading
Kuwait City, Abdullah Salem Street,
P.O.Box 126 Safat- 13002, Kuwait
Tel: +965 24844925

Qatar:
Al Muftah Trading & Contracting CO.W.L.L
P.O. Box 875, Doha, State of Qatar
Tel: +974 4446868

Bahrain:
Reuben's Store W.L.L
P.O.Box 233, Muharraq, Kingdom of Bahrain
Tel: +973 17227770

Oman:
Muscat Electronics L.L.C
Mezzanine Floor, Gulf House Building, CBD Area, Ruwi,
P.O.Box 1009. Postal code 114, Jibroo, Muscat, Sultanate of Oman
Tel: +968 24796231

Yemen:
Sydney Store
P.O.Box 5865, Al Tafeer Street, Taiz, Republic of Yemen
Tel: +967 4252231

In GCC Countries, please contact:
SHARP MIDDLE EAST FZE
P.O.Box 17215, Jebel Ali,
Dubai, United Arab Emirates
Tel: +971 4- 8815331
Fax: +971 4- 8816692

SHARP

KZ-SU14-W3

Сэндвичница

Внимательно прочитайте это руководство, прежде чем использовать прибор

РУКОВОДСТВО ПО ЭКСПЛУАТАЦИИ

Правила техники безопасности

Чтобы правильно работать с данным прибором, строго соблюдайте настоящее руководство по эксплуатации.

Чтобы предотвратить травмы персонала и ущерб собственности, необходимо соблюдать следующие правила техники безопасности.

При несоблюдении правил техники безопасности и при неправильной эксплуатации прибора могут произойти несчастные случаи.

- Перед началом использования этого устройства внимательно прочитайте руководство.
- Сохраните это руководство, гарантийный талон, квитанцию о продаже и, по возможности, коробку с внутренней упаковкой.
- Устройство предназначено исключительно для частного, а не для коммерческого использования.
- Вынимайте вилку из розетки, если устройство не используется, при подключении дополнительных компонентов, чистке устройства, а также в случае его неисправности. Сначала выключите устройство. Держите за вилку, а не за кабель.
- Чтобы защитить детей от опасности поражения электрическим током от электроприборов, не следует оставлять их с устройством без присмотра. Поэтому выбирайте такое место для вашего устройства, куда дети не имеют доступ. Следите за тем, чтобы кабель не свисал.
- Регулярно проверяйте устройство и кабель на наличие повреждений. Устройство не следует использовать при наличии каких-либо повреждений.
- Не ремонтируйте устройство самостоятельно, обратитесь в ближайший авторизованный сервисный центр.
- Держите устройство и кабель вдали от источников тепла, прямого солнечного света, влаги, острых краев и т. п.
- Никогда не оставляйте устройство без присмотра во время использования! Выключайте устройство, когда вы им не пользуетесь, даже ненадолго.
- Не используйте устройство вне помещения.
- Ни при каких обстоятельствах не допускается попадание на устройство воды или другой жидкости, а также запрещается погружать устройство в воду или другую жидкость. Не используйте устройство с мокрыми или влажными руками.
- Если на устройство попала жидкость или вода, немедленно выньте вилку из розетки. Не используйте воду.
- Используйте устройство только по назначению.
- Допускается использование прибора детьми 8 лет и старше, а также лицами с ограниченными физическими, сенсорными или умственными способностями, лицами,

не имеющими опыта и знания, необходимых при обращении с такими изделиями, при условии, что за ними осуществляется соответствующий надзор или они ознакомлены с инструкциями, касающимися безопасного использования прибора и объясняющими риски, возникающие в ходе его использования. Дети могут осуществлять очистку и уход за прибором, только если они старше 8 лет и только под присмотром взрослых. Храните прибор и шнур в месте, недоступном для детей младше 8 лет.
- Нагревательные пластины очень горячие. Беритесь только за ручки.
- Ставьте устройство на жаростойкую поверхность или коврик.
- Чтобы избежать тепловой пробки, не устанавливайте прибор непосредственно под шкафами. Позаботьтесь о том, чтобы было достаточно места.
- При открывании полуформ остерегайтесь выходящего пара.
- Мясо может подгореть, по этой причине ни в коем случае не ставьте тостер вблизи или под занавесками или другими легковоспламеняющимися предметами!
- Все электрические приборы представляют риск пожара и поражения электрическим током, что может привести к травмам или смерти. Следуйте всем инструкциям по технике безопасности.
- Если сетевой шнур поврежден, его необходимо заменить у производителя, или в авторизованном сервисном центре либо обратиться к аналогичному квалифицированному персоналу во избежание опасности.
- Не погружайте прибор в какую-либо жидкость.
- Во время работы температура доступной поверхности прибора может быть очень высокой.
- Запрещается использовать древесный уголь или другое подобное горючее с этим прибором.

Если у вас возникли вопросы, относящиеся к эксплуатационным характеристикам и использованию прибора, посетите наш сайт www.sharpmea.com

Убедитесь, что вы поняли вышеупомянутые инструкции по технике безопасности.

Внимательно прочитайте и сохраните все инструкции, поставляемые в комплекте с прибором.

This Icon means surface are liable to get hot during use.

Знай свой продукт

1.Power Indicator Light (Red Cover)
2.Ready Indicator Light(Green Cover)
3.Handle Lock
4.Standing Leg
5.Sandwich/Grill/Waffle Plates
6.Push buttons

Технические данные

Модель: KZ-SU14-W3
Напряжение: 220-240 В
Частота: 50-60 Гц
Номинальная мощность: 1200-1400 Вт

Наименование деталей:-

Запуск устройства

АНТИПРИГАРНОЕ ПОКРЫТИЕ
Слегка смажьте нагревательные поверхности прежде, чем использовать устройство в первый раз. Используйте прибор около 10 минут с закрытыми поверхностями для подрумянивания (см. «Эксплуатация»). Затем протрите его влажной тряпкой.
Не ешьте первые кусочки тостa, который вы сделали.

Эксплуатация

1. Вставьте вилку в розетку с заземлением 220-240 В, 50/60Hz Гц, потребляемая мощность 680-820Вт. Загорится красный неоновый индикатор питания (POWER), затем зеленый неоновый индикатор.

2. Не открывайте нагревательное устройство во время разогрева.
3. Откройте крышку и положите сэндвич. Затем аккуратно закройте крышку. Зафиксируйте ручку защелкой. Стейк готовится 3-5 минут.
4. Откройте крышку и извлеките сэндвич помощью деревянной вилки или аналогичного прибора. Не используйте острые предметы, чтобы не повредить покрытие нагревательных поверхностей.

5. Не следует оставлять открытыми полуформы в перерывах между готовкой.

Чистка и техническое обслуживание:-

- Выньте вилку сетевого шнура и дайте устройству остыть.
- Удалите остатки крошек с нагревательных поверхностей.
- Протирайте прибор только слегка влажной тряпкой.
- Не используйте абразивные моющие средства.
- Данное устройство соответствует CE Директиве о подавлении радиопомех и низковольтной безопасности, а также было произведено с соблюдением требований по безопасному использованию тока. Подлежит техническим изменениям без предварительного уведомления.

SHARP

KZ-SU14-W3

Grill
Сэндвичница
ساندویچ ساز
صانع ساندويتش

Please read these instructions carefully before operating the appliance

OPERATION MANUAL

Safety Notices

Please follow this instruction manual strictly to operate this unit correctly.

To avoid personal injury and property loss, please comply with the following safety notices. Accidents may occur if the user doesn't comply with the safety notices and operate the unit incorrectly.

- Before commissioning this device please read the instruction manual carefully.
- Please keep these instructions, the guaranty certificate, the sales receipt and, if possible, the carton with the inner packaging.
- The device is intended exclusively for private and not for commercial use!
- Always remove the plug from the socket whenever the device is not in use, when attaching accessory parts, cleaning the device or whenever a disturbance occurs. Switch off the device before. Pull on the plug, not on the cable.
- In order to protect children from the dangers of electrical appliances, never leave them unsupervised with the device. Consequently, when selecting the location for your device, do so in such a way that children do not have access to the device. Take care to ensure that the cable does not hang down.
- Test the device and the cable regularly for damage. If there is damage of any kind, the device should not be used.
- Do not repair the device yourself, but take this to nearest authorized service station.
- Keep the device and the cable away from heat, direct sunlight, moisture, sharp edges and such like.
- Never use the device unsupervised! Switch off the device whenever you are not using it, even if this is only for a moment.
- Do not use the device outdoors.
- Under no circumstances must the device be placed in water or other liquid, or come into contact with such. Do not use the device with wet or moist hands.
- Should the device become moist or wet, remove the mains plug from the socket immediately. Do not reach into the water.
- Use the device only for the intended purpose.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

  Children should be supervised to ensure that they do not play with the appliance.

  If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard

supervised. Keep the appliance and its cord out of reach of children less than 8 years.
- The baking surfaces get very hot. Touch the handles only.
- Put the unit down onto a heat-resistant surface or mat.
- In order to prevent heat from building up, do not put the unit directly underneath a cupboard. Ensure that there is enough space all around.
- Beware of steam coming out when you open the baking section.
- The steak can burn, so never use the toaster near or below curtains and other inflammable materials.
- A risk of fire and electrical shock exists in all electrical appliances and may cause personal injury or death. Please follow all safety instructions.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- Do not immerse the appliance in any liquid.
- The temperature of accessible surfaces may be high when the appliance is operating.
- Charcoal or similar combustible fuels must not be used with this appliance.

Important Information
The appliance are not intended to be operated by means of an external timer or separate remote-control system
This appliances is intended to be used in household and similar applications such as: -Staff kitchen areas in shops, offices and others working environments -Farm houses -by clients in hotels, motels and other residential type environments -bed and breakfast type environments

If you have any concerns regarding the performance and use of your appliance, please visit www.sharpmea.com

Ensure the above safety precautions are understood. Read carefully and save all the instructions provided with an appliance.

This Icon means surface are liable to get hot during use.

Know your product

1.Power Indicator Light (Red Cover)
2.Ready Indicator Light(Green Cover)
3.Handle Lock
4.Standing Leg
5.Sandwich/Grill/Waffle Plates
6.Push buttons

Technical Data

Model:KZ-SU14-W3
Voltage:220-240V
Frequency:50-60Hz
Rated Power:1200-1400W

Operation Method

Starting-up the unit
NON-STICK COATING
Lightly grease the baking surfaces before the unit is used for the first time. Use the appliance for about 10 minutes with the toasting surfaces closed (see "using the unit"). Then wipe it down with a damp cloth.
Please do not eat the first pieces of toast you make.

Using the unit

1. Put the plug into an earthed 220-240V/50/60Hz mains socket, the power is 680-820W.
   The Red Neon (POWER) and the Green Neon light up.
   Red Neon indicates connection into the electric power supply.
   Green Neon indicates heating of the cooking plates.
2. Keep the baking unit closed during the warming-up time.
   When the cooking plates are heated to the operating temperature, the Green Neon will be turned off.
   Note: the Green Neon keeps turning on and off while the power is turned on. This means that the operating temperature of cooking plates is constantly maintained.
3. Open the cover and place some sandwich. Then close the lid gently. Block the handle with the hinge. The sandwich will be finished after 3 to 5 minutes.
   Note: The cooking time depends on the type of bread, filling and your preferred toasting level.

4. Open the lid and remove the slices of sandwich with a wooden fork or the like. Do not use pointed or sharp objects to avoid damaging the coating of the baking surfaces.
5. The baking section should always be closed in the intervals between baking. Before cooking another sandwich, close the sandwich maker and wait until the green indicator light is turned off. After you finish using the product, please make sure the power is completely turned off.

Cleaning and Maintenance

- Pull out the mains plug and allow the unit to cool down.
- Brush away remains of crumbs from the baking surfaces
- Clean the machine only with a slightly damp cloth.
- Do not use abrasive detergents.
- This appliance conforms with the CE directives for radio interference suppression and low-voltage safety and has been built to meet current safety requirements. Subject to technical changes without prior notice.

Distributors in GCC:

Saudi Arabia:
Abdul Latif Jameel Electronics and Air-Conditioning Co. Ltd.
10, Al Mukhmal Tower, Rawdah Street.
Al Khalidiya District
Jeddah | Kingdom of Saudi Arabia
Toll Free # 800 127 9999 www.alelectronics.com.sa

UAE:
International Traders (ME) Limited
ITL House, Cosmos Lan, Al Fahidi Street, Bur Dubai
P.O.Box 6, Dubai, UAE
Tel: +971 4352 1155

Kuwait:
AL Yousifi United General Trading
Kuwait City, Abdullah Salem Street,
P.O.Box 126 Safat- 13002, Kuwait
Tel: +965 24844925

Qatar:
Al Muftah Trading & Contracting CO.W.L.L
P.O. Box 875, Doha, State of Qatar
Tel: +974 4446868

Bahrain:
Reuben's Store W.L.L
P.O.Box 233, Muharraq, Kingdom of Bahrain
Tel: +973 17227770