Lumora Pulse Pro - User Manual

Model: LA-PL-200. Document version 5.0, March 2026.

1. Noise control modes

Pulse Pro has three modes: ANC (active noise cancellation), Transparency and Off. Press and hold either earbud for 2 seconds to cycle through the modes. Adaptive ANC adjusts the strength to your surroundings and can be enabled in the Lumora app.

2. Battery

Up to 6 hours of playback with ANC on, or 8 hours with ANC off. The case adds up to 24 hours. The case supports wireless Qi charging and USB-C. A 5-minute charge gives 1 hour of playback.

3. Water resistance

The earbuds are rated IP54 (dust and splash resistant). The case is rated IPX2. Do not submerge the earbuds.

4. Error codes

Note: Pulse Pro uses its own error code list. Codes are not interchangeable with the standard Pulse.

Code	Meaning	What to do
E-101	Earbud not detected in the case	Clean the charging contacts and reinsert the earbud.
E-214	ANC microphone calibration failed	Remove the ear tips, place both earbuds in the open case, and run 'Recalibrate ANC' in the Lumora app (Device > Noise control). Keep the room quiet during the 30-second calibration.
E-502	ANC processor temperature too high	Stop using ANC for 10 minutes and keep the earbuds out of direct sunlight.
E-610	Wireless charging coil fault in the case	Charge the case with USB-C. If wireless charging still fails after 24 hours, contact support.

5. Specifications

Item	Value
Driver	11 mm dynamic with graphene diaphragm
Bluetooth	5.4, SBC, AAC and LDAC
Microphones	6 (3 per earbud)
Multipoint	Supported (2 devices)