Lumora Pulse - User Manual

Model: LA-PL-100. Document version 3.1, February 2026.

1. In the box

Two earbuds, charging case, USB-C cable (50 cm), ear tips in sizes S, M and L (M is pre-installed), quick start card.

2. Pairing

Open the charging case with both earbuds inside. The LED on the case blinks white: the earbuds are in pairing mode. Select 'Lumora Pulse' in your phone's Bluetooth menu. If the LED does not blink, press and hold the button on the back of the case for 3 seconds.

3. Touch controls

Action	Left earbud	Right earbud
Single tap	Play / pause	Play / pause
Double tap	Previous track	Next track
Triple tap	Game Mode on/off (fw 3.2.0+)	Voice assistant
Hold 2 s	Volume down	Volume up

4. Battery and charging

Earbuds: up to 7 hours of playback per charge. The case holds 3 additional full charges, for up to 28 hours in total. A 10-minute charge gives 1.5 hours of playback. Full charge of the case takes about 2 hours with USB-C; wireless (Qi) charging is not supported on Pulse.

Charge between 5 C and 40 C. Charging outside this range is paused automatically to protect the battery.

5. Water resistance

Pulse earbuds are rated IPX4: resistant to sweat and splashes. They are not designed for swimming, showering or submersion. The charging case is not water resistant.

6. Error codes

Error codes are shown in the Lumora app and announced by a voice prompt in the earbud.

Code	Meaning	What to do
E-101	Left earbud not detected in the case	Clean the gold charging contacts on the earbud and inside the case with a dry cotton swab. Reinsert the earbud.
E-214	Battery temperature sensor fault in the RIGHT earbud	Let the earbuds rest at room temperature for 20 minutes outside the case. Update to firmware 3.2.1 or later. If the code appears again, contact support for a replacement right earbud.
E-305	Charging case firmware does not match earbud firmware	Open the Lumora app with the case open and both earbuds inside; the app will offer a case update.
E-410	Pairing memory full (8 devices)	Reset the earbuds: hold the case button for 15 seconds until the LED blinks amber 3 times.

7. Factory reset

Place both earbuds in the case, keep the lid open, and hold the case button for 15 seconds until the LED blinks amber 3 times. Then remove 'Lumora Pulse' from your phone's Bluetooth list before pairing again.

8. Specifications

Item	Value
Driver	10 mm dynamic
Bluetooth	5.3, SBC and AAC
Weight	4.8 g per earbud, 42 g case
Multipoint	Not supported