

CNC Milling Machine Model X200 - Operation Manual, Section 1: Startup

Before powering on the X200, verify that the emergency stop button is in the released (out) position. Check coolant reservoir level; it must be above the minimum fill line marked on the tank. Power on the main disconnect switch located at the rear of the machine, then wait for the control panel to complete its boot sequence, which takes approximately 45 seconds.

CNC Milling Machine Model X200 - Section 2: Homing Procedure

After startup, the machine must be homed before any program can run. Press the HOME button on the control panel. All three axes (X, Y, Z) will move to their reference switches automatically. Do not open the enclosure door during homing. If homing fails, check for obstructions near the limit switches and retry. The homing sequence takes about 20 seconds.

CNC Milling Machine Model X200 - Section 3: Tool Change and Maintenance

Tool changes should only be performed with the spindle fully stopped. Use the manual tool release lever on the spindle head, remove the old tool, insert the new tool until it seats fully, and release the lever to lock it in place.

Perform spindle lubrication every 500 operating hours using ISO VG32 oil. Failure to lubricate on schedule voids the warranty on the spindle bearing.