



# **Wireless Barcode Scanner**

## **Quick Start Guide**



## Matters Needing Attention

- 1.The Barcode Scanner is suggested to charge with USB 3.0 interface of computer (Figure A).
- 2.Please use Power Adapter with DC 5V 1A (Figure B).
- 3.DO NOT use Power Adapter which is greater than 5V 1A; DO NOT use fast charge to avoid damaging the Barcode Scanner.
- 4.The battery level is suggested to save 60% - 80% when not in use.
- 5.Please power off the Barcode Scanner when fully charged.



Figure A




Figure B

## Contents

|                                                     |    |
|-----------------------------------------------------|----|
| Restore Wireless Parameters .....                   | 1  |
| Setting Custom Default Settings.....                | 2  |
| Version .....                                       | 2  |
| Sound Settings .....                                | 3  |
| Sound Frequency Setting .....                       | 4  |
| Vibration Setting .....                             | 4  |
| Electric Quantity Display .....                     | 5  |
| Sleep Time Setting .....                            | 5  |
| Data output format .....                            | 7  |
| Wireless transmission mode .....                    | 7  |
| Data Control (Data Processing for Storage Mode) ... | 8  |
| Communication Mode .....                            | 9  |
| Wireless Pairing Settings.....                      | 12 |
| Bluetooth Mode Function Configuration .....         | 18 |
| Keyboard Language Setting.....                      | 24 |
| Case Conversion .....                               | 29 |
| Hidden character GS replacement function.....       | 30 |
| Customize The Prefix And Suffix Settings .....      | 31 |

|                                             |    |
|---------------------------------------------|----|
| Clear Custom Prefix/Suffix .....            | 32 |
| Hidden Character Settings .....             | 33 |
| Clear Hidden Front/Rear Characters. ....    | 35 |
| End character setting .....                 | 36 |
| Clock Function.....                         | 37 |
| Control Character Set Escape Settings ..... | 38 |
| Appendix-Enter/Exit Settings .....          | 40 |
| Appendix-LED indicator description.....     | 41 |
| Appendix-Buzzer Sound Description .....     | 42 |
| Appendix-Control Character List .....       | 43 |
| Appendix-ASCII code character table .....   | 45 |

## Restore Wireless Parameters

If in use of the process, accidentally scan to other function settings code, which led to the scanning function can not be used normally, through the scan initialization barcode to restore to the initialization state.



Restore Wireless Parameters

NOTE: This bar code is most likely to be used in the following situations:

1. Error in scanner setting.
2. You forget what settings you made for scanners before, and you don't want to use the previous settings.
3. Set up the scanner to use some unusual functions, and use after completion.

## Setting Custom Default Settings

By setting custom default settings, you can set the default values of the wireless parameters of the wireless barcode reader to the required functions. First scan the wireless parameter function you need, and then scan the "Set as custom default settings" barcode. After the setting is completed, the existing functions will replace the original factory default values, and the wireless parameters will not be restored to the original state even if the settings are restored.



Set As Custom Default Settings

## Version



Version

## Sound Settings



Turn Sound Off



Low Volume



Middle Volume



High Volume\*



## Sound Frequency Setting



2.0KHz\*



2.7KHz

## Vibration Setting



Turn On Vibration (optional)



Turn Off Vibration (optional)

Note: Vibration function is selected for some products.

## Electric Quantity Display

Scan the barcode, you can check the power of the scanner



Electric Quantity Display

## Sleep Time Setting



Sleep Interval 30s



Sleep Interval 1min



Sleep Interval 2min



Sleep Interval 5min\*



Sleep Interval 10min



Sleep Interval 30min



Never Sleep



Sleep Immediately

## Data output format



Codepage



Unicode(UTF-8)

## Wireless transmission mode



Synchronous Mode



Storage Mode

## **Data Control (Data Processing for Storage Mode)**

### **Data upload**



Upload All Data

### **Total Data**



Upload Total Data

### **Data Clear**



Data Clear

### **Clear Number of Decoding (Optional)**



Clear Number of Decoding

## Communication Mode

This scanner not only supports wireless communication, but also supports wired communication. When the scanner is wired to the scanner, the scanner automatically switches to wired transmission.

### USB-COM

The USB virtual serial port supports the use of 2.4G mode wireless virtual serial ports and wired USB virtual serial ports.



USB-COM

Note: Whether you use wired or wireless virtual serial ports, you need to install a virtual serial port driver.

### **Wireless 2.4G Mode**



Wireless 2.4G Mode

### **Virtual Bluetooth Mode**



Virtual Bluetooth Mode

### **Bluetooth HID Mode**



Bluetooth HID Mode

## Bluetooth SPP Mode



Bluetooth SPP Mode

## Bluetooth BLE Mode



Bluetooth BLE Mode



## Wireless Pairing Settings

### Wireless 2.4G pairing steps (2.4G receiver pairing)

Support XP, Win7, Win8, Win10, MAC OS, etc.

#### **Step 1:** Scan the "Wireless 2.4G Mode" setting code

When setting the wireless 2.4G mode, it will give priority to connect to the last paired receiver by default.



Wireless 2.4G Mode

**Step 2:** Scan the "One-click Pairing" setting code to enter the pairing state, and the blue LED1 flashes quickly.



One-click Pairing

**Step 3:** Plug the receiver into the host (within 1 minute), hear a "Di", and the blue LED2 stays on. The connection is paired successfully.

**Note:** When the scanner is in the pairing state, you can exit the pairing state by double-clicking the button twice or the pairing timeout for 1 minute.

## **Virtual Bluetooth Pairing Steps (Virtual Bluetooth receiver pairing)**

Support XP, Win7, Win8, Win10, MAC OS, etc.

**Step 1:** Scan the "Virtual Bluetooth Mode" setting code

When setting the virtual Bluetooth mode, the virtual Bluetooth receiver paired last time will be connected first by default.



Virtual Bluetooth Mode

**Step 2:** Scan the "Forced Pairing" setting code to enter the pairing state, and the blue LED1 flashes quickly.



One-click Pairing

**Step 3:** Plug the receiver into the host (within 1 minute), hear a "Di", and the blue LED2 stays on. The connection is paired successfully.

**Note:** When the scanner is in the pairing state, you can exit the pairing state by double-clicking the button twice or the pairing timeout for 1 minute.

## Bluetooth HID Pairing Steps

### Step 1: Scan the "Bluetooth HID Mode" setting code

When setting the wireless Bluetooth HID mode, the Bluetooth that was paired last time will be connected by default.



Bluetooth HID Mode

**Step 2:** Scan the "Forced Pairing" setting code to enter the pairing state, and the blue LED1 and blue LED2 flash alternately.



One-click Pairing

**Note:** Press and hold the button for 8 seconds without releasing it. If you hear a beep, then release the button to enter the Bluetooth HID pairing state (this function needs to be turned on).

**Step 3:** Turn on Bluetooth in the device and search for "BarCode Bluetooth HID".

**Step 4:** Click the "BarCode Bluetooth HID" Bluetooth device to enter the pairing state.

**Step 5:** When you hear a "Di", and the blue LED2 stays on. The connection is paired successfully.

**Note:** When the scanner is in the pairing state, you can exit the pairing state by double-clicking the button twice or the pairing timeout for 1 minute.

## **Bluetooth SPP Pairing Steps**

**Step 1:** Scan the "Bluetooth SPP Mode" setting code

When setting the wireless Bluetooth SPP mode, it will automatically enter the SPP mode and enter the broadcast state by default. You can directly click the BarCode Bluetooth SPP device in the SPP software to pair.



Bluetooth SPP Mode

**Step 2:** Search for "BarCode Bluetooth SPP" in the SPP transparent transmission software.

**Step 3:** Click "BarCode Bluetooth SPP" Bluetooth device to enter the pairing state.

**Step 4:** When you hear a "Di", and the blue LED2 stays on. The connection is paired successfully.

## Bluetooth BLE Pairing Steps

### **Step 1:** Scan the "Bluetooth SPP Mode" setting code

When setting the wireless Bluetooth BLE mode, it will automatically enter the BLE mode and enter the broadcast state by default. You can directly click the BarCode Bluetooth BLE device in the BLE software to pair.



Bluetooth BLE Mode

**Step 2:** Search for "BarCode Bluetooth BLE" in the SPP transparent transmission software.

**Step 3:** Click "BarCode Bluetooth BLE" Bluetooth device to enter the pairing state.

**Step 4:** When you hear a "Di", and the blue LED2 stays on. The connection is paired successfully.

## Bluetooth Mode Function Configuration

### Long press for 8 seconds to enter Bluetooth HID search

When using a Bluetooth barcode, turn on and hold for 8 seconds to enter the Bluetooth HID search, and the Bluetooth configuration connection can be made faster.



Enable



Disable

## IOS System HID Virtual Keyboard Setting



### Show Or Hide The IOS Keyboard

Users can also set to quickly show or hide the IOS keyboard. When the double-click to display the IOS keyboard function is enabled, the IOS virtual keyboard can be called up by quickly clicking the scanner button.



### Turn On The Double-click To Display The IOS Keyboard Function (HID mode)



### Turn Off The Double-click To Display The IOS Keyboard Function (HID mode)



## Bluetooth HID Upload Speed Setting

When using Bluetooth HID to connect to a Bluetooth host, the upload speed of the Bluetooth scanner can be adjusted according to the response capability of the Bluetooth host. If the uploaded content is messy or missing, please lower the speed.



Fast Upload Speed



Medium Upload Speed\*



Slow Upload Speed



Very Low Upload Speed

## Set Bluetooth Name Settings

Use the following steps to customize the Bluetooth name of Bluetooth HID, SPP and BLE.

**Step 1:** Scan the "Custom Bluetooth Name" setting code



Custom Bluetooth Name

**Step 2:** Scan the Bluetooth name barcode.

**Note:** The default name of Bluetooth is "Barcode Scanner". After setting through this step, this barcode will be set to the name of Bluetooth.

**(a)** The name can only be set up to 16 bytes. If the name bar code exceeds 16 bytes, the scanner will only take the first 16 bytes as the Bluetooth name.

**(b)** The complete Bluetooth name includes: Bluetooth name + protocol type, only supports to modify the Bluetooth name. After modifying the Bluetooth name, the names of all Bluetooth protocols have been changed.

**Example: Set the Bluetooth name to: Scanner.**

**Step 1:** Scan the "Custom Bluetooth Name" setting code



Custom Bluetooth Name

**Step 2:** Make and scan the Bluetooth name barcode.



Scanner

Bluetooth Name" Scanner"

**After setting up:**

The name of the Bluetooth HID is displayed as: Scanner HID,;

The name of the Bluetooth SPP is displayed as: Scanner SPP;

The name of Bluetooth BLE is displayed as: Scanner BLE.

## Get the Bluetooth Name



Get the Bluetooth Name

**Note:** Only in the Bluetooth HID, SPP, BLE mode can the Bluetooth name be obtained successfully, otherwise it will fail.

## Keyboard Language Setting

The keyboard key arrangement, symbols, etc. corresponding to different national languages are not the same. The scanner can be virtualized into different national keyboard formats according to actual needs. The keyboard layout setting is applicable to the HID communication interface mode, and the default is "American English keyboard".



English



German



French



Spanish



Italian



Japanese



Belgian French



Portuguese



British English



German IOS keyboard



Brazilian Portuguese



Russian



Czech



Italy 142



Turkey Q



Turkey F



Sweden / Finland



Mexican Spanish



Denmark



Written Norwegian



Croatian/Serbian



Swiss German



Swiss French



Dutch



Hungarian



Polish



Canadian French



Argentina (Latin American)





Slovak



International keyboard

**Note:** The international keyboard supports all small languages on the PC side.

## Case Conversion



Normal (unchanged)\*



Upper (all uppercase)



Lower (all lowercase)



Inverse (reverse case)

This parameter is only valid in standard keyboard input mode and keyboard emulation input control character mode.

## Hidden character GS replacement function

**Step 1:** Scan the "Custom GS Replacement" setting code



Custom GS Replacement

**Step 2:** Query "Appendix-ASCII code character table" to find the barcode corresponding to the character to be replaced and scan it.

### Example:

Replace GS characters with characters that can be displayed|

**Step 1:** Scan the "custom GS replacement" setting code

The second step is to query the "Appendix-ASCII code character table" to find the bar code corresponding to the "|" character and scan it.



Cancel GS Replacement

## Customize The Prefix And Suffix Settings

This product supports up to 32-byte prefix and 32-byte suffix setting.

**Step 1:** Scan the "Add Custom Prefix" or "Add Custom Suffix" setting code;



Add Custom Prefix



Add Custom Suffix

**Step 2:** According to the content to be added, query "Appendix-ASCII code character table" and scan the setting code corresponding to the custom prefix in turn;

**Example:**

Set to "ABC123", add custom prefix "789", add custom suffix "DEF", output "789ABC123DEF"

**Step 1:** Scan the "Add custom prefix" setting code;

**Step 2:** According to the content that needs to be added, query "Appendix-ASCII code character table" and scan the setting codes corresponding to "7", "8" and "9" in turn

**Step 3:** Scan the "Add custom suffix" setting code;

**Step 4:** According to the content that needs to be added, query "Appendix-ASCII code character table" and scan the corresponding setting codes of "D", "E", and "F" in turn;

**Clear Custom Prefix/Suffix**

Refer to adding custom prefix/suffix settings, and follow the steps below to clear custom suffixes.

**Step 1:** Scan the "Add custom prefix" or "Add custom suffix" setting code;

**Step 2:** Scan the "Exit Setting Mode" setting code in "Appendix-Enter/Exit Setting";

**Note:** you can directly scan and restore the factory settings to clear custom prefixes and suffixes.

## Hidden Character Settings

According to the following steps, set the number of characters before and after hiding, up to 16 bits are hidden.

Step 1: Scan the setting code of " Hide Front Characters " or " Hide Rear Characters ";



Hide Front Characters



Hide Rear Characters

**Step 2:** Scan the barcode corresponding to 01-16 in "Appendix-ASCII Code Character Table" according to the number of prefix or suffix characters to be hidden.



%%01

Hide 1 characters



%%02

Hide 2 characters



%%03

Hide 3 characters



%%0A

Hide 10 characters



%%10

Hide 16 characters

Note: For more hidden character digit setting codes, please refer to 01-16 key value setting codes in "Appendix-ASCII Character Table"

## **Clear Hidden Front/Rear Characters.**

Refer to the custom setting of hidden leading characters and follow the steps below to clear the hidden leading characters.

**Step 1:** Scan the setting code of " Hide front characters " or " hide rear characters ";

**Step 2:** Scan the "Exit Setting Mode" setting code in "Appendix-Enter/Exit Setting";

**Note:** You can directly scan and restore factory values to clear custom prefixes.



## End character setting



CR(0x0D)\*



LF(0x0A)



CR+LF(0x0D,0x0A)



HT(0x09)



NONE

## Clock Function



Show Current Time



Add Time Before Barcode



Add Time After Barcode



Clear The Time Before And After The Barcode

**Note:** The clock function needs to be supported by software version 3.0 or higher. The clock function will re-time after the bar coder is turned off. You need to use a tool to synchronize the current time of the computer.

## Control Character Set Escape Settings

The character table used for adding prefixes and suffixes is divided into two parts, the control character table part and the displayable character table part. The character table can be displayed, mainly ASCII characters with key values greater than 31. Generally, these characters can be output directly through the HID keyboard without escaping.

The control character table is mainly the characters whose key value is less than 32. Most of these characters cannot be directly output from the HID keyboard, and need to be escaped to output from the HID keyboard. The scanner defines 4 escape methods, which can be switched by scanning the code. Different ways of escaping. Customers can set a suitable escape character set according to their needs, the default is the escape character set 0.



Escape Character Set 0\*



Escape Character Set 1



Escape Character Set 2



Escape Character Set 3



Escape Character Set 4

Note: The character escape function is supported by wireless version 3.0 and above.

## Appendix-Enter/Exit Settings



Enter Setting Mode



Exit Setting Mode

## **Appendix-LED indicator description**

Blue LED1 flashes once:

---The scanner decoded successfully.

Blue LED2 is on:

---Connection succeeded.

Red LED3 is on:

---Battery is being charged, full off.

Blue LED1 flashes quickly:

--- The scanner is in the 2.4G/virtual Bluetooth pairing state.

Blue LED2 flashes quickly:

--- The scanner is in Bluetooth SPP mode pairing state.

Blue LED1 and blue LED2 blink rapidly alternately:

--- The scanner is in Bluetooth HID mode pairing state.

Blue LED1 and blue LED2 flash quickly and synchronously:

--- The scanner is in the Bluetooth BLE mode pairing state.

Blue LED1 and blue LED2 flash slowly at the same time:

--- The scanner is in an upgraded state.

Note: The lighting instructions in this part are slightly different according to the configuration of different products. For more information, please contact the supplier.

## **Appendix-Buzzer Sound Description**

Basic function description of indicator light:

A long tone (low first and then high frequency) indicates that the power is on

A long beep (high first and then low frequency) means the power is off

A short tone (low frequency) indicates that the normal barcode is read, or the pairing is successful, or the wireless connection is successful.

A short tone (low first and then high frequency) indicates that the scanned data is stored in the storage area

A short tone (high first and then low frequency) means the setting code has been scanned

Three short tones (low frequency) indicate wireless transmission failure or buffer is full

Five short beeps (low frequency) indicate that the battery is dead

Two short beeps (low frequency) indicate wireless disconnection

Two short beeps (high frequency) indicate that the scanned setting code is not working

## Appendix-Control Character List

**Note:** The setting code of the control character table refers to the corresponding setting code of 01-31 in the ASCII character table.

| HEX | Decimal | ASCII | Char set 0 | Char set 1  | Char set 2 | Char set 3 | Char set 4                 |
|-----|---------|-------|------------|-------------|------------|------------|----------------------------|
| 01  | 01      | SOH   | NULL       | Home        | Ctrl+A     | Alt+001    | Small<br>keyboard<br>Enter |
| 02  | 02      | STX   | Ctrl+B     | End         | Ctrl+B     | Alt+002    | Cap Lock                   |
| 03  | 03      | ETX   | Ctrl+C     | Up Arrow    | Ctrl+C     | Alt+003    | Right Arrow                |
| 04  | 04      | EOT   | NULL       | Down Arrow  | Ctrl+D     | Alt+004    | Up Arrow                   |
| 05  | 05      | ENQ   | NULL       | Left Arrow  | Ctrl+E     | Alt+005    | NULL                       |
| 06  | 06      | ACK   | NULL       | Right Arrow | Ctrl+F     | Alt+006    | NULL                       |
| 07  | 07      | BEL   | NULL       | Shift+Tab   | Ctrl+G     | Alt+007    | Enter                      |
| 08  | 08      | BS    | Back Space | Back Space  | Back Space | Alt+008    | Left Arrow                 |
| 09  | 09      | HT    | Tab        | Tab         | Tab        | Alt+009    | Tab                        |
| 0A  | 10      | LF    | Enter      | Enter       | Ctrl+P     | Alt+010    | Down Arrow                 |
| 0B  | 11      | VT    | NULL       | NULL        | Ctrl+Q     | Alt+011    | Tab                        |
| 0C  | 12      | FF    | NULL       | NULL        | Ctrl+R     | Alt+012    | delete                     |
| 0D  | 13      | CR    | Enter      | Enter       | Enter      | Alt+013    | Enter                      |
| 0E  | 14      | S0    | F1         | Page Up     | Ctrl+N     | Alt+014    | Insert                     |
| 0F  | 15      | S1    | F2         | Page Down   | Ctrl+O     | Alt+015    | Esc                        |
| 10  | 16      | DLE   | F3         | F11         | Ctrl+P     | Alt+016    | F11                        |
| 11  | 17      | DC1   | F4         | NULL        | Ctrl+Q     | Alt+017    | Home                       |



|    |    |     |         |      |        |         |                 |
|----|----|-----|---------|------|--------|---------|-----------------|
| 12 | 18 | DC2 | F5      | NULL | Ctrl+R | Alt+018 | Print<br>Screen |
| 13 | 19 | DC3 | F6      | NULL | Ctrl+S | Alt+019 | Back Space      |
| 14 | 20 | DC4 | F7      | NULL | Ctrl+T | Alt+020 | Shift tab       |
| 15 | 21 | NAK | F8      | F12  | Ctrl+U | Alt+021 | F12             |
| 16 | 22 | SYN | F9      | F1   | Ctrl+V | Alt+022 | F1              |
| 17 | 23 | TB  | F10     | F2   | Ctrl+W | Alt+023 | F2              |
| 18 | 24 | CAN | F11     | F3   | Ctrl+X | Alt+024 | F3              |
| 19 | 25 | EM  | F12     | F4   | Ctrl+Y | Alt+025 | F4              |
| 1A | 26 | SUB | NULL    | F5   | Ctrl+Z | Alt+026 | F5              |
| 1B | 27 | Esc | Esc     | F6   | Ctrl+[ | Alt+027 | F6              |
| 1C | 28 | FS  | ALT+028 | F7   | Ctrl+\ | Alt+028 | F7              |
| 1D | 29 | GS  | ALT+029 | F8   | Ctrl+] | Alt+029 | F8              |
| 1E | 30 | RS  | NULL    | F9   | Ctrl+^ | Alt+030 | F9              |
| 1F | 31 | US  | NULL    | F10  | Ctrl+_ | Alt+031 | F10             |

## Appendix-ASCII code character table

The key values 01-31 are invisible characters. Refer to "Appendix-Control Character List" to set the escape character set. The visible character table with the key value of 32-127, this part of the characters can generally be directly output through the HID keyboard without escaping.



%%01

SOH



%%02

STX



%%03

ETX



%%04

EOT



%%05

ENQ



%%06

ACK



%%07

BEL



%%08

BS



%%09

HT



%%0A

LF



%%0B

VT



%%0C

FF



%%0D

CR



%%0E

S0



%%0F

S1



%%10

DLE



%%11

DC1



%%12

DC2



%%13

DC3



%%14

DC4



%%15

NAK



%%16

SYN



%%17

TB



%%18

CAN



%%19

EM



%%1A

SUB



%%1B

Esc



%%1C

FS



%%1D

GS



%%1E

RS



%%1F

US



%%20

SP



%%21

!



%%22

"



%%23

#




%%24

\$



%%25

%




%%26

&



%%27

,



%%28

(



%%29

)



%%2A

\*



%%2B

+



%%2C

,



%%2D

-



%%2E

.



%%2F

/



%%30

0



%%31

1



%%32

2



%%33

3



%%34

4



%%35

5



%%36

6



%%37

7



%%38

8



%%%39

9



%%%3A

:



%%%3B

;



%%%3C

<



%%%3D

=



%%%3E

>



%%%3F

?



%%%40

@



%%%41

A



%%%42

B





%%43

C



%%44

D



%%45

E



%%46

F



%%47

G



%%48

H



%%49

I



%%4A

J



%%4B

K



%%4C

L



%%4D

M



%%4E

N



%%4F

O



%%50

P



%%51

Q



%%52

R



%%53

S



%%54

T



%%55

U



%%56

V




%%57

W



%%58

X



%%59

Y



%%5A

Z



%%5B

[



%%5C

\



%%5D

]



%%5E

^



%%5F

\_



%%60

`



%%61

a



%%62

b



%%63

c



%%64

d



%%65

e



%%66

f



%%67

g



%%68

h



%%69

i



%%6A

j



%%6B

k



%%6C

l



%%6D

m



%%6E

n



%%6F

o



%%70

p



%%71

q



%%72

r



%%73

s



%%74

t



%%75

u



%%76

v



%%77

w



%%78

x



%%79

y



%%7A

z



%%7B

{



%%7C

|



%%7D

}



%%7E

~



%%7F

DEL



%%C7

Ç



%%E7

Ç

