

Address

Vector table entry

Points to

0x08000000

Initial SP

➤ top of stack

0x08000004

Reset

➤ Reset_Handler

0x08000008

NMI

➤ NMI_Handler

0x0800000C

HardFault

➤ HardFault_Handler

⋮

0x08000058

EXTIO

➤ EXTIO_IRQHandler

⋮

EXTI15_10

➤ EXTI15_10_IRQHandler

matched to your
code by symbol *name*