

Pacify Phone X

User Manual

Model: PPX-2026 · Document: MAN-PPX-001 · Revision: 2

S1. In the box

Pacify Phone X · 30 W USB-C power adapter · USB-C cable (1.0 m) · SIM tray tool · Quick start leaflet
Warranty: 24 months from delivery.

S2. Specifications

Display	6.1 in, 2340 x 1080, 60 Hz, OLED
Storage	128 GB, not expandable
Memory	8 GB
Rear cameras	50 MP main, 12 MP ultra-wide
Front camera	16 MP
Battery	4,200 mAh
Charging	30 W wired. No wireless charging on this model.
SIM	One nano-SIM plus one eSIM
Water resistance	IP53, splash resistant only
Weight	178 g

The Phone X Pro adds 120 Hz, 15 W wireless charging, and IP68. Those features are not present on the Phone X.

S3. Setting up

- S3.1 Insert the nano-SIM using the supplied tool, or provision an eSIM from network settings.
- S3.2 Note that once an eSIM profile has been provisioned, the eSIM activation pack is no longer returnable. See POL-RET-002 S5.1(c).
- S3.3 Transfer data from an existing device during setup or later from settings.

S4. Battery and charging

- S4.1 The supplied 30 W adapter charges to about 50% in 30 minutes.
- S4.2 There is no wireless charging on the Phone X. A phone placed on a wireless pad will not charge and this is not a fault.
- S4.3 Battery health is in Settings, Battery, Battery health. Below 80% within 12 months is a warranty matter.

S5. Water resistance

- S5.1 IP53 means protection against dust and against water spray at up to 60 degrees from vertical. It is not immersion protection.
- S5.2 Liquid damage is excluded from warranty cover under POL-WAR-001 S3.1(a) regardless of the IP rating. The rating describes design intent, not a guarantee.

S6. Display

S6.1 The panel is OLED. Prolonged display of static content can cause image retention, which is excluded from cover as cosmetic wear under POL-WAR-001 S3.1(e).

S6.2 Dead or stuck pixel claims follow the five-pixel threshold at POL-WAR-001 S6.

S7. Reset and recovery

S7.1 Force restart: hold power plus volume-down for 12 seconds.

S7.2 Factory reset from Settings, System, Reset. This erases everything.

S7.3 Recovery mode: power off, then hold volume-up while connecting the charger.

S8. Care

S8.1 Use a case. The frame is aluminium and marks easily; cosmetic wear is not covered.

S8.2 Charge between 5 and 35 degrees Celsius.

S8.3 A swollen battery or a device that will not sit flat must be taken out of use immediately.

Pacify Electronics Private Limited.