Messages Applicable to LTS150 and LTS300

MGMSG MOD IDENTIFY	0x0223	20
MGMSG MOD SET CHANENABLESTATE	0x0210	21
MGMSG MOD REQ CHANENABLESTATE	0x0211	21
MGMSG MOD GET CHANENABLESTATE	0x0212	21
MGMSG HW START UPDATEMSGS	0x0011	25
MGMSG HW STOP UPDATEMSGS	0x0012	25
MGMSG HW REQ INFO	0x0005	26
MGMSG_HW_GET_INFO	0x0006	26
MGMSG MOT SET POSCOUNTER	0x0410	36
MGMSG_MOT_REQ_POSCOUNTER	0x0411	36
MGMSG MOT GET POSCOUNTER	0x0412	36
MGMSG MOT SET VELPARAMS	0x0413	39
MGMSG MOT REQ VELPARAMS	0x0414	39
MGMSG MOT GET VELPARAMS	0x0415	39
MGMSG_MOT_SET_JOGPARAMS	0x0416	41
MGMSG MOT REQ JOGPARAMS	0x0417	41
MGMSG_MOT_GET_JOGPARAMS	0x0418	41
MGMSG MOT SET GENMOVEPARAMS	0x043A	46
MGMSG MOT REQ GENMOVEPARAMS	0x043B	46
MGMSG MOT GET GENMOVEPARAMS	0x043C	46
MGMSG MOT SET MOVERELPARAMS	0x0445	47
MGMSG MOT REQ MOVERELPARAMS	0x0446	47
MGMSG MOT GET MOVERELPARAMS	0x0447	47
MGMSG MOT SET MOVEABSPARAMS	0x0450	48
MGMSG MOT REQ MOVEABSPARAMS	0x0451	48
MGMSG MOT GET MOVEABSPARAMS	0x0452	48
MGMSG MOT SET HOMEPARAMS	0x0440	49
MGMSG MOT REQ HOMEPARAMS	0x0441	49
MGMSG MOT GET HOMEPARAMS	0x0442	49
MGMSG MOT SET LIMSWITCHPARAMS	0x0423	51
MGMSG MOT REQ LIMSWITCHPARAMS	0x0424	51
MGMSG MOT GET LIMSWITCHPARAMS	0x0425	51
MGMSG MOT MOVE HOME	0x0443	53
MGMSG MOT MOVE HOMED	0x0444	53
MGMSG_MOT_MOVE_RELATIVE	0x0448	54
MGMSG MOT MOVE COMPLETED	0x0464	56
MGMSG MOT MOVE ABSOLUTE	0x0453	57
MGMSG_MOT_MOVE_JOG	0x046A	59
MGMSG MOT MOVE VELOCITY	0x0457	60
MGMSG_MOT_MOVE_STOP	0x0465	61
MGMSG MOT MOVE STOPPED	0x0466	62
MGMSG_MOT_SET_BOWINDEX	0x0450	63
MGMSG MOT REQ BOWINDEX	0x0451	63
MGMSG MOT GET BOWINDEX	0x0452	63
MGMSG_MOT_SET_EEPROMPARAMS	0x04B9	75
MGMSG MOT GET STATUSUPDATE	0x0481	94
MGMSG_MOT_REQ_STATUSUPDATE	0x0480	_96
MGMSG MOT REQ STATUSBITS	0x0429	99
MGMSG MOT GET STATUSBITS	0x042A	99