HX-200 Hydraulic Pump Service Manual

Document No: HX-200-SM

Revision: A Date: 2023-06-01

Model: HX-200 axial piston pump

1 Introduction

This manual covers inspection, adjustment and repair of the HX-200 axial piston pump used on mobile hydraulic equipment. Read the safety section before starting any work.

1.1 Safety

WARNING: Relieve all hydraulic pressure before disconnecting any line. Fluid escaping under pressure can penetrate the skin and cause serious injury.

CAUTION: Pump surfaces can exceed 80 C during operation. Allow the pump to cool before service.

2 Specifications

The values below apply to pumps with serial numbers from HX2A00001 onward.

Table 1 HX-200 performance specifications

Parameter	Value	Notes
Rated pressure	320 bar (4641 psi)	Continuous duty
Peak pressure	400 bar (5802 psi)	Maximum 10 s
Rated flow	120 L/min	At 1800 rpm
Displacement	67 cm3/rev	Fixed
Relief valve setting	350 bar	Factory set
Dry weight	48 kg	Without fluid
Operating temperature	-20 to 80 C	Fluid temperature
Shaft seal kit	4J-5521	Part number

3 Fluid Recommendations

Use ISO VG 46 anti-wear hydraulic oil. Change filter element 1R-0741 every 250 service hours. Change the hydraulic fluid every 2000 service hours or after any pump failure.

This revision is superseded when a later revision of HX-200-SM is issued.