CNC_Maintenance_v3 - Scope & Safety

Document: CNC_Maintenance_v3.pdf Revision: A Section: Bearing Replacement

Scope: maintenance procedure for bearing replacement on plant equipment.

PPE: ISI helmet, cut-resistant gloves, safety goggles. Isolate power and apply lockout/tagout (LOTO). Operator fatigue below 70%. Written supervisor approval is required before starting.

Bearing Replacement - Procedure

Follow these steps in order:

1. Power OFF + LOTO
2. Remove housing 12mm wrench
3. Replace bearing 6205ZZ
4. Lubricate NLGI-2
5. Torque 25Nm
6. Test 10min

Bearing Replacement - Symptoms, Limits & Escalation

Symptoms and limits: Bearing failure due to vibration >4.5mm/s.

Keywords: bearing, vibration, noise, cnc

Escalate to the maintenance supervisor if the fault persists after one attempt.