Pneumatic_SOP_v1 - Scope & Safety

Document: Pneumatic_SOP_v1.pdf Revision: A Section: Air Pressure Drop

Scope: maintenance procedure for air pressure drop on plant equipment.

PPE: ISI helmet, cut-resistant gloves, safety goggles. Isolate power and apply lockout/tagout (LOTO). Operator fatigue below 70%. Written supervisor approval is required before starting.

Air Pressure Drop - Procedure

Follow these steps in order:

1. Isolate branch
2. Check FRL unit
3. Soap-test fittings
4. Replace seals
5. Drain moisture trap
6. Restore to 6.5bar

Air Pressure Drop - Symptoms, Limits & Escalation

Symptoms and limits: Line pressure <5.5bar.

Keywords: pneumatic, air, pressure drop, compressor

Escalate to the maintenance supervisor if the fault persists after one attempt.