

Solar® Turbines

A Caterpillar Company

Wire List

PD/Unit Number:

4M231 / 1

Project Name:

PROP-92

Sheet Name:

PNL A,SMT130

Revision:

0.1

PERSONNEL / SWS SIGN-IN

BADGE #	DATE	TIME	WIRER	IPV
-----	--/--/----	--:-- --	☐	☐
-----	--/--/----	--:-- --	☐	☐
-----	--/--/----	--:-- --	☐	☐
-----	--/--/----	--:-- --	☐	☐
-----	--/--/----	--:-- --	☐	☐
-----	--/--/----	--:-- --	☐	☐

Table of Contents

#	SECTION	ROWS	PAGE
LOCATION: PNL A SMT130			
1	Grounds	10	3
2	Clips	19	3
3	Resistors	4	3
	$\angle$ VD6211	2	3
	$\angle$ VD6212	2	3
4	FU Jumpers	5	4
	$\angle$ FU0081-FU0091	3	4
	$\angle$ FU0139-FU2100	2	4
5	Relay Mechanical Jumpers	34	4
	$\angle$ A1: KA0131 $\rightarrow$ KA0232	5	4
	$\angle$ A1: KA0176 $\rightarrow$ KA0177	1	4
	$\angle$ A1: KA0235 $\rightarrow$ KA0239	3	4
	$\angle$ A1: KA0241 $\rightarrow$ KA0242	1	4
	$\angle$ A1: KA0243 $\rightarrow$ KA0247	3	4
	$\angle$ A1: KA0249 $\rightarrow$ KA0245	1	4
	$\angle$ A2: KA0131 $\rightarrow$ KA0232	5	4
	$\angle$ A2: KA0133 $\rightarrow$ KA0138	2	4
	$\angle$ A2: KA0176 $\rightarrow$ KA0260	8	4
	$\angle$ A2: KA0241 $\rightarrow$ KA0239	5	4
6	KA Jumpers	1	5
	$\angle$ KA0178 $\rightarrow$ KA0875	1	5
7	KA Twin Ferrules	24	5
	$\angle$ KA0132:11 / FU0139	2	5
	$\angle$ KA0132:12 / KT014315	2	5
	$\angle$ KA0134:11 / FU0139	2	5
	$\angle$ KA0135:21 / KA013521	2	5
	$\angle$ KA0135:22 / KA0176A1	2	5
	$\angle$ KA0137:11 / FU0139	2	5
	$\angle$ KA0137:14 / KA013222	2	5
	$\angle$ KA0141:21 / KT0146A1	2	5
	$\angle$ KA0241:11 / UA1200J21	2	5
	$\angle$ KA0242:11 / KT014618	2	5
	$\angle$ KA0244:11 / FU0139	2	5
	$\angle$ KA0875:14 / FU0213	2	5
8	KT Jumpers	3	6
	$\angle$ KT0140 $\rightarrow$ KT0142	2	6
	$\angle$ KT0141 $\rightarrow$ KT0142	1	6
9	AF/AU Jumpers	10	6
10	Single Connections	164	6
	$\angle$ FU0081	1	6
	$\angle$ XT0082	1	6
	$\angle$ AU0080	2	6
	$\angle$ AF0081	4	6
	$\angle$ AF0082	2	6
	$\angle$ XT0237	2	6

#	SECTION	ROWS	PAGE
	LXT0233	6	6
	LKA0130	2	6
	LKA0178	3	6
	LKA0875	2	6
	LXT0089	3	6
	LKA0135	3	6
	LKA6211	2	6
	LKA6212	2	6
	LAU0090	2	6
	LAFO091	9	6
	LAFO092	17	6
	LAFO093	19	6
	LKA1020	4	6
	LKA0133	2	6
	LKA0136	3	6
	LKA0138	3	6
	LKA0134	2	6
	LKA0137	3	6
	LKA0131	3	6
	LKA0132	3	6
	LKA0141	1	6
	LKA0231	1	6
	LKA0232	3	6
	LKA0176	2	6
	LKA0177	1	6
	LKA0243	3	6
	LKA0244	1	6
	LKA0246	2	6
	LKA0247	2	6
	LKA0245	1	6
	LKA0260	1	6
	LKA0241	3	6
	LKA0242	2	6
	LKA0235	1	6
	LKA0236	3	6
	LKA0237	2	6
	LKA0239	2	6
	LKT0140	4	6
	LKT0141	1	6
	LKT0142	2	6
	LKT0145	3	6
	LKT0146	3	6
	LPC0470	1	6
	LFU0137	1	6
	LFU0080	2	6
	LFU0139	1	6
	LFU0140	1	6
	LXT0135	4	6
	LXT0138	2	6
	LXT0136	1	6
	LXT0134	2	6

#	SECTION	ROWS	PAGE
11	Cables	4	12

Locations: 1

Sections: 97

Rows: 278

Pages: 12

4M231 PROP-92 - Wire List

Unit: 1 Rev: 0.1 Rows: 278

LOCATION:
PNL A,SMT130

Grounds (10)

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
☐	AF0083:SH	AU0080G	GRN	14	☐	AU0080:GND	PWR DIST PANEL	☐	
☐	AF0086:SH	IEG02304	GRN	14	☐	IEG0230:4	PWR DIST PANEL	☐	
☐	AF0083:SH	AF0083G	GRN	14	☐	AF0084:SH	PWR DIST PANEL	☐	
☐	AF0084:SH	AF0084G	GRN	14	☐	AF0085:SH	PWR DIST PANEL	☐	
☐	AF0085:SH	AF0085G	GRN	14	☐	AF0086:SH	PWR DIST PANEL	☐	
☐	AU0090:GND	IEG02305	GRN	14	☐	IEG0230:5	PWR DIST PANEL	☐	
☐	GR0131	GR0131	GRN/YEL	14	☐	FRAME	PWR DIST PANEL	☐	
☐	GR0132	GR0132	GRN/YEL	14	☐	FRAME	PWR DIST PANEL	☐	
☐	GR0111	IEG02303	GRN	14	☐	IEG0230:3	PWR DIST PANEL	☐	
☐	GR0134	IEG02307	GRN	14	☐	IEG0230:7	PWR DIST PANEL	☐	

Clips (19)

FROM		TO				
✓	DEVICE ID	WIRE ID	✓	DEVICE ID	LOCATION	NOTES
☐	XT0080:1	CLIP	☐	XT0080:2	PWR DIST PANEL	
☐	XT0080:2	CLIP	☐	XT0080:3	PWR DIST PANEL	
☐	XT0080:3	CLIP	☐	XT0080:4	PWR DIST PANEL	
☐	XT0081:2	CLIP	☐	XT0081:3	PWR DIST PANEL	
☐	XT0081:3	CLIP	☐	XT0081:4	PWR DIST PANEL	
☐	XT0081:4	CLIP	☐	XT0081:5	PWR DIST PANEL	
☐	XT0081:5	CLIP	☐	XT0081:6	PWR DIST PANEL	
☐	XT0134:1	CLIP	☐	XT0134:2	PWR DIST PANEL	
☐	XT0134:2	CLIP	☐	XT0134:3	PWR DIST PANEL	
☐	XT0134:3	CLIP	☐	XT0134:4	PWR DIST PANEL	
☐	XT0138:1	CLIP	☐	XT0138:2	PWR DIST PANEL	
☐	XT0138:2	CLIP	☐	XT0138:3	PWR DIST PANEL	
☐	XT0138:3	CLIP	☐	XT0138:4	PWR DIST PANEL	
☐	XT0082:1	CLIP	☐	XT0082:2	PWR DIST PANEL	
☐	XT0082:2	CLIP	☐	XT0082:3	PWR DIST PANEL	
☐	XT0135:1	CLIP	☐	XT0135:2	PWR DIST PANEL	
☐	XT0135:2	CLIP	☐	XT0135:3	PWR DIST PANEL	
☐	XT0089:1	CLIP	☐	XT0089:2	PWR DIST PANEL	

FROM			TO				
✓	DEVICE ID	WIRE ID	✓	DEVICE ID	LOCATION	IPV	NOTES
☐	XT0090:1	CLIP	☐	XT0090:2	PWR DIST PANEL	☐	

Resistors (4)

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
VD6211									
☐	VD6211:+-1N4007	-009204	LEAD	---	☐	XT0137:2	PWR DIST PANEL	☐	
☐	VD6211:+-1N4007	KA024611	LEAD	---	☐	XT0137:1	PWR DIST PANEL	☐	
VD6212									
☐	VD6212:+-1N4007	-009213	LEAD	---	☐	XT0137:4	PWR DIST PANEL	☐	
☐	VD6212:+-1N4007	KA024711	LEAD	---	☐	XT0137:3	PWR DIST PANEL	☐	

FU Jumpers (5)

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
FU0081-FU0091									
☐	FU0081:LI	FU0080	WHT	14	☐	FU0082:LI	PWR DIST PANEL	☐	
☐	FU0082:LI	FU0080	WHT	14	☐	FU0090:LI	PWR DIST PANEL	☐	
☐	FU0090:LI	FU0080	WHT	14	☐	FU0091:LI	PWR DIST PANEL	☐	
FU0139-FU2100									
☐	FU0139:LI	FU0137	WHT	14	☐	FU0140:LI	PWR DIST PANEL	☐	
☐	FU0140:LI	FU0137	WHT	14	☐	FU2100:LI	PWR DIST PANEL	☐	

Relay Mechanical Jumpers (34)

FROM			TO				
✓	DEVICE ID	WIRE ID	✓	DEVICE ID	LOCATION	IPV	NOTES
A1: KA0131 -> KA0232							
☐	KA0131:A1	WHT	☐	KA0132:A1	PWR DIST PANEL	☐	
☐	KA0132:A1	WHT	☐	KA0141:A1	PWR DIST PANEL	☐	
☐	KA0141:A1	WHT	☐	KA0230:A1	PWR DIST PANEL	☐	
☐	KA0230:A1	WHT	☐	KA0231:A1	PWR DIST PANEL	☐	
☐	KA0231:A1	WHT	☐	KA0232:A1	PWR DIST PANEL	☐	
A1: KA0176 -> KA0177							
☐	KA0176:A1	WHT	☐	KA0177:A1	PWR DIST PANEL	☐	
A1: KA0235 -> KA0239							
☐	KA0235:A1	WHT	☐	KA0236:A1	PWR DIST PANEL	☐	
☐	KA0236:A1	WHT	☐	KA0237:A1	PWR DIST PANEL	☐	
☐	KA0237:A1	WHT	☐	KA0239:A1	PWR DIST PANEL	☐	
A1: KA0241 -> KA0242							
☐	KA0241:A1	WHT	☐	KA0242:A1	PWR DIST PANEL	☐	
A1: KA0243 -> KA0247							

FROM			TO				
✓	DEVICE ID	WIRE ID	✓	DEVICE ID	LOCATION	IPV	NOTES
☐	KA0243:A1	WHT	☐	KA0244:A1	PWR DIST PANEL	☐	
☐	KA0244:A1	WHT	☐	KA0246:A1	PWR DIST PANEL	☐	
☐	KA0246:A1	WHT	☐	KA0247:A1	PWR DIST PANEL	☐	
A1: KA0249 -> KA0245							
☐	KA0245:A1	WHT	☐	KA0249:A1	PWR DIST PANEL	☐	
A2: KA0131 -> KA0232							
☐	KA0131:A2	WHT	☐	KA0132:A2	PWR DIST PANEL	☐	
☐	KA0132:A2	WHT	☐	KA0141:A2	PWR DIST PANEL	☐	
☐	KA0141:A2	WHT	☐	KA0230:A2	PWR DIST PANEL	☐	
☐	KA0230:A2	WHT	☐	KA0231:A2	PWR DIST PANEL	☐	
☐	KA0231:A2	WHT	☐	KA0232:A2	PWR DIST PANEL	☐	
A2: KA0133 -> KA0138							
☐	KA0133:A2	WHT	☐	KA0136:A2	PWR DIST PANEL	☐	
☐	KA0136:A2	WHT	☐	KA0138:A2	PWR DIST PANEL	☐	
A2: KA0176 -> KA0260							
☐	KA0176:A2	WHT	☐	KA0177:A2	PWR DIST PANEL	☐	
☐	KA0177:A2	WHT	☐	KA0243:A2	PWR DIST PANEL	☐	
☐	KA0243:A2	WHT	☐	KA0244:A2	PWR DIST PANEL	☐	
☐	KA0244:A2	WHT	☐	KA0246:A2	PWR DIST PANEL	☐	
☐	KA0246:A2	WHT	☐	KA0247:A2	PWR DIST PANEL	☐	
☐	KA0247:A2	WHT	☐	KA0249:A2	PWR DIST PANEL	☐	
☐	KA0245:A2	WHT	☐	KA0249:A2	PWR DIST PANEL	☐	
☐	KA0245:A2	WHT	☐	KA0260:A2	PWR DIST PANEL	☐	
A2: KA0241 -> KA0239							
☐	KA0241:A2	WHT	☐	KA0242:A2	PWR DIST PANEL	☐	
☐	KA0235:A2	WHT	☐	KA0242:A2	PWR DIST PANEL	☐	
☐	KA0235:A2	WHT	☐	KA0236:A2	PWR DIST PANEL	☐	
☐	KA0236:A2	WHT	☐	KA0237:A2	PWR DIST PANEL	☐	
☐	KA0237:A2	WHT	☐	KA0239:A2	PWR DIST PANEL	☐	

KA Jumpers ⁽¹⁾

FROM					TO						
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES		
KA0178 -> KA0875											
☐	KA0178:11	KA087511	WHT	20	☐	KA0875:11	PWR DIST PANEL	☐			

KA Twin Ferrules ⁽²⁴⁾

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
KA0132:11 / FU0139									
☐	KA0132:11	FU0139	WHT	20	☐	KA0133:11	PWR DIST PANEL	☐	

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
☐	KA0132:11	FU0139	WHT	20	☐	XT0081:1	PWR DIST PANEL	☐	
KA0132:12 / KT014315									
☐	KA0132:12	KT014315	WHT	20	☐	KA0133:12	PWR DIST PANEL	☐	
☐	KA0132:12	KT014315	WHT	20	☐	KT0142:A1	PWR DIST PANEL	☐	
KA0134:11 / FU0139									
☐	KA0134:11	FU0139	WHT	20	☐	KA0136:11	PWR DIST PANEL	☐	
☐	KA0134:11	FU0139	WHT	20	☐	KT0144:15	PWR DIST PANEL	☐	
KA0135:21 / KA013521									
☐	KA0135:21	KA013521	WHT	20	☐	KA0232:22	PWR DIST PANEL	☐	
☐	KA0135:21	KA013521	WHT	20	☐	KA0249:11	PWR DIST PANEL	☐	
KA0135:22 / KA0176A1									
☐	KA0135:22	KA0176A1	WHT	20	☐	KA0176:A1	PWR DIST PANEL	☐	
☐	KA0135:22	KA0176A1	WHT	20	☐	KA0249:12	PWR DIST PANEL	☐	
KA0137:11 / FU0139									
☐	KA0137:11	FU0139	WHT	20	☐	KT0140:15	PWR DIST PANEL	☐	
☐	KA0137:11	FU0139	WHT	20	☐	KT0144:15	PWR DIST PANEL	☐	
KA0137:14 / KA013222									
☐	KA0137:14	KA013222	WHT	20	☐	KT0141:18	PWR DIST PANEL	☐	
☐	KA0137:14	KA013222	WHT	20	☐	KT0144:18	PWR DIST PANEL	☐	
KA0141:21 / KT0146A1									
☐	KA0141:21	KT0146A1	WHT	20	☐	KA0241:21	PWR DIST PANEL	☐	
☐	KA0141:21	KT0146A1	WHT	20	☐	KT0146:A1	PWR DIST PANEL	☐	
KA0241:11 / UA1200J21									
☐	KA0241:11	UA1200J21	WHT	20	☐	KA0236:21	PWR DIST PANEL	☐	
☐	KA0241:11	UA1200J21	WHT	20	☐	XT0233:1	PWR DIST PANEL	☐	
KA0242:11 / KT014618									
☐	KA0242:11	KT014618	WHT	20	☐	KA0231:11	PWR DIST PANEL	☐	
☐	KA0242:11	KT014618	WHT	20	☐	KT0146:18	PWR DIST PANEL	☐	
KA0244:11 / FU0139									
☐	KA0244:11	FU0139	WHT	20	☐	KT0142:15	PWR DIST PANEL	☐	
☐	KA0244:11	FU0139	WHT	20	☐	XT0081:2	PWR DIST PANEL	☐	
KA0875:14 / FU0213									
☐	KA0875:14	FU0213	WHT	20	☐	KA0232:12	PWR DIST PANEL	☐	
☐	KA0875:14	FU0213	WHT	20	☐	XT0089:7	PWR DIST PANEL	☐	

KT Jumpers (3)

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
KT0140 -> KT0142									
☐	KT0140:A2	-0V	WHT	20	☐	KT0141:A2	PWR DIST PANEL	☐	
☐	KT0141:A2	-0V	WHT	20	☐	KT0142:A2	PWR DIST PANEL	☐	
KT0141 -> KT0142									

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
☐	KT0141:A1	KT014315	WHT	20	☐	KT0142:A1	PWR DIST PANEL	☐	

AF/AU Jumpers (10)

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
☐	AF0082:V+	AF0082P	WHT	16	☐	AF0083:V+	PWR DIST PANEL	☐	
☐	AF0082:COM	AF0082N	WHT	16	☐	AF0083:COM	PWR DIST PANEL	☐	
☐	AF0083:V+	AF0083P	WHT	16	☐	AF0084:V+	PWR DIST PANEL	☐	
☐	AF0083:COM	AF0083N	WHT	16	☐	AF0084:COM	PWR DIST PANEL	☐	
☐	AF0084:V+	AF0084P	WHT	16	☐	AF0085:V+	PWR DIST PANEL	☐	
☐	AF0084:COM	AF0084N	WHT	16	☐	AF0085:COM	PWR DIST PANEL	☐	
☐	AF0085:V+	AF0085P	WHT	16	☐	AF0086:V+	PWR DIST PANEL	☐	
☐	AF0085:COM	AF0085N	WHT	16	☐	AF0086:COM	PWR DIST PANEL	☐	
☐	AF0091:V+	AU0090P	WHT	16	☐	AU0090:V+	PWR DIST PANEL	☐	
☐	AF0091:COM	AU0090N	WHT	16	☐	AU0090:COM	PWR DIST PANEL	☐	

Single Connections (164)

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
FU - FU									
☐	FU0081:LI	FU0080	WHT	14	☐	FU0080:LD	PWR DIST PANEL	☐	
XT - XT									
☐	XT0082:3	-0V	WHT	16	☐	XT0090:1	PWR DIST PANEL	☐	
☐	XT0080:1	-0V	WHT	20	☐	XT0135:2	PWR DIST PANEL	☐	
☐	XT0136:4	FU0139	WHT	14	☐	XT0081:4	PWR DIST PANEL	☐	
AU0080									
☐	AU0080:V+	FU0081	WHT	16	☐	FU0081:LD	PWR DIST PANEL	☐	
☐	AU0080:COM	-0V	WHT	16	☐	XT0082:2	PWR DIST PANEL	☐	
AF0081									
☐	AF0081:V+	FU0082	WHT	16	☐	FU0082:LD	PWR DIST PANEL	☐	
☐	AF0081:COM	-0V	WHT	16	☐	XT0082:3	PWR DIST PANEL	☐	
☐	AF0081:20	SV21202	WHT	20	☐	XT0240:1	PWR DIST PANEL	☐	
☐	AF0081:04	-008104	WHT	20	☐	KA0221:14	PWR DIST PANEL	☐	
AF0082									
☐	AF0082:V+	AU0080P	WHT	16	☐	AU0080:V+	PWR DIST PANEL	☐	
☐	AF0082:COM	AU0080N	WHT	16	☐	AU0080:COM	PWR DIST PANEL	☐	
XT0237									
☐	XT0237:1 B2	-007511	WHT	20	☐	AF0075:11	PWR DIST PANEL	☐	
☐	XT0237:1 B1	UA1200J15	WHT	20	☐	UA1200:J1-5	PWR DIST PANEL	☐	
XT0233									
☐	XT0233:1	UA1200J21	WHT	20	☐	UA1200:J2-1	PWR DIST PANEL	☐	

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
☐	XT0233:2	FU0212	WHT	20	☐	UA1200:J1-10	PWR DIST PANEL	☐	
☐	XT0233:2	FU0212	WHT	20	☐	UA1200:J2-2	PWR DIST PANEL	☐	
☐	XT0233:3	-0V	WHT	20	☐	UA1200:J1-9	PWR DIST PANEL	☐	
☐	XT0233:3	-0V	WHT	20	☐	XT0235:3	PWR DIST PANEL	☐	
☐	XT0233:2	FU0212	WHT	16	☐	FU0212:LD	PWR DIST PANEL	☐	
KA0130									
☐	KA0130:A1	-009338	WHT	20	☐	KA0130:11	PWR DIST PANEL	☐	
☐	KA0130:A2	UA1200J26	WHT	20	☐	UA1200:J2-6	PWR DIST PANEL	☐	
KA0178									
☐	KA0178:14	KA017814	WHT	20	☐	KA0232:11	PWR DIST PANEL	☐	
☐	KA0178:A1	KA0178A1	WHT	20	☐	XT0136:11	PWR DIST PANEL	☐	
☐	KA0178:A2	AT017824	WHT	20	☐	XT0136:12	PWR DIST PANEL	☐	
KA0875									
☐	KA0875:11	KA087511	WHT	20	☐	XT0136:1	PWR DIST PANEL	☐	
☐	KA0875:A2	KA0875A2	WHT	20	☐	XT0136:2	PWR DIST PANEL	☐	
XT0089									
☐	XT0089:1	KA0131A1	WHT	20	☐	KA0234:A1	PWR DIST PANEL	☐	
☐	XT0089:6	ESTOP	WHT	20	☐	KA0251:A1	PWR DIST PANEL	☐	
☐	XT0089:7	FU0213	WHT	16	☐	FU0213:LD	PWR DIST PANEL	☐	
KA0135									
☐	KA0135:A2	-0V	WHT	20	☐	KA0137:A2	PWR DIST PANEL	☐	
☐	KA0135:11	KM3150EN	RED	16	☐	XT1135:2	PWR DIST PANEL	☐	
☐	KA0135:12	KM3150EP	RED	16	☐	XT1135:1	PWR DIST PANEL	☐	
KA6211									
☐	KA6211:11	KM6211EN	RED	16	☐	XT1135:4	PWR DIST PANEL	☐	
☐	KA6211:14	KM6211EP	RED	16	☐	XT1135:3	PWR DIST PANEL	☐	
KA6212									
☐	KA6212:11	KM6212EN	RED	16	☐	XT1135:6	PWR DIST PANEL	☐	
☐	KA6212:14	KM6212EP	RED	16	☐	XT1135:5	PWR DIST PANEL	☐	
AU0090									
☐	AU0090:V+	FU0090	WHT	16	☐	FU0090:LD	PWR DIST PANEL	☐	
☐	AU0090:COM	-0V	WHT	16	☐	XT0090:1	PWR DIST PANEL	☐	
AF0091									
☐	AF0091:V+	AF0091P	WHT	16	☐	AF0093:V+	PWR DIST PANEL	☐	
☐	AF0091:47	SB6200NO	WHT	20	☐	XT0139:7	PWR DIST PANEL	☐	
☐	AF0091:36	KA013621	WHT	20	☐	KA0136:21	PWR DIST PANEL	☐	
☐	AF0091:35	KA014111	WHT	20	☐	KA0141:11	PWR DIST PANEL	☐	
☐	AF0091:COM	AF0091N	WHT	16	☐	AF0093:COM	PWR DIST PANEL	☐	
☐	AF0091:15	SB6200C	WHT	20	☐	XT0139:8	PWR DIST PANEL	☐	
☐	AF0091:07	KA0134A1	WHT	20	☐	KA0134:A1	PWR DIST PANEL	☐	
☐	AF0091:04	KA013624	WHT	20	☐	KA0136:24	PWR DIST PANEL	☐	
☐	AF0091:03	KA014114	WHT	20	☐	KA0141:14	PWR DIST PANEL	☐	

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
AF0092									
☐	AF0092:V+	FU0091	WHT	16	☐	FU0091:LD	PWR DIST PANEL	☐	
☐	AF0092:45	-009245	WHT	20	☐	KA0177:14	PWR DIST PANEL	☐	
☐	AF0092:39	-009239	WHT	20	☐	PC0470:+PWR	PWR DIST PANEL	☐	
☐	AF0092:36	-009236	WHT	20	☐	KA0176:14	PWR DIST PANEL	☐	
☐	AF0092:COM	-0V	WHT	16	☐	XT0090:2	PWR DIST PANEL	☐	
☐	AF0092:31	HL62001	WHT	20	☐	XT0139:6	PWR DIST PANEL	☐	
☐	AF0092:29	-009229	WHT	20	☐	KA6212:A2	PWR DIST PANEL	☐	
☐	AF0092:24	KA0875A2	WHT	20	☐	XT0136:2	PWR DIST PANEL	☐	
☐	AF0092:23	-009223	WHT	20	☐	PC0470:-PWR	PWR DIST PANEL	☐	
☐	AF0092:20	-009220	WHT	20	☐	KA6211:A2	PWR DIST PANEL	☐	
☐	AF0092:15	HL62002	WHT	20	☐	XT0139:5	PWR DIST PANEL	☐	
☐	AF0092:13	-009213	WHT	20	☐	XT0137:4	PWR DIST PANEL	☐	
☐	AF0092:08	-009208	WHT	20	☐	KA0875:A1	PWR DIST PANEL	☐	
☐	AF0092:07	-009207	WHT	20	☐	PC0470:INP_A	PWR DIST PANEL	☐	
☐	AF0092:06	KA013114	WHT	20	☐	KA0131:14	PWR DIST PANEL	☐	
☐	AF0092:04	-009204	WHT	20	☐	XT0137:2	PWR DIST PANEL	☐	
☐	AF0092:02	KA0133A1	WHT	20	☐	KA0133:A1	PWR DIST PANEL	☐	
AF0093									
☐	AF0093:44	KA014124	WHT	20	☐	KA0141:24	PWR DIST PANEL	☐	
☐	AF0093:43	SB751211	WHT	16	☐	XT0139:9	PWR DIST PANEL	☐	
☐	AF0093:42	SB047311	WHT	20	☐	XT0139:1	PWR DIST PANEL	☐	
☐	AF0093:39	KA023911	WHT	20	☐	KA0239:11	PWR DIST PANEL	☐	
☐	AF0093:38	-009338	WHT	20	☐	KA0130:A1	PWR DIST PANEL	☐	
☐	AF0093:37	KA026011	WHT	20	☐	KA0260:11	PWR DIST PANEL	☐	
☐	AF0093:35	KA024511	WHT	20	☐	KA0245:11	PWR DIST PANEL	☐	
☐	AF0093:34	KA024311	WHT	20	☐	KA0243:11	PWR DIST PANEL	☐	
☐	AF0093:28	KA0131A2	WHT	20	☐	KA0131:A2	PWR DIST PANEL	☐	
☐	AF0093:12	KT014618	WHT	20	☐	KT0146:18	PWR DIST PANEL	☐	
☐	AF0093:11	SB751212	WHT	16	☐	XT0139:10	PWR DIST PANEL	☐	
☐	AF0093:10	SB047312	WHT	20	☐	XT0139:2	PWR DIST PANEL	☐	
☐	AF0093:07	KA023914	WHT	20	☐	KA0239:14	PWR DIST PANEL	☐	
☐	AF0093:06	-009306	WHT	20	☐	KA0130:14	PWR DIST PANEL	☐	
☐	AF0093:05	KA026014	WHT	20	☐	KA0260:14	PWR DIST PANEL	☐	
☐	AF0093:03	KA024514	WHT	20	☐	KA0245:14	PWR DIST PANEL	☐	
☐	AF0093:02	KA024314	WHT	20	☐	KA0243:14	PWR DIST PANEL	☐	
☐	AF0093:00	UA1200J21	WHT	20	☐	XT0233:1	PWR DIST PANEL	☐	
☐	AF0093:22	UA1200J27	WHT	20	☐	UA1200:J2-7	PWR DIST PANEL	☐	
KA1020									
☐	KA1020:A1	KA1020A1	WHT	20	☐	AF0075:07	PWR DIST PANEL	☐	
☐	KA1020:A2	KA1020A2	WHT	20	☐	AF0075:23	PWR DIST PANEL	☐	

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
☐	KA1020:14	FU0211	WHT	16	☐	FU0211:LD	PWR DIST PANEL	☐	
☐	KA1020:24	-0V	WHT	16	☐	XT0235:2	PWR DIST PANEL	☐	
KA0133									
☐	KA0133:11	FU0139	WHT	20	☐	KT0144:A1	PWR DIST PANEL	☐	
☐	KA0133:A2	-0V	WHT	20	☐	KT0144:A2	PWR DIST PANEL	☐	
KA0136									
☐	KA0136:11	FU0139	WHT	20	☐	KT0144:A1	PWR DIST PANEL	☐	
☐	KA0136:14	KA013821	WHT	20	☐	KA0138:21	PWR DIST PANEL	☐	
☐	KA0136:A1	PS32002	WHT	20	☐	XT0136:5	PWR DIST PANEL	☐	
KA0138									
☐	KA0138:11	KM31701	WHT	20	☐	XT0136:9	PWR DIST PANEL	☐	
☐	KA0138:24	KT0144B1	WHT	20	☐	KT0144:B1	PWR DIST PANEL	☐	
☐	KA0138:A2	-0V	WHT	20	☐	KT0143:A2	PWR DIST PANEL	☐	
KA0134									
☐	KA0134:A1	KA0134A1	WHT	20	☐	AF0081:08	PWR DIST PANEL	☐	
☐	KA0134:A2	-0V	WHT	20	☐	KT0143:A2	PWR DIST PANEL	☐	
KA0137									
☐	KA0137:24	KA013112	WHT	20	☐	AF0091:05	PWR DIST PANEL	☐	
☐	KA0137:A1	KA0137A1	WHT	20	☐	KT0145:18	PWR DIST PANEL	☐	
☐	KA0137:A2	-0V	WHT	20	☐	KT0145:A2	PWR DIST PANEL	☐	
KA0131									
☐	KA0131:11	KA0135A1	WHT	20	☐	KA0135:A1	PWR DIST PANEL	☐	
☐	KA0131:12	KA013112	WHT	20	☐	KA0137:24	PWR DIST PANEL	☐	
☐	KA0131:A1	KA0131A1	WHT	20	☐	KA0242:14	PWR DIST PANEL	☐	
KA0132									
☐	KA0132:21	KA0138A1	WHT	20	☐	KA0138:A1	PWR DIST PANEL	☐	
☐	KA0132:22	KA013222	WHT	20	☐	KT0141:18	PWR DIST PANEL	☐	
☐	KA0132:24	KA013224	WHT	20	☐	KA0134:14	PWR DIST PANEL	☐	
KA - KA									
☐	KA0141:24	KA014124	WHT	20	☐	KA0241:24	PWR DIST PANEL	☐	
☐	KA0231:24	KA023124	WHT	20	☐	KA0245:21	PWR DIST PANEL	☐	
KA0232									
☐	KA0232:21	FU0139	WHT	20	☐	XT0081:3	PWR DIST PANEL	☐	
☐	KA0232:A1	KA0131A1	WHT	20	☐	KA0233:A1	PWR DIST PANEL	☐	
☐	KA0232:A2	KA0131A2	WHT	20	☐	KA0233:A2	PWR DIST PANEL	☐	
KA0176									
☐	KA0176:11	KA024611	WHT	20	☐	XT0137:1	PWR DIST PANEL	☐	
☐	KA0176:A2	-0V	WHT	20	☐	XT0080:3	PWR DIST PANEL	☐	
KA - XT									
☐	KA0177:11	KA024711	WHT	20	☐	XT0137:3	PWR DIST PANEL	☐	
KA0243									
☐	KA0243:21	KA024524	WHT	20	☐	KA0245:24	PWR DIST PANEL	☐	

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
☐	KA0243:24	ESTOPF	WHT	20	☐	XT0139:3	PWR DIST PANEL	☐	
☐	KA0243:A1	KA0243A1	WHT	20	☐	XT0089:3	PWR DIST PANEL	☐	
KA/KT - KT									
☐	KA0244:12	KT0145A1	WHT	20	☐	KT0145:A1	PWR DIST PANEL	☐	
☐	KT0141:A1	KT014315	WHT	20	☐	KT0143:15	PWR DIST PANEL	☐	
KA0246									
☐	KA0246:14	KA6211A1	WHT	20	☐	KA6211:A1	PWR DIST PANEL	☐	
☐	KA0246:11	KA024611	WHT	20	☐	XT0137:1	PWR DIST PANEL	☐	
KA0247									
☐	KA0247:14	KA6212A1	WHT	20	☐	KA6212:A1	PWR DIST PANEL	☐	
☐	KA0247:11	KA024711	WHT	20	☐	XT0137:3	PWR DIST PANEL	☐	
KA:A1 - XT									
☐	KA0245:A1	KA0245A1	WHT	20	☐	XT0089:4	PWR DIST PANEL	☐	
☐	KA0260:A1	KA0260A1	WHT	20	☐	XT0089:5	PWR DIST PANEL	☐	
☐	KA0235:A1	ESTOP	WHT	20	☐	XT0139:12	PWR DIST PANEL	☐	
KA0241									
☐	KA0241:14	KA024114	WHT	20	☐	KA0231:21	PWR DIST PANEL	☐	
☐	KA0241:A1	KA0241A1	WHT	20	☐	XT0081:7	PWR DIST PANEL	☐	
☐	KA0241:A2	-0V	WHT	20	☐	XT0080:4	PWR DIST PANEL	☐	
KA0242									
☐	KA0242:14	KA0131A1	WHT	20	☐	KA0231:14	PWR DIST PANEL	☐	
☐	KA0242:21	KA024221	WHT	20	☐	XT0237:1 T2	PWR DIST PANEL	☐	
KA0236									
☐	KA0236:11	PS32004	WHT	20	☐	XT0136:6	PWR DIST PANEL	☐	
☐	KA0236:14	UF1300P	WHT	20	☐	XT0136:7	PWR DIST PANEL	☐	
☐	KA0236:24	KA024114	WHT	20	☐	KA0241:14	PWR DIST PANEL	☐	
KA0237									
☐	KA0237:21	KA023721	WHT	20	☐	KA0242:24	PWR DIST PANEL	☐	
☐	KA0237:22	FU0212	WHT	20	☐	XT0233:2	PWR DIST PANEL	☐	
KA0239									
☐	KA0239:A1	ESTOP	WHT	20	☐	KA0240:A1	PWR DIST PANEL	☐	
☐	KA0239:A2	-0V	WHT	20	☐	KA0240:A2	PWR DIST PANEL	☐	
KT0140									
☐	KT0140:16	KT014115	WHT	20	☐	KT0141:15	PWR DIST PANEL	☐	
☐	KT0140:18	KT0143A1	WHT	20	☐	KT0143:A1	PWR DIST PANEL	☐	
☐	KT0140:A1	KT0140A1	WHT	20	☐	KT0143:16	PWR DIST PANEL	☐	
☐	KT0140:A2	-0V	WHT	20	☐	XT0080:1	PWR DIST PANEL	☐	
KT0142									
☐	KT0142:15	FU0139	WHT	20	☐	KT0145:15	PWR DIST PANEL	☐	
☐	KT0142:A2	-0V	WHT	20	☐	KT0144:A2	PWR DIST PANEL	☐	
KT0145									
☐	KT0145:15	FU0139	WHT	20	☐	KA0137:21	PWR DIST PANEL	☐	

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
☐	KT0145:18	KA0137A1	WHT	20	☐	KT0142:18	PWR DIST PANEL	☐	
☐	KT0145:A2	-0V	WHT	20	☐	XT0080:2	PWR DIST PANEL	☐	
KT0146									
☐	KT0146:15	KT014615	WHT	20	☐	AF0075:08	PWR DIST PANEL	☐	
☐	KT0146:A2	KT0146A2	WHT	20	☐	AF0075:25	PWR DIST PANEL	☐	
☐	KT0146:B1	KT0146B1	WHT	20	☐	AF0075:09	PWR DIST PANEL	☐	
PC - PC									
☐	PC0470:INP_A	-009207	WHT	20	☐	PC0470:INP_B	PWR DIST PANEL	☐	
FU - XT									
☐	FU0137:LI	FU0136	WHT	14	☐	XT0138:2	PWR DIST PANEL	☐	
☐	FU0139:LD	FU0139	WHT	16	☐	XT0081:1	PWR DIST PANEL	☐	
FU0080									
☐	FU0080:LI	FU0137	WHT	14	☐	FU0137:LD	PWR DIST PANEL	☐	
☐	FU0080:LI	FU0137	WHT	14	☐	FU0139:LI	PWR DIST PANEL	☐	
FU - KA									
☐	FU0140:LD	FU0140	WHT	16	☐	KA0138:14	PWR DIST PANEL	☐	
XT0135									
☐	XT0135:3	-0V	WHT	16	☐	XT0136:10	PWR DIST PANEL	☐	
☐	XT0135:1	-0V	WHT	14	☐	XT0134:2	PWR DIST PANEL	☐	
☐	XT0135:2	-0V	WHT	14	☐	XT0082:1	PWR DIST PANEL	☐	
XT0138									
☐	XT0138:3	FU0136	WHT	14	☐	FU0110:LI	PWR DIST PANEL	☐	
☐	XT0138:1	FU0136	WHT	12	☐	FU0210:LI	PWR DIST PANEL	☐	
XT0134									
☐	XT0134:1	-0V	WHT	14	☐	XT0235:1	PWR DIST PANEL	☐	
☐	XT0134:3	-0V	WHT	14	☐	XT0110:1	PWR DIST PANEL	☐	

Cables (4)

FROM					TO				
✓	DEVICE ID	TYPE	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
Cable: WC5072									
☐	XT0136:1	WC5072	BLK	16	☐	HA0472:BLK-2	CTRL	☐	
☐	XT0136:2	WC5072	WHT	16	☐	HA0472:BLK-1	CTRL	☐	
Cable: WC0009									
☐	AU0080:L1	WC0009	ENET	CABLE	☐	AU0090:L2	PWR DIST PANEL	☐	
Cable: WC0008									
☐	AU0080:L2	WC0008	ENET	CABLE	☐	AU0070:L1	PWR DIST PANEL	☐	