

Solar[®] Turbines

A Caterpillar Company

Wire List

PD/Unit Number:

4M231 / 1

Project Name:

PROP-92

Sheet Name:

PNL B,SMT130

Revision:

0.1

PERSONNEL / SWS SIGN-IN

BADGE #	DATE	TIME	WIRER	IPV
-----	--/--/----	--:-- --	☐	☐
-----	--/--/----	--:-- --	☐	☐
-----	--/--/----	--:-- --	☐	☐
-----	--/--/----	--:-- --	☐	☐
-----	--/--/----	--:-- --	☐	☐
-----	--/--/----	--:-- --	☐	☐

Table of Contents

#	SECTION	ROWS	PAGE
LOCATION: PNL B SMT130			
1	Grounds	23	3
2	Clips	5	3
3	FU Jumpers	9	3
	$\angle$ FU0060-FU0214	4	3
	$\angle$ FU0070-FU0064	5	3
4	Relay Mechanical Jumpers	4	4
	$\angle$ A1: KA0233 $\rightarrow$ KA0234	1	4
	$\angle$ A1: KA0240 $\rightarrow$ KA0251	1	4
	$\angle$ A2: KA0233 $\rightarrow$ KA0234	1	4
	$\angle$ A2: KA0240 $\rightarrow$ KA0251	1	4
5	AF/AU Jumpers	16	4
6	Single Connections	73	4
	$\angle$ FU0110	1	4
	$\angle$ XT0110	1	4
	$\angle$ AF0410	4	4
	$\angle$ AF0420	2	4
	$\angle$ FU0210	1	4
	$\angle$ FU0060	1	4
	$\angle$ FU0211	1	4
	$\angle$ FU0212	1	4
	$\angle$ FU0213	1	4
	$\angle$ FU0214	1	4
	$\angle$ XT0235	4	4
	$\angle$ XT0240	5	4
	$\angle$ KA0233	2	4
	$\angle$ KA0234	1	4
	$\angle$ KA0221	2	4
	$\angle$ KA0222	1	4
	$\angle$ KA0240	2	4
	$\angle$ KA0251	1	4
	$\angle$ AU0070	2	4
	$\angle$ AF0075	15	4
	$\angle$ AF0064	2	4
	$\angle$ AF0063	4	4
	$\angle$ AF0062	2	4
	$\angle$ AF0061	4	4
	$\angle$ AU0060	2	4
	$\angle$ FU0061	1	4
	$\angle$ XT0060	1	4
	$\angle$ UA1200	8	4
7	Cables	11	7

Locations: 1

Sections: 41

Rows: 141

Pages: 7

4M231 PROP-92 - Wire List

Unit: 1 Rev: 0.1 Rows: 141

LOCATION:
PNL B,SMT130

Grounds (23)

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
☐	IEG0230:4	IEG02304	GRN	14	☐	AF0086:SH	PWR DIST PANEL	☐	
☐	IEG0230:5	IEG02305	GRN	14	☐	AU0090:GND	PWR DIST PANEL	☐	
☐	IEG0230:3	IEG02303	GRN	14	☐	GR0111	PWR DIST PANEL	☐	
☐	IEG0230:7	IEG02307	GRN	14	☐	GR0134	PWR DIST PANEL	☐	
☐	IEG0230:8	IEG02308	GRN	16	☐	UA1200:J3-4	PWR DIST PANEL	☐	
☐	IEG0230:9	IEG02309	GRN	14	☐	XT0400:3	PWR DIST PANEL	☐	
☐	AF0065:SH	AF0065G	GRN	14	☐	AF0066:SH	PWR DIST PANEL	☐	
☐	AF0066:SH	AF0066G	GRN	14	☐	AF0067:SH	PWR DIST PANEL	☐	
☐	AF0067:SH	AF0067G	GRN	14	☐	AF0068:SH	PWR DIST PANEL	☐	
☐	AF0071:SH	AF0071G	GRN	14	☐	AF0072:SH	PWR DIST PANEL	☐	
☐	AF0072:SH	AF0072G	GRN	14	☐	AF0073:SH	PWR DIST PANEL	☐	
☐	AF0073:SH	AF0073G	GRN	16	☐	AF0074:SH	PWR DIST PANEL	☐	
☐	AF0065:SH	AU0060G	GRN	14	☐	AU0060:GND	PWR DIST PANEL	☐	
☐	AF0071:SH	AU0070G	GRN	14	☐	AU0070:GND	PWR DIST PANEL	☐	
☐	AF0068:SH	IEG02302	GRN	14	☐	IEG0230:2	PWR DIST PANEL	☐	
☐	AF0074:SH	IEG02301	GRN	14	☐	IEG0230:1	PWR DIST PANEL	☐	
☐	AF0400:12	XT04001	GRN	16	☐	XT0400:1	PWR DIST PANEL	☐	
☐	AF0410:32	XT04001	GRN	16	☐	XT0400:1	PWR DIST PANEL	☐	
☐	AF0420:32	XT04001	GRN	16	☐	XT0400:1	PWR DIST PANEL	☐	
☐	AF0450:32	AF045032	GRN	16	☐	XT0400:2	PWR DIST PANEL	☐	
☐	GR0233	GR0233	GRN/YEL	14	☐	FRAME	PWR DIST PANEL	☐	
☐	GR0244	IEG023011	GRN	14	☐	IEG0230:11	PWR DIST PANEL	☐	
☐	GR0251	IEG02306	GRN	14	☐	IEG0230:6	PWR DIST PANEL	☐	

Clips (5)

FROM			TO				
✓	DEVICE ID	WIRE ID	✓	DEVICE ID	LOCATION	IPV	NOTES
☐	XT0060:1	CLIP	☐	XT0060:2	PWR DIST PANEL	☐	
☐	XT0060:2	CLIP	☐	XT0060:3	PWR DIST PANEL	☐	
☐	XT0235:1	CLIP	☐	XT0235:2	PWR DIST PANEL	☐	
☐	XT0235:2	CLIP	☐	XT0235:3	PWR DIST PANEL	☐	

FROM			TO				
✓	DEVICE ID	WIRE ID	✓	DEVICE ID	LOCATION	IPV	NOTES
☐	XT0070:1	CLIP	☐	XT0070:2	PWR DIST PANEL	☐	

FU Jumpers (9)

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
FU0060-FU0214									
☐	FU0060:LI	FU0210	WHT	14	☐	FU0211:LI	PWR DIST PANEL	☐	
☐	FU0211:LI	FU0210	WHT	14	☐	FU0212:LI	PWR DIST PANEL	☐	
☐	FU0212:LI	FU0210	WHT	14	☐	FU0213:LI	PWR DIST PANEL	☐	
☐	FU0213:LI	FU0210	WHT	14	☐	FU0214:LI	PWR DIST PANEL	☐	
FU0070-FU0064									
☐	FU0061:LI	FU0060	WHT	14	☐	FU0062:LI	PWR DIST PANEL	☐	
☐	FU0062:LI	FU0060	WHT	14	☐	FU0063:LI	PWR DIST PANEL	☐	
☐	FU0063:LI	FU0060	WHT	14	☐	FU0064:LI	PWR DIST PANEL	☐	
☐	FU0064:LI	FU0060	WHT	14	☐	FU0070:LI	PWR DIST PANEL	☐	
☐	FU0070:LI	FU0060	WHT	14	☐	FU0071:LI	PWR DIST PANEL	☐	

Relay Mechanical Jumpers (4)

FROM			TO				
✓	DEVICE ID	WIRE ID	✓	DEVICE ID	LOCATION	IPV	NOTES
A1: KA0233 -> KA0234							
☐	KA0233:A1	WHT	☐	KA0234:A1	PWR DIST PANEL	☐	
A1: KA0240 -> KA0251							
☐	KA0240:A1	WHT	☐	KA0251:A1	PWR DIST PANEL	☐	
A2: KA0233 -> KA0234							
☐	KA0233:A2	WHT	☐	KA0234:A2	PWR DIST PANEL	☐	
A2: KA0240 -> KA0251							
☐	KA0240:A2	WHT	☐	KA0251:A2	PWR DIST PANEL	☐	

AF/AU Jumpers (16)

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
☐	AF0071:V+	AF0071P	WHT	16	☐	AF0072:V+	PWR DIST PANEL	☐	
☐	AF0071:V+	AU0070P	WHT	16	☐	AU0070:V+	PWR DIST PANEL	☐	
☐	AF0071:COM	AF0071N	WHT	16	☐	AF0072:COM	PWR DIST PANEL	☐	
☐	AF0071:COM	AU0070N	WHT	16	☐	AU0070:COM	PWR DIST PANEL	☐	
☐	AF0064:V+	AF0064P	WHT	16	☐	AF0065:V+	PWR DIST PANEL	☐	
☐	AF0064:COM	AF0064N	WHT	16	☐	AF0065:COM	PWR DIST PANEL	☐	
☐	AF0065:V+	AF0065P	WHT	16	☐	AF0066:V+	PWR DIST PANEL	☐	
☐	AF0065:COM	AF0065N	WHT	16	☐	AF0066:COM	PWR DIST PANEL	☐	

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
☐	AF0066:V+	AF0066P	WHT	16	☐	AF0067:V+	PWR DIST PANEL	☐	
☐	AF0066:COM	AF0066N	WHT	16	☐	AF0067:COM	PWR DIST PANEL	☐	
☐	AF0067:V+	AF0067P	WHT	16	☐	AF0068:V+	PWR DIST PANEL	☐	
☐	AF0067:COM	AF0067N	WHT	16	☐	AF0068:COM	PWR DIST PANEL	☐	
☐	AF0072:V+	AF0072P	WHT	16	☐	AF0073:V+	PWR DIST PANEL	☐	
☐	AF0072:COM	AF0072N	WHT	16	☐	AF0073:COM	PWR DIST PANEL	☐	
☐	AF0073:V+	AF0073P	WHT	16	☐	AF0074:V+	PWR DIST PANEL	☐	
☐	AF0073:COM	AF0073N	WHT	16	☐	AF0074:COM	PWR DIST PANEL	☐	

Single Connections (73)

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
FU - XT									
☐	FU0110:LI	FU0136	WHT	14	☐	XT0138:3	PWR DIST PANEL	☐	
☐	FU0210:LI	FU0136	WHT	12	☐	XT0138:1	PWR DIST PANEL	☐	
☐	FU0212:LD	FU0212	WHT	16	☐	XT0233:2	PWR DIST PANEL	☐	
☐	FU0213:LD	FU0213	WHT	16	☐	XT0089:7	PWR DIST PANEL	☐	
☐	FU0214:LD	FU0214	WHT	16	☐	XT0240:6	PWR DIST PANEL	☐	
XT - XT									
☐	XT0110:1	-0V	WHT	14	☐	XT0134:3	PWR DIST PANEL	☐	
☐	XT0060:3	-0V	WHT	14	☐	XT0070:1	PWR DIST PANEL	☐	
AFO410									
☐	AF0410:56	FU0110	WHT	16	☐	AF0420:55	PWR DIST PANEL	☐	
☐	AF0410:55	FU0110	WHT	16	☐	FU0110:LD	PWR DIST PANEL	☐	
☐	AF0410:54	-0V	WHT	16	☐	AF0420:53	PWR DIST PANEL	☐	
☐	AF0410:53	-0V	WHT	16	☐	XT0110:1	PWR DIST PANEL	☐	
AFO420									
☐	AF0420:56	FU0110	WHT	16	☐	AF0450:55	PWR DIST PANEL	☐	
☐	AF0420:54	-0V	WHT	16	☐	AF0450:53	PWR DIST PANEL	☐	
FU - FU									
☐	FU0060:LI	FU0210	WHT	14	☐	FU0210:LD	PWR DIST PANEL	☐	
☐	FU0061:LI	FU0060	WHT	14	☐	FU0060:LD	PWR DIST PANEL	☐	
FU/KA - KA									
☐	FU0211:LD	FU0211	WHT	16	☐	KA1020:14	PWR DIST PANEL	☐	
☐	KA0222:11	KA024024	WHT	20	☐	KA0240:24	PWR DIST PANEL	☐	
XT0235									
☐	XT0235:2	-0V	WHT	14	☐	XT0060:1	PWR DIST PANEL	☐	
☐	XT0235:3	-0V	WHT	20	☐	XT0233:3	PWR DIST PANEL	☐	
☐	XT0235:2	-0V	WHT	16	☐	KA1020:24	PWR DIST PANEL	☐	
☐	XT0235:1	-0V	WHT	14	☐	XT0134:1	PWR DIST PANEL	☐	
XT0240									

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
☐	XT0240:7	-0V	WHT	16	☐	XT0235:3	PWR DIST PANEL	☐	
☐	XT0240:8	LON1S2	WHT	16	☐	XT0240:14	PWR DIST PANEL	☐	
☐	XT0240:12	FU0214	WHT	16	☐	XT0240:6	PWR DIST PANEL	☐	
☐	XT0240:13	-0V	WHT	16	☐	XT0240:7	PWR DIST PANEL	☐	
☐	XT0240:1	SV21202	WHT	20	☐	AF0081:20	PWR DIST PANEL	☐	
KA0233									
☐	KA0233:A1	KA0131A1	WHT	20	☐	KA0232:A1	PWR DIST PANEL	☐	
☐	KA0233:A2	KA0131A2	WHT	20	☐	KA0232:A2	PWR DIST PANEL	☐	
KA:A1 - XT									
☐	KA0234:A1	KA0131A1	WHT	20	☐	XT0089:1	PWR DIST PANEL	☐	
☐	KA0251:A1	ESTOP	WHT	20	☐	XT0089:6	PWR DIST PANEL	☐	
KA0221									
☐	KA0221:11	KA024014	WHT	20	☐	KA0240:14	PWR DIST PANEL	☐	
☐	KA0221:14	-008104	WHT	20	☐	AF0081:04	PWR DIST PANEL	☐	
KA0240									
☐	KA0240:A1	ESTOP	WHT	20	☐	KA0239:A1	PWR DIST PANEL	☐	
☐	KA0240:A2	-0V	WHT	20	☐	KA0239:A2	PWR DIST PANEL	☐	
AU0070									
☐	AU0070:V+	FU0070	WHT	16	☐	FU0070:LD	PWR DIST PANEL	☐	
☐	AU0070:COM	-0V	WHT	16	☐	XT0070:1	PWR DIST PANEL	☐	
AF0075									
☐	AF0075:V+	FU0071	WHT	16	☐	FU0071:LD	PWR DIST PANEL	☐	
☐	AF0075:COM	-0V	WHT	16	☐	XT0070:2	PWR DIST PANEL	☐	
☐	AF0075:20	KA0222A2	WHT	20	☐	KA0222:A2	PWR DIST PANEL	☐	
☐	AF0075:19	KA0221A2	WHT	20	☐	KA0221:A2	PWR DIST PANEL	☐	
☐	AF0075:10	UA1200J14	WHT	20	☐	UA1200:J1-4	PWR DIST PANEL	☐	
☐	AF0075:04	KA0222A1	WHT	20	☐	KA0222:A1	PWR DIST PANEL	☐	
☐	AF0075:03	KA0221A1	WHT	20	☐	KA0221:A1	PWR DIST PANEL	☐	
☐	AF0075:01	KA025124	WHT	20	☐	KA0251:24	PWR DIST PANEL	☐	
☐	AF0075:00	KA025114	WHT	20	☐	KA0251:14	PWR DIST PANEL	☐	
☐	AF0075:25	KT0146A2	WHT	20	☐	KT0146:A2	PWR DIST PANEL	☐	
☐	AF0075:23	KA1020A2	WHT	20	☐	KA1020:A2	PWR DIST PANEL	☐	
☐	AF0075:11	-007511	WHT	20	☐	XT0237:1 B2	PWR DIST PANEL	☐	
☐	AF0075:09	KT0146B1	WHT	20	☐	KT0146:B1	PWR DIST PANEL	☐	
☐	AF0075:08	KT014615	WHT	20	☐	KT0146:15	PWR DIST PANEL	☐	
☐	AF0075:07	KA1020A1	WHT	20	☐	KA1020:A1	PWR DIST PANEL	☐	
AF0064									
☐	AF0064:V+	AU0060P	WHT	16	☐	AU0060:V+	PWR DIST PANEL	☐	
☐	AF0064:COM	AU0060N	WHT	16	☐	AU0060:COM	PWR DIST PANEL	☐	
AF0063									
☐	AF0063:V+	FU0064	WHT	16	☐	FU0064:LD	PWR DIST PANEL	☐	
☐	AF0063:COM	-0V	WHT	16	☐	XT0060:3	PWR DIST PANEL	☐	

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
☐	AF0063:22	SV21242	WHT	20	☐	XT0240:2	PWR DIST PANEL	☐	
☐	AF0063:06	-006306	WHT	20	☐	KA0222:14	PWR DIST PANEL	☐	
AF0062									
☐	AF0062:V+	FU0063	WHT	16	☐	FU0063:LD	PWR DIST PANEL	☐	
☐	AF0062:COM	-0V	WHT	16	☐	XT0060:3	PWR DIST PANEL	☐	
AF0061									
☐	AF0061:V+	FU0062	WHT	16	☐	FU0062:LD	PWR DIST PANEL	☐	
☐	AF0061:COM	-0V	WHT	16	☐	XT0060:2	PWR DIST PANEL	☐	
☐	AF0061:14	-006114	WHT	20	☐	KA0234:14	PWR DIST PANEL	☐	
☐	AF0061:02	-006102	WHT	20	☐	KA0233:14	PWR DIST PANEL	☐	
AU0060									
☐	AU0060:V+	FU0061	WHT	16	☐	FU0061:LD	PWR DIST PANEL	☐	
☐	AU0060:COM	-0V	WHT	16	☐	XT0060:2	PWR DIST PANEL	☐	
UA1200									
☐	UA1200:J1-8	UA1200J	WHT	20	☐	UA1200:J3-5	PWR DIST PANEL	☐	
☐	UA1200:J1-5	UA1200J15	WHT	20	☐	XT0237:1 B1	PWR DIST PANEL	☐	
☐	UA1200:J1-9	-0V	WHT	20	☐	XT0233:3	PWR DIST PANEL	☐	
☐	UA1200:J1-10	FU0212	WHT	20	☐	XT0233:2	PWR DIST PANEL	☐	
☐	UA1200:J2-1	UA1200J21	WHT	20	☐	XT0233:1	PWR DIST PANEL	☐	
☐	UA1200:J2-2	FU0212	WHT	20	☐	XT0233:2	PWR DIST PANEL	☐	
☐	UA1200:J2-6	UA1200J26	WHT	20	☐	KA0130:A2	PWR DIST PANEL	☐	
☐	UA1200:J2-7	UA1200J27	WHT	20	☐	AF0093:22	PWR DIST PANEL	☐	

Cables (11)

FROM					TO				
✓	DEVICE ID	TYPE	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
Cable: WC4524									
☐	AF0067:12	WC4524	RED	20	☐	UA1200:J1-3	PWR DIST PANEL	☐	
☐	AF0067:28	WC4524	BLK	20	☐	UA1200:J1-1	PWR DIST PANEL	☐	
☐	AF0067:60	WC4524	SH	20	☐	FW1:1	PWR DIST PANEL	☐	
Cable: WC0006									
☐	AF0410:L1	WC0006	ENET	CABLE	☐	AU0060:L2	PWR DIST PANEL	☐	
Cable: WC0007									
☐	AU0060:L1	WC0007	ENET	CABLE	☐	AU0070:L2	PWR DIST PANEL	☐	
Cable: WC0041									
☐	AF0410:L2	WC0041	ENET	CABLE	☐	AF0420:L1	PWR DIST PANEL	☐	
Cable: WC0042									
☐	AF0420:L2	WC0042	ENET	CABLE	☐	AF0450:L1	PWR DIST PANEL	☐	
Cable: WC8040									
☐	AF0400:LBUS	WC8040	BUS	CABLE	☐	AF0410:RBUS	PWR DIST PANEL	☐	
Cable: WC8041									
☐	AF0410:LBUS	WC8041	BUS	CABLE	☐	AF0420:RBUS	PWR DIST PANEL	☐	

FROM					TO				
✓	DEVICE ID	TYPE	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
Cable: WC8042									
☐	AF0420:LBUS	WC8042	BUS	CABLE	☐	AF0450:RBUS	PWR DIST PANEL	☐	
Cable: WC0008									
☐	AU0070:L1	WC0008	ENET	CABLE	☐	AU0080:L2	PWR DIST PANEL	☐	