

# **GULFSTREAM G600**

**N183T** 

**COCKPIT REFERENCE GUIDE** 

Revision 1, July 2024

Prepared to AFM Revision 9, dated June 11, 2024

# **AIRPLANE POWER-UP**

EMERGENCY POWER	ARM/Check+
MAIN BATTERIES (Left and Right)	ON
FCS BATTERIES	ON
Fire Test	Perform
APU MASTER	ON
ELECTRICAL POWER CONTROL Panel	Check
BLEED AIR Panel	Check
Main Door	Verify open
Verify APU Ready Light C	On
APU	START
Electronic Checklist	select NORMAL
END	

# **SECURING FROM APU POWER**

Times and Fuel R	ecord/Log
Purge A	s required
Oil Quantity Check (10 to 30 minutes after engine s	shutdown)
GCMS Hangar or Ramp Shutdown	Preselect
Cabin Power	OFF
FCS BATTERIES	OFF
EMERGENCY POWER	OFF
APU	STOP
APU MASTER (RPM less than 70%)	Off
TROVVei	ify closed
MAIN BATTERIES (APU RPM is 0%)	OFF
Wheel Chocks	In place
PARKING BRAKE A	s required
Gear Pins	Install
Probe Covers	Install
**CAUTION**	
When closing the main door, activation of auxiliary hydraulic pump	o may take
up to 20 seconds. remain clear of the main door for 30 second	s following
actuation of close switch.	
Exterior Doors	Secure
END	

# **EXTERNAL AC POWER APPLICATION**

EXT PWR	OFF (out)
Ext	Connect then ON
External TROV fan	As required
MAIN BATTERIES	ON
EXT PWR switch annunciator	Checked illuminated
EXT PWR	ON
CABIN PRES CONTROL MANU	AL and TROV open (if Ext. fan in use)
IRSs	ON (if desired)
EMERGENCY POWER	ARM
-If planning to	utilize Cabin systems-
CABIN MASTERS (CABIN/GALLEY	, 60HZ) Verify in
CABIN PWR	All On (as desired)
GALLEY REFRIGERATOR	As required (GCMS touchscreen)
-If aircr	aft is in hangar-
SAT-IRIDIUM (Cabin Power Pg. 1)	OFF
KA-SAT-BBND (Cabin Power Pg. 2)	OFF
SAT-INMARSAT (Cabin Power Pg. 2	<u>2</u> ) <b>OFF</b>
E	ND

# **REMOVING EXTERNAL AC POWER**

FN	מו
EXTERNAL TROV FAN	OFF and removed
GPU	OFF then disconnected
MAIN BATTERIES	OFF
EXT PWR	OFF (out)
CABIN PRESSURE CONTROL	AUTO (out)
EMERGENCY POWER	OFF
CABIN PWR	OFF

### REFERENCE INFORMATION

### **AIRCRAFT DIMENSIONS**

WINGSPAN	95'
LENGTH	96'1"
HEIGHT	25'3"
MIN TURN DIAMETER	120'
MIN WIDTH FOR 180 DEG TURN	65'

### FLIGHT ATTENDANT / ES BRIEFING

Flight Time	Enroute time and anticipated weather or ATC delays
Aircraft	Safety equipment checked, MEL items that affect the flight
Armed	Executives Services declaration of their armed status
Catering	
<b>C</b> oms	Establish a communications text chain for the crew
Turbulence	Forecasted turbulence
Signals	Cockpit to cabin signals to be used:

- SEATBELT sign on below 10,000' for sterile cockpit, at other times for turbulence
- NO SMOKE sign on for Flight Attendant to be seated (takeoff/landing, turbulence)
- Multiple chimes for Flight Attendant requested to come to cockpit

# TFS RUNWAY CONDITION ASSESMENT MATRIX

Assessment Criteria RCAM			Target Recommended Crosswind Limit (Including Gusts)
Runway Surface Description	RWYCC	Pilot Braking Action	G280 and G600
DRY	6	N/A	G280 25 / G600 30
WET (The runway surface is covered by any visible dampness or water up to and including 1/8 inch (3 mm) depth)  Up to and including 1/8 inch (3 mm) depth: SLUSH DRY SNOW	5	GOOD	15-24
WET SNOW  Outside Air Temperature -15°C and Colder:  COMPACTED SNOW	4	GOOD TO MEDIUM	12-14
SLIPPERY (WHEN) WET (wet runway) DRY SNOW or WET SNOW (any depth) ON TOP OF COMPACTED SNOW  Greater than 1/8 inch (3 mm) depth: DRY SNOW WET SNOW WET SNOW  Warmer than -15°C outside air temperature: COMPACTED SNOW	3	MEDIUM	10-12
Greater than 1/8 inch (3 mm) depth: STANDING WATER SLUSH	2	MEDIUM TO POOR	0-9
ICE, WET ICE SLUSH ON TOP OF ICE WATER ON TOP OF COMAPACTED SNOW DRY SNOW or WET SNOW ON TOP OF ICE	1 & 0	POOR TO LESS THAN POOR / NIL	N/A

## **COLD WEATHER OPERATIONS**

FOR REFERENCE ONLY, CONSULT THE AIRCRAFT OPERATING MANUAL AND LARGE CABIN COLD WX OPS MANUAL FOR COMPLETE GUIDANCE.

Plane Book > Operating Manual > All Weather and Special Flight Ops > Cold Weather Operations

ARINC Docs > Gulfstream G600 > Gulfstream Aircraft Documents > Cold Wx Ops Manual

#### PREFLIGHT AND ENGINE START

- Ensure all ice is removed from the inlet, fan, and nose cone. If currently
  in or previously exposed to icing conditions with SAT of 5 deg C or below,
  a closeup visual inspection with adequate lighting is recommended.
  Inspect all fan blade surfaces (leading edges, trailing edges, front side,
  back side, etc.) for the presence of frozen ice deposits. The fan must be
  verified to be free to rotate and completely free of ice.
- IF N1 EVM EXCEEDS 0.15 IPS AT IDLE IMMEDIATELY AFTER ENGINE START, DO NOT ADVANCE THROTTLES, SHUTDOWN THE ENGINE.

### **DEICE / ANTI-ICE APPLICATION**

Consult the Aircraft Operating Manual:

Plane Book > Operating Manual > All Weather and Special Flight Ops > Cold Weather Operations / Deicing and Anti-Icing Supplemental Information

- Consult with ground crew and reference TFS Deice Reference Card.
- An operational check of flight controls is required prior to flight if Deice or Anti-Ice has been applied to the aircraft.

### TAXI and TAKEOFF

• When icing conditions are present, periodic engine accelerations must be performed to shed ice from the fan blades. The engine accelerations (targeting a 5 second acceleration) must be conducted to a minimum of 60% N1 with a two second dwell at that power setting. The procedure should be performed at 10 minute intervals during all ground operations. The first engine acceleration should be done as soon as practical during taxi, but not more than 10 minutes after engine start.

# ENGINE ICE SHEDDING (GROUND)

CAI / WAI	Verify ON
Throttles (one at a time)	60% N1 minimum for 2 seconds
Throttles	ldle
WAI	As required

- Wing Anti-Ice must be on 4 minutes prior to takeoff in icing conditions.
- Wing Anti-Ice use on ground is limited to a cumulative 20 minutes to prevent de-ice / anti-ice fluid coagulation and contamination of leading edge.

**END** 

## **EMERGENCY BRIEFING INFORMATION**

### T. TYPE OF EMERGENCY

- PROBLEM
- o PLAN
- CALL FIRESIDE PARTNERS 302-613-2020 (Time Permitting)

### E. EXIT PLAN

- MAIN CABIN DOOR
- OVERWING EXITS

### S. SIGNALS

- o 2 MINUTE
- 10 SECONDS
- "EVACUATE"

## T. TIME TO TOUCHDOWN

### P. PREPARE PAX

- o T.E.S.T.
- ENLIST ABLEBODIED PAX
- RE-SEAT
- BRACE POSITION
- DON LIFE VESTS IF APPLICABLE

### R. READY CABIN

- STOW LOOSE ITEMS
- NON-ESSENTIAL POWER
- SECURE CABINETS

## E. EVAC/EXIT REVIEW

- BRIEF PAX
- DEMO EXITS
- BRIEF AND TRAIN ABP ON DUTIES
- DEMO LIFE RAFTS IF APPLICABLE

### P. PIC REPORT

- o ABOVE ITEMS COMPLETE
- ISSUES
- BE SEATED AND BELTED

# CREW RESPONSE TO ACCIDENT or INCIDENT

### **IMMEDIATE ACTIONS:**

- Assist Passengers in evacuating AC to safe location.
- If able, gather needed supplies, medical equipment and portable Satphone (if equipped).
- Contact 911, MedLink or emergency responders.
- Attend to immediate medical needs of passengers.
- Prepare visual distress signals if in remote area and activate ELT.
- Call Fireside Partners 302-613-2020
  - o Fireside will notify Director, Chief Pilot, DOM, or C3
- Proceed to TFS Crew Accident/Incident Response Guidelines in ARINC docs.

# **EMERGENCY EVACUATION**

Crew and Pax Briefing (time permitting)T.E.S.T. and P.R.E.F.
ATCADVISE
PARKING BRAKESe
FUEL CONTROLS (L & R) OFI
Fire Handles (L & R)Pull (solenoid release required
Fire Handles (L & R) (if Req'd) Rotate fully to DISCH 1 / DISCH 2
CABIN PRESSURE CONTROL MANUAI
Outflow ValveFull open (climb
FCS BATTERIESOFI
Note
The APU will shut down when the Right Main Battery switch is
selected off.
MAIN BATTERIES (Left and Right) OFI
Passengers / Crew Evacuate immediately
FND

Refer to previous page for Crew Response to Accident or Incident.