## MACHINE MASTER


Machine Master Screen is the record of different machines with different attributes. This functionality is used to perform the CRUD operations over the machine\_master table.

The term CRUD is short for Create, Read, Update and Delete-

- Create
  - Creates a new row in the machine\_master table with data as entered by the user
- Read
  - Returns a Stream over all the rows in the machine\_ master table
- Update
  - Updates an existing row in machine\_master table in the database from the given entity based on primary key- "machine id"
- Delete
  - Removes the row from machine\_master table in the database that has the same machine\_id as the given entity

When user clicks on the "Add Machine Master" option under the "Master" Menu option of Maintenance, all the machines along with their attributes will be shown here.





Here, you can add a new machine record by clicking toolbar option 'Add new Record', can edit already available machine record by clicking edit button, or delete existing machine record by clicking delete button.

## **Add Machine Master:**

A new machine record is created by clicking toolbar icon 'Add New Record'.

## **Functionalities:**

✓ **List of Machines**: A Machine List table with the following properties is displayed:

### • S No

A unique identifier assigned incrementally or sequentially to the machines, to uniquely identify them.

### Machine Sr No

A unique identifier assigned by the user to the machines, to uniquely identify them.

## • Machine Description

Description of machines corresponding to the particular machine ID.

## • Machine Type

Type of machine is to be selected here. There are some types which are already defined like CNC machine, non-CNC machine, laboratory instruments etc.

## • Working Shop

Sequence of stages are carried out in different shops such as wheel shop, bogie shop etc.

## • Make

Making of machine is done under some section, that section is "make".

### Model

Different models of machine are available, so to differentiate, user have to enter the model of machine.

## Purchased By

Machine is purchased by whom, this data will be entered by user.

## • Purchase No

With every purchase of machine, there is a purchase no associated.

## • Purchase Order Date

The date at which machine is purchased.

## • Maintenance shop ID

IDs associated with the maintenance shop of machines.

## • Date of Commissioned

Date notified by Corporation as the date on which the Plant is ready to commercial operations on machines after successfully completing the testing.

## Machine Cost

Cost at which machine is purchased.

## • Machine Life

Years machine is available for the customer i.e. years for which machine is working.

## • AMC Agency

ID and description associated with the AMC Agency.

### • Machine Status


This feature is not available on the screen but available in the database, tells whether the machine is in failed or working state.

## ✓ Add New Record: There are various fields:


- Machine Sr No
- Machine Description
- Machine Type
- Working Shop
- Make
- Model
- Purchased By
- Purchase No
- Purchase Order Date
- Maintenance Shop ID
- Date of Commissioned
- Machine Cost
- Machine Life
- AMC Agency

**Note**: Editing and deleting of existing data can be done on the screen.


## ADDING NEW RECORD



When you want to add some new information to the existing data or want to update already entered data, you click on the edit button on the screen.



## **DELETE DATA**



## SCHEDULE ACTIVITY MASTER

Machine Schedule Activity is the master screen of all the activities which are to be performed on the machines on the basis of different schedules, activities can be cleaning, greasing etc. This functionality is used to perform the CRUD operations over the machine\_schedule\_activity table. It is the record of all activities.

The term CRUD is short for Create, Read, Update and Delete-

- Create
  - Creates a new row in the machine\_schedule\_activity table with data as entered by the user
- Read
  - Returns a Stream over all the rows in the machine\_schedule\_activity
- Update
  - Updates an existing row in machine\_schedule\_activity table in the database from the given entity based on primary key- "activity no"
- Delete
  - Removes the row from machine\_schedule\_activity table in the database that has the same activity\_no as the given entity

When user clicks on the "Add Schedule Activity" option under the "Master" Menu option of Maintenance, all the activities will be shown here.



Fig: Add Schedule Activity option under Master Menu option

Machine Schedule Activity Description

	Activity Description		
1	MACHINE CLEANING, REMOVAL OF CHIPS FROM COVERS, TROUGHS AND CHIP CONVEYORS.	G	P
2	MACHINE INSPECTION WITH FOCUSING ON LEAKAGE OF MEDIA (OIL, COOLANTS) OUTSIDE OF MACHINE.	6	P
3	INSPECTING THE TIGHTNESS OF MACHINE COVERS AND DAMAGE OF THE ENCLOSURE.	6	P
4	CLEANING THE TAPERED CAVITY OF THE SPINDLE AND TOOL CLAMPING CONE, CHECK WHETHER FUNCTIONAL AREAS ARE NOT DAMAGED.	6	P
5	CHECKING THE PRESSURES OF PRESSURE GAUGES AND IN HYDRAULICS CIRCUITS OF THE MACHINE ACCORDING TO THE DATA IN THE HYDRAULIC DIAGRAM.	4	P
6	CHECKING THE SPECIFIED VALUE OF PRESSURE OF HYDRAULIC UNITS, PRESSURE CAN BE CHECKED ON PRESSURE GAUGES OF THE HYDRAULIC UNIT AND THE LUBRICATION UNIT. THE VALUE IS STATED ON THE LABEL.	6	P
7	COOLING MEDIUM INSPECTION – FOR CONCENTRATION AND CONTAMINATION. NORMAL CONCENTRATION OF COOLANT IS 9-11%, OR IN ACCORDANCE WITH THE INSTRUCTIONS OF THE MANUFACTURER OF COOLANT OR USED TECHNOLOGY.	G	P
8	CHECKING THE OPERATION OF THE "EMERGENCY STOP" PUSHBUTTON. TEST IT IN THE AUTOMATIC MODE; AT THE SAME TIME, MAKE SURE THAT THE TOOL IS NOT PRESENT IN CUT. TEST IT AT SELECTED MEDIUM SPEED OF THE SPINDLE.	6	P
9	CHECKING THE PASSAGE THROUGH THE BORING ON THE BOTTOM SIDE OF THE FRONT FLANGE OF THE SPINDLE (WASTE FROM SEALING LABYRINTH)	6	P
10	CHECKING THE VENTILATION SYSTEM OPERATION. OVERHEATING IS INDICATED WITH AN ERROR MASSAGE ON THE DISPLAY OF THE MACHINE CONTROL SYSTEM.	6	P

Here, you can add a new machine activity record by clicking toolbar option 'Add new Activity', can edit already available activity record by clicking edit button, or delete existing record by clicking delete button.

## **Add New Activity:**

A new activity is created by clicking toolbar icon 'Add New Activity'.


## **Functionalities:**

- ✓ **List of Activities**: An Activity List table with the following properties is displayed:
- S No
  A unique identifier assigned incrementally or sequentially to the machines, to uniquely identify them.
- Activity Description


  Description of activities corresponding to the particular activity no.
- ✓ Add New Record: There are two fields:
- Activity No
- Activity Description

**Note**: Editing and deleting of existing data can be done on the screen.


## ADDING NEW RECORD



When you want to add some new information to the existing data or want to update already entered data, you click on the edit button on the screen.



## **DELETE DATA**



## AMC AGENCY MASTER

AMC stands for Annual Maintenance Contract. It is offered by all manufacturers after sales. It is the term that relates the buyers and the suppliers. The manufacturer company provides the maintenance service to their buyers for their valuable products. The duration of this contract can vary from 1 year to 3 year as per mutual consent of both the parties.

AMC Agency Master is the master screen of all the AMC Agencies which are associated with the individual machine. This functionality is used to perform the CRUD operations over the machine\_amc\_agency table. It is the record of all AMC Agencies.

The term CRUD is short for Create, Read, Update and Delete-

- Create
  - Creates a new row in the machine\_amc\_agency table with data as entered by the user
- Read
  - Returns a Stream over all the rows in the machine\_amc\_agency
- Update
  - Updates an existing row in machine\_amc\_agency table in the database from the given entity based on primary key- "amc agency id"
- Delete
  - Removes the row from machine\_amc\_agency table in the database that has the same amc\_agency\_id as the given entity

When user clicks on the "AMC Agency Master" option under the "Master" Menu option of Maintenance, all the AMC Agencies along with some attributes will be shown here.



Fig: AMC Agency Master option under Master Menu option

Machine Amc Agency + Add new record								ord
Agency Name	♠ Address	Country						
A V Industries	18/2, Punjab Bagh Extn., New Delhi - 110026	India	011 25927421, 25927021	No.	011 25927181	avindustries@hotmail.com	C	
ABL MACHINE	NAGPUR	India					6	
Accurate Gauging & Instruments Pvt Ltd.	Gauge House, 67, Hadapsar Industrial Estate, Pune- 411013	India	020-26870158		020-26870858	accurate@vsl.com	C	

Here, you can add a new AMC Agency record by clicking toolbar option 'Add new record', can edit already available AMC Agency record by clicking edit button, or delete existing record by clicking delete button.

## **Add New Record:**


A new record is created by clicking toolbar icon 'Add New Record'.

## **Functionalities:**


- ✓ **List of AMC Agencies**: An AMC Agency's List table with the following properties is displayed:
- Agency Name Name of the AMC Agency
- Address Address of AMC Agency
- Country
  Country to which AMC Agency belongs
- Telephone Telephone Number of associated AMC Agency
- Phone Phone Number of associated AMC Agency
- Fax Fax associated with AMC Agency
- Email Email ID of associated AMC Agency
- ✓ Add New Record: There are various fields:
- ID
- Agency Name
- Address
- Country
- Telephone
- Phone No.
- Fax
- Email

**Note**: Editing and deleting of existing data can be done on the screen.


## ADDING NEW RECORD



When you want to add some new information to the existing data or want to update already entered data, you click on the edit button on the screen.



## **DELETE DATA**



## **Machine FIR Master**

FIR stands for First Information Report. It is a document prepared by organizations when they receive information about the failure of any machine.

Machine FIR Master is the master screen of all the failure description along with failure codes which are associated with the machines. This functionality is used to perform the CRUD operations over the machine\_failure\_master table. It is the record of all failure descriptions.

The term CRUD is short for Create, Read, Update and Delete-

- Create
  - Creates a new row in the machine\_failure\_master table with data as entered by the user
- Read
  - Returns a Stream over all the rows in the machine\_failure\_master
- Update
  - Updates an existing row in machine\_failure\_master table in the database
- Delete
  - Removes the row from machine\_failure\_master table in the database

When user clicks on the "Add Machine FIR Description" option under the "Master" Menu option of Maintenance, all the failure description along with failure code will be shown here.



Fig: Add Machine FIR Description option under Master Menu option

Machine FIR Master			+ Add new red	cord
		FIR Description		
		JIB ADJUSTED / PROBLEM	C	
	2	PIN BROKEN/BEND/DAMAGED.	C	1
	3	FLUX CYCLON	C	
4	1	A T C PROBLEM.	C	
!	5	SHUTTER NOT OPEN / SHUTTER PROBLOM.	0	1
	5	BOLT/SCREW/NUT/LOOSE,BROKEN & DAMAGED.	0	1
	7	TABLE PROBLEM.	6	1
	3	TABLE PROBLEM.	0	Ī
	)	FINGER,SHEET CLAMPING FINGER DEFECTIVE/BROKEN & MISALIGNMENT.	6	
1	0	COUPLER HEAD REPLACED.	6	1
< < 1 2 323 324 > >> Go	to page: 1 ▼ Row count: 10 ▼		Showing 1-10 of 3	323

FIR Code And Description

Here, you can add a new FIR description record by clicking toolbar option 'Add new record', can edit already available record by clicking edit button, or delete existing record by clicking delete button.

## Add New Record:

A new record is created by clicking toolbar icon 'Add New Record'.

### **Functionalities:**

- ✓ List of Failure Descriptions: A FIR Description List table with the following properties is displayed:
- S No

A unique identifier assigned incrementally or sequentially to the machines, to uniquely identify them.


• FIR Description

Description of FIRs corresponding to the particular failure code


- ✓ **Add New Record**: There are some fields:
- Failure Code
- FIR Description

**Note**: Editing and deleting of existing data can be done on the screen.


## ADDING NEW RECORD



When you want to add some new information to the existing data or want to update already entered data, you click on the edit button on the screen.



**DELETE DATA** 



# SAFETY INSTRUCTION MASTER

Safety Instructions are set of written instructions that identify the health and safety issues that may arise from use of the machinery and equipment or be based on a task or process

Safety Instruction Master is the master screen of all the safety instructions along with safety instruction ID. This functionality is used to perform the CRUD operations over the safety\_instruction\_master table. It is the record of all safety instructions.

The term CRUD is short for Create, Read, Update and Delete-

- Create
  - Creates a new row in the safety\_instruction\_master table with data as entered by the user
- Read
  Returns a Stream over all the rows in the safety\_instruction\_master
- Update
  - Updates an existing row in safety\_instruction\_master table in the database
- Delete
   Removes the row from safety\_instruction\_master table in the database

When user clicks on the "Add Safety Instructions" option under the "Master" Menu option of Maintenance, all the safety instructions will be shown here.



Fig: Add Safety Instructions option under Master Menu option

## Safety Instruction Master SNo Safety Instruction 1 Clean machine 2 washing 3 open pannel

## Safety Instruction Master

Here, you can add a new safety instruction record by clicking toolbar option 'Add new record', can edit already available record by clicking edit button, or delete existing record by clicking delete button.

## **Add New Record:**

A new record is created by clicking toolbar icon 'Add New Record'.


## **Functionalities:**

- ✓ List of Safety Instructions: A Safety Instruction List table with the following properties is displayed:
- S No A unique identifier assigned incrementally or sequentially to the machines, to uniquely identify them.
- Safety Instruction Description


  Description of safety instructions corresponding to the particular safety instruction ID.
- ✓ **Add New Record**: There are some fields:
- Safety instruction ID
- Safety instruction description

**Note**: Editing and deleting of existing data can be done on the screen.


## ADDING NEW RECORD



When you want to add some new information to the existing data or want to update already entered data, you click on the edit button on the screen.



**DELETE DATA** 



## SPARE MASTER

Safety Instructions are set of written instructions that identify the health and safety issues that may arise from use of the machinery and equipment or be based on a task or process

Safety Instruction Master is the master screen of all the safety instructions along with safety instruction ID. This functionality is used to perform the CRUD operations over the safety\_instruction\_master table. It is the record of all safety instructions.

The term CRUD is short for Create, Read, Update and Delete-

- Create
  - Creates a new row in the safety\_instruction\_master table with data as entered by the user
- Read
   Returns a Stream over all the rows in the safety\_instruction\_master
- Update
  Updates an existing row in safety\_instruction\_master table in the database
- Delete
   Removes the row from safety\_instruction\_master table in the database

When user clicks on the "Add Safety Instructions" option under the "Master" Menu option of Maintenance, all the safety instructions will be shown here.



Fig: Add Safety Instructions option under Master Menu option

Safety Instruction Master				
SNo	Safety Instruction			
1	clean machine	Ø 111		
2	washing	Ø 111		
3	open pannel			

## Safety Instruction Master

Here, you can add a new safety instruction record by clicking toolbar option 'Add new record', can edit already available record by clicking edit button, or delete existing record by clicking delete button.

## **Add New Record:**

A new record is created by clicking toolbar icon 'Add New Record'.


## **Functionalities:**

- ✓ List of Safety Instructions: A Safety Instruction List table with the following properties is displayed:
- S No A unique identifier assigned incrementally or sequentially to the machines, to uniquely identify them.
- Safety Instruction Description


  Description of safety instructions corresponding to the particular safety instruction ID.
- ✓ Add New Record: There are some fields:
- Safety instruction ID
- Safety instruction description

Note: Editing and deleting of existing data can be done on the screen.

## ADDING NEW RECORD



When you want to add some new information to the existing data or want to update already entered data, you click on the edit button on the screen.



**DELETE DATA** 

