

Aria Water Leak Sensor — Owner's Manual

Aria Home · SKU ARIA-LEAK · sensor · \$34

This manual covers the Aria Water Leak Sensor (model ARIA-LEAK) only. Other Aria products have their own manuals; procedures and error codes are not interchangeable between models.

1. Specifications

Detection	two contact probes on the base plus a 4-foot rope probe
Alerts	app push, 85 dB local siren, temperature and freeze warning below 41 °F
Radio	Zigbee 3.0 via the Aria Hub
Battery	2 × AAA, about 3 years

2. In the box

Leak Sensor, rope probe, 2 AAA batteries.

3. Setup

1. Place on the floor under the water heater or sink; lay the rope where water pools.

4. Status light

Blue blink: water detected.

Red blink: battery low.

5. Power and battery

Aria Water Leak Sensor: 2 × AAA alkaline, about 3 years.

6. Troubleshooting

Aria Water Leak Sensor — Siren keeps going after the floor is dry. Dry the probes on the base; a film of water on the contacts still reads as wet.

Aria Water Leak Sensor — Freeze alert but the room is warm. The sensor reads its own location; it may be on a cold slab. Raise the freeze threshold in settings.

7. Error codes

Aria Water Leak Sensor error W-02: Rope probe disconnected — reseal the 3.5 mm plug.

8. Factory reset

To factory reset the Aria Water Leak Sensor: Remove the batteries for 30 seconds, then hold the button while reinserting them.

9. Warranty and compatibility

The Aria Water Leak Sensor carries a two-year standard warranty covering manufacturing defects, from the delivery date. Unwanted returns follow the Aria Home returns policy: 30 days from delivery for the Aria Water Leak Sensor (most devices have a 30-day window). Damage caused by the customer is handled as a warranty repair, not a refund.

Works with: Aria app, Aria Hub (required).