
Wiring Diagram for PATTONPAK Condensing Unit PEMS100/150 Single Phase Compressor

MAY 2021 Rev.4



Note

- For the mostat control remove bridge between "1" & "2". Connect Tstat feed to terminal "2". -PEMS models (Embraco NJ compressor) not fitted with C/case heater.

- Wired for automatic pump down

LEGEND	
Neutral	N
Field Wire	
Internal Wire	•

This information is provided for the use of individuals as they see fit. Patton Ltd is not responsible for the use of this information by any party, especially those lacking sufficient skill or knowledge to perform those tasks safely and in accordance with local electrical codes and governance. Any hazard created is the sole responsibility of the user. Patton reserves the right to change information without notice.