

← Go Back

Hardware

MKR IoT Carrier

Tutorials

MKR IoT Carrier User Manual

IoT Smart Garden Setup with MKR IoT Carrier

Home / Hardware / MKR IoT Carrier / MKR IoT Carrier User Manual


MKR IoT Carrier User Manual

Learn how to set up the MKR IoT Carrier, get a quick overview of the compatible boards, components, and the library.

Author · Liam Aljundi · Last revision · 09/30/2025

ON THIS PAGE

Compatible Boards	—
Assembly	
Datasheet	
Arduino Cloud	
Pinout	
Grove Connectors	
Carrier Library	—
Initialization	
Setup	
Humidity & Temperature Sensor	—
Code	
Pressure Sensor	—
Code	
IMU Accelerometer & Gyroscope Sensors	+
RGB and Gesture Sensor	+
Relays	+
Peripherals	+
Memory	+
Power	



The Arduino MKR IoT
Carrier

The Arduino® MKR IoT Carrier is equipped with different sensors, actuators and with a display to leave you free to focus on prototyping and programming your next IoT projects. The carrier does not come equipped with a microcontroller, meaning it only works in combination with an Arduino board. The MKR IoT Carrier comes equipped with 5 RGB LEDs, 5 capacitive touch buttons, a colored display, IMU and a variety of quality sensors. It also features a battery holder for a 18650 Li-Ion battery, SD card holder and Grove connectors.

Compatible Boards

The MKR family of boards share a common pinout, meaning that they can all be easily connected to the MKR IoT Carrier. Here is a list of the MKR boards:

[MKR 1000 WiFi](#)

[MKR FOX 1200](#)

[MKR GSM 1400](#)

[MKR NB 1500](#)

[MKR Vidor 4000](#)


MKR WiFi 1010

MKR Zero

The MKR family boards offer different features that can be useful for your projects. You can [browse through the boards](#) and pick the one that is most compatible for your project.

Assembly

The chosen Arduino MKR board needs to be mounted on top of the MKR IoT Carrier and connected to a computer. The board can be connected as shown in the image below, matching the pin numbers on the board to the ones on the carrier.



Mounting board on the MKR IoT Carrier

Datasheet

The full datasheet is available as a downloadable PDF from the link below:

[Download the Arduino MKR IoT Carrier datasheet](#)

Arduino Cloud

The MKR IoT Carrier can be controlled through the [Arduino Cloud](#), a Cloud service that allows us to create IoT applications in just minutes, if combined with an Arduino Cloud compatible board. Here's a list of the Arduino MKR family boards that are compatible with the Arduino Cloud:

[MKR 1000 WiFi](#)

[MKR GSM 1400](#)

[MKR NB 1500](#)

[MKR WAN 1300](#)


[MKR WAN 1310](#)

[MKR WiFi 1010](#)

Note: The MKR GSM 1400 and MKR NB 1500 require a SIM card to connect to the Cloud, as they communicate over the mobile networks. The MKR WAN 1300 and 1310 board requires a [Arduino PRO Gateway LoRa®](#) to connect to the Cloud.

If you need help to get started, you can go through the [Arduino Cloud tutorial](#).


Pinout



To see the full pinout, you can download the PDF from the link below.

[The MKR IoT Carrier full pinout \(PDF\)](#)

Grove Connectors



Grove connectors on the MKR IoT Carrier

The MKR IoT Carrier comes with **three grove connectors** (2 analog and 1 I2C) that enables us to easily connect external sensors. The type of the connector is labeled clearly on the back of the carrier.

Carrier Library

To program the MKR IoT Carrier, the [Arduino_MKRIoTCarrier](#) library needs to be included. This library allows us to control and read all the components of the MKR IoT Carrier. Setting up the MKRIoTCarrier library requires an addition of few code lines in the **initialization** and **setup**. Practically speaking, the code used in the initialization and setup is rarely changed, and it is required in every sketch.

In the initialization (the very top) of every sketch, the **MKRIOtCarrier** library needs to be included, which includes the individual libraries of the components mounted onto the carrier.

Next, an object of type `MKRIOtCarrier` needs to be created. We'll call it `carrier` for simplicity.

```
1 #include <Arduino_MKRI
2 MKRIOtCarrier carrier;
```

Setup

Inside the `setup()` of every sketch that created, 2 lines of code needs to added.

First, we need to tell the library whether the carrier is being used inside the **plastic enclosure** included in the Oplà IoT Kit or not. The library uses this information in order to calibrate the sensitivity of the capacitive buttons.

If you use the plastic enclosure, add this line:

```
1 carrier.withCase();
```

Otherwise, add this line:


```
1 carrier.noCase();
```

After that, the

`carrier.begin();` command is needed. Final example is:

```
1 void setup() {  
2   carrier.noCase();  
3   carrier.begin();  
4 }
```

Humidity & Temperature Sensor



The HTS221 Humidity Sensor on the MKR IoT Carrier

The **HTS221 Humidity Sensor** is mounted on the top side of the carrier under the display, marked with a drop icon. The sensor uses capacitive sensing with a **humidity sensing range** of **0-100%** and **accuracy** of **± 3.5% rH (20 to +80% rH)**, and a **temperature sensing range** of **-40 to 120° C**, with an **accuracy** of **± 0.5 °C, 15 to +40 °C**. The sensor uses a low power consumption (2µA at 1 Hz

the mounted Arduino MKR board through a I2C interface.

Code


The values from the **temperature** and **humidity** sensors can be retrieved and stored in **float** variables as shown below.

```
1 float temperature = ca
2 float humidity = carri
```

Temperature is returned in degrees Celsius, while relative humidity is returned in percentage.

The underlying library used to read the sensor is [Arduino_HTS221](#).

Pressure Sensor



The LPS22HBTR Pressure Sensor on the MKR IoT Carrier

The **LPS22HBTR Pressure Sensor** is mounted on the top side of the carrier under the display, marked with a meter icon. The sensor measures **absolute pressure range** of **260**

Arduino MKR board through a I2C interface.


Code

The value from the **pressure** sensor, expressed in kiloPascal (kPa) can be retrieved and stored in a **float** variable as shown below.

```
1 float pressure = carrier
```

The underlying library used to read the sensor is [Arduino_LPS22HB](#).

IMU Accelerometer & Gyroscope Sensors



The IMU on the MKR
IoT Carrier

The carrier includes a **LSM6DS3** sensor from STM which is an IMU (Inertial Measurement Unit) featuring a 3D digital accelerometer and a 3D digital gyroscope.

The 3-axis values from the **accelerometer** and **gyroscope** sensors can be retrieved and stored in **float** variables as shown below:

```
1 float x, y, z;
2
3 void loop(){
4   if (carrier.IMUmodule
5     {
6       carrier.IMUmodule
7       Serial.println(x
8     }
9 }
```

The following methods can be used to detect movement:

```
1 carrier.IMUmodule.acce
```


Returns 0 if no new acceleration data sample is available, 1 if new acceleration data sample is available.

```
1 carrier.IMUmodule.read
```

Reads acceleration data from the sensor on the three axis and assigns it to the provided variables.

The underlying library used to read the sensor is [Arduino_LSM6DS3](#).

RGB and Gesture Sensor



The APDS-9960 sensor on the MKR IoT Carrier

The MKR IoT Carrier contains a Broadcom **APDS-9960 RGB and Gesture sensors**, situated under the display and marked with a bulb icon. The sensor is useful for **ambient light** and **RGB** color sensing, **proximity** sensing, and **gesture** detection.

Code

The color values from the **RGB** sensor can be retrieved and stored in **int** variables as shown below.

The

```
carrier.Light.readColor(r, g, b);
```

method can be used to detect colors.

The if statement

```
if (r >= 135 && g >= 135 && b >= 135)
```

in the code below checks if the color detected ranges from light gray to white, but the numbers assigned to red (r), green (g) and blue (b) can be customized to any desired color.

```
1 int r, g, b;
2
3 void loop(){
4
5     if (carrier.Light
6         carrier.Light.read
7
8         // check if color
9         if (r >= 135 &&
10            Serial.print('
11        }
12    }
13 }
```

The following methods can be used to detect gesture:

```
1 carrier.Light.gestureAv
```

Checks the availability of the **gesture** sensor.

```
1 carrier.Light.readGeste
```


Confirms which gesture is being detected, and **returns** UP, DOWN, RIGHT or LEFT.

The code example below shows the gesture value in a fixed width integer `uint8_t` variable, and the if statement checks `if (gesture == UP)`. To detect movements in other directions, UP can be replaced with DOWN, RIGHT or LEFT.

```
1 void loop(){
2
3   if (carrier.Light
4   {
5       uint8_t gesture
6       Serial.print("Ge
7
8       // when gesture
9       if (gesture == L
10      {
11          Serial.printl
12      }
13  }
```

The underlying library used to read the sensor is [Arduino_APDS9960](#).


Relays



The relays on the MKR IoT Carrier


The MKR IoT Carrier is equipped with two 5V Coil voltage **KEMET EE2-5NU-L relays**, located on the back side of the carrier. The relays are non-latching with a **COM** (common), **NO** (Normally open) and **NC** (normally closed) contacts, and can take up a max of **2A** Current and **24 V** of input each.

The connections between a high power circuit and the relays will be done through these connectors.



The relays connectors

Once the cables are introduced inside the connectors, they will automatically be locked inside. To unlock a cable and remove it from the connector, a tool is needed to be inserted through the top square hole (it can be a flat screwdriver, a hard piece of plastic, etc.).



The L1 and L2 LEDs indicators

The **L1 and L2 LEDs** on the carrier are visual indicators of the state of the relays. If the LED is ON, it means that the **COM** and the **NO** terminal of the relay are **connected**, and if the LED is OFF it means that **COM** and **NC** are **connected**.

Code

The `carrier.RelayX.open();` and `carrier.RelayX.close();` methods can be used to control the relays, and `carrier.RelayX.getStatus();` to read the status of the relays.

Swap to the Normally Open (NO) circuit of relay 1 (turns it on):

```
1 carrier.Relay1.open();
```

Swap to the Normally Closed (NC) circuit of relay 2 (turns it off), default mode on power off:


```
1 carrier.Relay2.close()
```

Bool, returns the status LOW means NC and HIGH means NO:

```
1 carrier.Relay2.getState()
```

Peripherals

Display



The MKR IoT Carrier's display

The screen on the MKR IoT Carrier is a **rounded 1.3" TFT display**, with a 240 x 240 resolution and a diameter of 36 x 40 mm.

Code

The display is controlled through the `carrier.display` object which is an instance of the **Adafruit_ST7789** class, based on the more general **Adafruit_GFX** interface. Most tutorials mentioning **Adafruit_GFX** should be usable on your MKR IoT Carrier.

To get started, check the [Adafruit_GFX documentation](#) and see the examples included in the `Arduino_MKTIOTCarrier` library.

]
(<https://www.arduino.cc/reference/en/libraries/adafruit-st7735-and-st7789-library/>), which is included in the carrier's library, meaning that it does not need to be added it separately.

We'll list here some of the most useful methods to configure the MKR IoT Carrier's display, including basic configurations, background and text colors, font size, position of the cursor and a loading animation.

```
1 carrier.display.fillSc
```

This method sets the color of the background of the display using hex codes. Example values are:

`0xFFFF` for white

`0x0000` for black

`0xF800` for red

`0x07E0` for green

`0xF81F` for magenta

`0xFFE0` for yellow

`0xFC00` for orange

```
1 carrier.display.setRotation(0)
```

This method sets the angle of the screen. 0 is the starting position with no rotation. The screen can only be rotated 90, 180 or 270 degrees by replacing the 0 with 1, 2 or 3.

```
1 carrier.display.drawBitmap(x, y, w, h, bitmap_visual)
```

This method displays a bitmap visual on the carrier's screen. The values x & y values are the top left coordinates where the visual is drawn, w & h are the width and height of the visual. The data for the bitmap_visual graphic can be stored as a byte array and used as the `bitmap_visual`.

```
1 carrier.display.setTextColor(0xFF0000)
```

This method sets the color of the text using hex codes.

```
1 carrier.display.setTextSize
```

This method sets the text size. 2 is an average text size since it is visible, but not too small, 3 is a bit larger.

```
1 carrier.display.setCursor
```

This method is very important, as it indicates where on the printing starts on the display. It is indicated by pixels, so, if **0, 0** are used for example, it will start printing in the top left corner.


```
1 display.print("text");
```

This method will print the text inside the string at the current cursor position.

More Resources

In order to develop a graphical user interface with the MKR IoT Carrier, the [Arduino_OplaUI](#) library can be used. This library uses the color LEDs, the buzzer and the touch buttons to build an interactive user interface featuring multiple pages. It also includes a few predefined gauges to display values. See the library

Buttons



The MKR IoT Carrier's buttons

The carrier has five **capacitive touch buttons** on its top side, numbered from 0 to 4. The buttons are sensitive to direct touch and can also detect wireless touch.

Code

```
1 carrier.Buttons.update
```

Reads the state of the pads and save them to be used in the different types of touch events.

```
1 carrier.Buttons.getTou
```

Get if the pad is getting touched, true until it gets released.

```
1 carrier.Buttons.onTou
```

Get when have been a touch down.

```
1 carrier.Buttons.onTouch
```

Get when the button has been released.

```
1 carrier.Buttons.onTouch
```

Get both, touched and released.

Replace `TOUCH0` with `TOUCH1`, `TOUCH2`, `TOUCH3`, `TOUCH4` in the examples above to access the other buttons. The code example below shows how the status of a button can be checked.

```
1 void loop(){
2     // updates buttons
3     carrier.Buttons.up
4
5     // Checks if butto
6     if (carrier.Button
7     {
8         Serial.print("Bu
9     }
10 }
```

LEDs



The LEDs on the MKR

The MKR IoT Carrier comes with 5 **digital RGB LEDs** placed on the top side of the carrier in front of the buttons.

Code

The LEDs are controlled with the Adafruit® DotStar library, which is included in the `MKRIoTCarrier` library.

The `carrier.leds.show();` method is necessary for updating the new state of the LEDs and needs to be called after any change of the state of the LEDs (turning on & off or change of color).

Here are some of the useful methods used to control the LEDs on the MKR IoT Carrier:

```
1 carrier.leds.setPixelColor
```

Sets the color of the index's LED.

```
1 carrier.leds.setBrightness
```

Set the overall brightness, from 0 (no brightness) to 255 (maximum brightness).

```
1 carrier.leds.clear();
```

```
1 carrier.leds.fill(color);
```

Fill X amount of the LEDs with the same color.


```
1 uint32_t myColor = color;
```

Saves a custom color.

The code example below shows how to light up all 5 LEDs with our customized color.

```
1 #include <Arduino_MKR1000.h>
2 MKRIoTCarrier carrier;
3
4 uint32_t myCustomColor = 0;
5
6 void setup() {
7     carrier.noCase();
8     carrier.begin();
9     carrier.leds.fill(myCustomColor);
10    carrier.leds.show();
11 }
```

Buzzer



The buzzer on the MKR IoT Carrier

The MKR IoT Carrier is equipped

bottom side of the carrier, under the MKR board.

Code

The buzzer can be controlled with the following methods:

```
1 carrier.Buzzer.sound(f
```

Equivalent to `tone()`, it will make the tone with the selected frequency.

```
1 carrier.Buzzer.noSound
```

Equivalent to `noTone()`, it will stop the tone signal.

```
1 carrier.Buzzer.beep();  
2 carrier.Buzzer.beep(800
```

This method is a handy shortcut generating a beep. The two arguments are optional and can be set to customize the frequency and the duration (in milliseconds);

Memory

The MKR IoT Carrier contains a **SD card slot** that accepts a Micro

Code


The memory can be used with the SD library commands that is already included in the `MKRIoTCarrier` library.

The SD class initialized in the main `carrier.begin()` so you don't need to do it yourself. The code below demonstrates how to save data on a file on a SD card.

```
1 #include <Arduino_MKR.  
2 MKRIoTCarrier carrier  
3  
4 File myFile;  
5  
6 void setup() {  
7     carrier.noCase();  
8     carrier.begin();  
9  
10     myFile = SD.open(""  
11 }
```

In order to learn more, check any of the many tutorials about using the `SD` library on Arduino.

Power



JST battery connector
on the MKR IoT
Carrier.

The MKR IoT Carrier can be either powered through a USB

The battery used should be a LI-ION 18650 3.7v battery, which can be mounted to the carrier via the battery holder on the bottom side.

In order to use the USB power to charge the battery, a little cable with JST connectors on both ends is needed between the MKR IoT Carrier and the MKR board. The bBattery can then be recharged via a USB connection through the MKR Board (runs up to 48h with a 3.7v 2500mAh).

0:00 0:25

Suggest changes	Need support?	License
The content on docs.arduino.cc is facilitated through a public GitHub repository . If you see anything wrong, you can edit this page here .	Help Center Ask the Arduino Forum Discover Arduino Discord	The Arduino documentation is licensed under the Creative Commons Attribution-Share Alike 4.0 license.

Was this article helpful?

