

NovaCart Electronics

Official User Manual

Document Name: UserManual.pdf

Version: 1.0

Published by: NovaCart Electronics

Website: www.novacartelectronics.com

About This Document

This User Manual provides guidance on the daily operation, maintenance, software updates, troubleshooting, and safe usage of NovaCart Electronics products.

This manual should be used after the product has been successfully installed.

For installation procedures, please refer to [InstallationGuide.pdf](#).

For warranty coverage, please refer to [Warranty.pdf](#).

Product Maintenance

To maximize the lifespan of your NovaCart products:

- Keep devices clean and dry.
- Avoid exposing products to extreme temperatures.
- Use only official NovaCart chargers and accessories.
- Install software updates regularly.
- Store devices in a dry, well-ventilated environment.
- Avoid dropping or applying excessive force to electronic devices.

Improper handling may reduce product lifespan and may void warranty coverage.

Battery Care

Applicable Products:

- NC-LAP-001 — NovaBook Air 14
- NC-LAP-002 — NovaBook Pro 15

- NC-PHN-001 — NovaPhone X
- NC-PHN-002 — NovaPhone Lite
- NC-TAB-001 — NovaTab 11
- NC-WAT-001 — NovaWatch S
- NC-AUD-001 — NovaBuds Pro
- NC-AUD-002 — NovaSound Mini
- NC-GAM-001 — NovaGame Controller

Recommended practices:

- Keep battery levels between 20% and 80% whenever possible.
- Avoid leaving devices connected to power continuously after reaching full charge.
- Use the supplied charger or an officially supported replacement.
- Avoid charging in extremely hot or cold environments.
- If storing a device for an extended period, maintain approximately 50% battery charge.

Software Updates

NovaCart Electronics regularly releases firmware and software updates that may include:

- Security improvements
- Performance enhancements
- Bug fixes
- Stability improvements
- New features

Customers are encouraged to install updates as soon as they become available.

Cleaning Instructions

Before cleaning:

- Turn off the device.

- Disconnect power cables.
- Remove connected accessories.

Cleaning recommendations:

- Use a soft microfiber cloth.
- Do not use abrasive materials.
- Avoid spraying liquids directly onto devices.
- Do not immerse products in water unless specifically designed for water resistance.

Troubleshooting Guide

Laptops

Applicable Products:

- NC-LAP-001 — NovaBook Air 14
- NC-LAP-002 — NovaBook Pro 15

Laptop does not power on:

Possible Solutions:

- Verify the battery is charged.
- Connect the official charger.
- Hold the power button for 10 seconds.
- Ensure the charging indicator is illuminated.

Laptop is running slowly

Possible Solutions:

- Restart the device.
- Install pending software updates.
- Close unnecessary applications.
- Ensure sufficient storage space is available.

Wi-Fi is not connecting

Possible Solutions:

- Restart the router.
- Toggle Wi-Fi off and on.
- Forget and reconnect to the wireless network.
- Install the latest network driver updates.

Smartphones

Applicable Products:

- NC-PHN-001 — NovaPhone X
- NC-PHN-002 — NovaPhone Lite

Device is not charging:

Possible Solutions:

- Inspect the charging cable.
- Use the supplied charger.
- Clean the charging port carefully.
- Restart the phone.

Fingerprint sensor is not responding

Possible Solutions:

- Clean the fingerprint sensor.
- Remove moisture from your finger.
- Re-register fingerprints.

Bluetooth cannot find devices

Possible Solutions:

- Restart Bluetooth.
- Ensure nearby devices are in pairing mode.

- Move closer to the device.
- Restart the smartphone.

Tablets

Applicable Product:

- NC-TAB-001 — NovaTab 11

Stylus is not working:

Possible Solutions:

- Recharge the stylus.
- Restart the tablet.
- Update the firmware.
- Reconnect the stylus.

Smartwatch

Applicable Product:

- NC-WAT-001 — NovaWatch S

Watch will not pair:

Possible Solutions:

- Enable Bluetooth.
- Restart both devices.
- Reset Bluetooth pairing.
- Update the Companion App.

Heart rate readings appear inaccurate

Possible Solutions:

- Wear the watch snugly.
- Clean the sensor.
- Ensure proper skin contact.

NovaBuds Pro

Applicable Product:

- NC-AUD-001 — NovaBuds Pro

Earbuds are not pairing:

Possible Solutions:

- Place both earbuds back into the charging case.
- Hold the pairing button for five seconds.
- Delete previous Bluetooth pairing information.
- Pair again.

One earbud has no sound

Possible Solutions:

- Recharge both earbuds.
- Clean the speaker mesh.
- Reset the earbuds.

NovaSound Mini

Applicable Product:

- NC-AUD-002 — NovaSound Mini

No audio output

Possible Solutions:

- Increase volume.
- Verify Bluetooth connection.
- Restart the speaker.
- Recharge the battery.

NovaVision 55 Smart TV:

Applicable Product:

- NC-TV-001 — NovaVision 55

TV does not connect to Wi-Fi:

Possible Solutions:

- Restart the television.
- Restart the router.
- Re-enter Wi-Fi credentials.
- Install the latest software update.

Remote control is not responding:

Possible Solutions:

- Replace batteries.
- Remove obstacles.
- Re-pair the remote if necessary.

Smart Home Devices

NovaCam Home:

Common Issues:

- Camera offline
- Motion detection unavailable
- Video delay

Possible Solutions:

- Verify Wi-Fi connection.
- Restart the camera.
- Check internet connectivity.
- Update firmware.

NovaBulb Smart:

Common Issues:

- Bulb not detected
- Cannot connect to Wi-Fi

Possible Solutions:

- Reset the bulb.
- Ensure 2.4 GHz Wi-Fi is available.
- Restart the Companion App.

Factory Reset

Factory resetting restores products to their original settings.

Factory reset is recommended only when troubleshooting steps have failed.

Customers should back up important data before performing a factory reset.

Factory reset procedures vary by product.

Storage Recommendations

If products will not be used for an extended period:

- Store in a cool, dry location.
- Avoid direct sunlight.
- Recharge batteries every three months.
- Disconnect external accessories.

Safety Information

To ensure safe operation:

- Do not disassemble products.
- Keep products away from water unless water resistance is specified.
- Do not block ventilation openings.
- Use only approved accessories.
- Keep devices away from children where appropriate.

Data Protection

Before sending any product for warranty service, repair, or replacement:

- Back up important data.
- Remove personal accounts.
- Disable device locks where possible.

NovaCart Electronics is not responsible for data loss during servicing.

Contact Technical Support

Customers requiring technical assistance may contact NovaCart Electronics through:

- AI-powered Chat Support
- Email Support
- Phone Support

Support requests are handled during normal business hours.