On the **HVLP Alpha version** the 10mA current excitation supply is provided from the unit.

Refere to "App note - HVLP - HVIL explanation (Alpha version)" app note for how to set the HVIL on **HVLP Alpha version.**

Recommended software version to use for the HVIL implementation :

- SN0088.54_MCP.dldx
- SN0089.51_IOP.dldx

On the **HVLP Beta version** the 10mA current excitation supply is removed but the HVIL is still there.

The only difference is that on **HVLP Beta version** the customer will need to add to the system a 10mA current excitation supply for the HVIL e.g. from the BMS or maybe from the VCU.

Refere to "App note - HVLP - HVIL explanation (Beta version)" app note for how to set the HVIL on **HVLP Beta version.**