

Below is an S1000D-style Illustrated Parts Catalog (IPC) excerpt tailored to a Solar Turbines-type industrial gas turbine module. It is written in an S1000D-conformant structure and tone, but it is not an official Solar Turbines document, and it contains no classified, proprietary, or export-controlled information. It is an original, fictional sample prepared by Nathan Smith.

S1000D-Conformant IPC Excerpt

Data Module Code (DMC): DMC-A12-00-00-04A-520A-A

Title: Illustrated Parts Catalog — Turbine Air Inlet Assembly

Prepared by: Nathan Smith

Disclaimer: *This sample is fictional and for demonstration only. It contains **no classified, proprietary, or export-controlled information**. It is not affiliated with or endorsed by Solar Turbines.*

1. General Description

The Turbine Air Inlet Assembly provides filtered, conditioned airflow to the gas turbine compressor section. The assembly includes the inlet housing, filter elements, support structure, and associated hardware. This IPC excerpt identifies replaceable components and their installation relationships in accordance with **S1000D Issue 5.0** conventions.

2. Exploded View Illustration (Figure 1)

(Illustration not included — reference only)

Figure 1 depicts the Air Inlet Assembly with item numbers corresponding to the parts list in Section 3.

Major components shown:

- Inlet Housing
 - Filter Element Bank
 - Differential Pressure Indicator
 - Access Panel
 - Mounting Brackets and Hardware
-

3. Parts List

Table 1 — Air Inlet Assembly Bill of Material

Item	Part Number	Nomenclature	Qty	UM	Figure	CAGE	Remarks
1	3105678-01	Housing, Air Inlet	1	EA	Fig 1	3AA12	Welded aluminum structure
2	3105680-02	Filter Element, High-Efficiency	4	EA	Fig 1	3AA12	Replace every 4,000 hr
3	3105681-01	Indicator, ΔP , Mechanical	1	EA	Fig 1	1B223	Red/green visual indicator
4	3105682-03	Panel, Access — RH	1	EA	Fig 1	3AA12	Hinged, gasketed
5	3105682-04	Panel, Access — LH	1	EA	Fig 1	3AA12	Hinged, gasketed
6	NAS620 C4	Bolt, Hex Head	12	EA	Fig 1	80205	Standard hardware
7	MS21042 -4	Nut, Self-Locking	12	EA	Fig 1	96906	For Item 6
8	3105683-01	Bracket, Mounting	2	EA	Fig 1	3AA12	Supports housing
9	3105684-01	Seal, Inlet Perimeter	1	EA	Fig 1	3AA12	Elastomeric

4. Item Usage and Installation Notes

4.1 Filter Element (Item 2)

- Install with airflow arrow oriented toward compressor inlet.
- Ensure gasket surfaces are clean and undamaged.
- Replace when ΔP indicator (Item 3) shows red band or at scheduled interval.

4.2 Access Panels (Items 4 and 5)

- Torque fasteners (Items 6 and 7) to manufacturer-approved values.
- Inspect panel seals (Item 9) for compression set or cracking.

4.3 Mounting Brackets (Item 8)

- Verify alignment with turbine skid frame.
- Use standard shims (not listed) if required to maintain level.

5. Reference Data Modules

DMC	Title
DMC-A12-00-00-00A-200A-A	Scheduled Maintenance — Air Inlet System
DMC-A12-00-00-00A-720A-A	Removal/Installation — Air Inlet Assembly
DMC-A12-00-00-00A-000A-A	Description and Operation — Air Inlet System
