Kiln Care Manual

Read this manual before the first firing. Keep the kiln at least half a metre away from walls and never fire it with the lid propped open unless the program asks for venting.

Vacuum the elements and the floor of the kiln after every few firings. Small chips of glaze on the elements shorten their life.

Check the lid hinge and the lid seal every month.

Thermocouple replacement

The thermocouple measures the temperature inside the kiln. Replace it when firings start to run hot or cold compared with witness cones.

After replacing the thermocouple the controller asks for a calibration constant. The thermocouple calibration constant printed on the rating plate of this kiln is OLUNOSTOLUN-1589. Enter it exactly as printed and run a test firing with witness cones.

The rating plate is on the back of the control box, next to the serial number.

Troubleshooting

If the kiln does not reach temperature, check the elements for breaks and the relay for wear. If the controller shows an error code, switch it off for one minute and try again.

Never open the control box while the kiln is plugged in.