

Yealink CP925 Setup Guide

CP925

Conference speakerphone · 7-mic array · 20ft pickup · Wi-Fi + Bluetooth

Kit: Conference Room Kit

1 Unbox and check contents



Open the box and confirm you have:

- ✓ CP925 conference phone body
- ✓ 48V power adapter (required — no PoE)
- ✓ Ethernet cable
- ✓ Quick start card

The CP925 has a **7-microphone array** with **360-degree pickup** up to 20 feet .

CP925 does NOT support PoE. Use only the included 48V adapter.

2 Place on table and connect cables



Place CP925 in the **center of the conference table** .

Connect the **48V power adapter** to the back and into the wall.

Connect **Ethernet** to the LAN port and run to the wall port.

Touchscreen shows **Connected** when ready.

✓ **Tip:**
Nothing blocking the top — mic ports face up. Away from HVAC vents.

3 Configure SIP via web interface



Tap **More** → **Status** → **Network** for the IP address.
Type it in a browser. Login: **admin / admin** .

Go to **Account** → **Account 1** → **Basic** . Enter:

- Label — give the room a clear, recognisable name
- Register Name, Password, SIP Server

Click **Confirm** . Status → **Registered** .

✓ **Tip:**
Use a name anyone in the office would recognise at a glance, like the room number or location.

4 Confirm registration and test call



The CP925 screen shows **Phone Registered** when complete.

Dial a test number and confirm from different seats:

- ✓ Remote caller hears everyone clearly
- ✓ No echo or feedback
- ✓ All seats within pickup range

If a seat sounds faint, add a CPW25 expansion mic.

✓ **Tip:**
Enable Noise Proof: Settings → Audio. Reduces HVAC and keyboard noise.

Quick Troubleshooting

Problem	Fix
CP925 won't power on	Confirm using the included 48V adapter. PoE will not work.
Remote callers say room sounds faint	Clear top surface of CP925. Enable Noise Proof in Settings → Audio.
Echo reported by remote caller	Reduce CP925 speaker volume. Nothing placed on top of the device.
CPW25 expansion mic not pairing	Power cycle CPW25. On CP925 remove old Bluetooth pairing, then re-pair.
Calls connect, no audio	RTP ports 10000-12000 must be open UDP both ways on your firewall.