Proprietary to General Electric Company
Direction 5438996-8EN, **Rev#** 9
Brivo CT385 Series Service Methods (Adv)
Module Version 5.0, **Version Date** 5/7/10

Reset TnT

(Click Here for Summary Version)

1 Personnel Requirements

Required Persons	Preliminary Reqs	Procedure	Finalization
1	N/A	15 mins	N/A

2 Overview

This document defines the procedures to reset the Generator Tracking and Trending data and filament aging calibration to factory values.

Last Revised:	February 9, 2010

3 Preliminary Requirements

3.1 Required Conditions

Condition	Reference	Effectivity
Recommend procedure completion by GE Service trained personnel.	-	-
Confirm [120 VAC], [AXIAL DRIVE ENABLE], and [HVDC ENABLE] switches on Service Switch Panel are turned on.	-	-
Confirm Gantry Controls Table Collision Sensor Indicator has been reset.	-	-
Confirm Scan Hardware has been successfully reset.	-	-
Confirm no flashing indicators on Gantry Controls or Display.	-	-

4 Procedure

1. Select [DIAGNOSTICS] from Service Desktop.
2. Select [GENERATOR TOOL - JEDI], or [X-RAY GENERATION], [GENERATOR TOOL - JEDI].
3. Click [RESET TNT DATA]
4. Select data areas to be re-initialized.
    a. For Tube Replacement, select (highlight) [TUBE TNT DATA].
    b. For all other procedures, select (highlight) [TUBE TNT DATA] and [GENERATOR TNT DATA].
5. Click [RESET].
6. Click [OK] in *Attention* window.
7. Click [CANCEL] in *Reset TnT Data* window.

NOTE: If process fails, take appropriate corrective action and repeat procedure. If the process fails persistently, perform *Initialize Generator Database*.

8. Click [DISMISS] in *Generator Tool - JEDI* window.

5 Finalization

1. *Filament Calibration*
2. Save System State.

Back to top