Proprietary to General Electric Company
Direction 5438996-8EN, **Rev#** 9
Brivo CT385 Series Service Methods (Adv)
Module Version 4.0, **Version Date** 5/7/10

Filament Calibration

(Click Here for Summary Version)

1 Personnel Requirements

Required Persons	Preliminary Reqs	Procedure	Finalization
1	Not Applicable	15 mins	Not Applicable

2 Overview

The Filament Calibration tool runs an automated scan sequence and populates the JEDI database accordingly.

Last revised:	November 9, 2009

3 Preliminary Requirements

3.1 Safety



⚠ CAUTION
Remove any objects from scan window area which may interfere with the rotating gantry.



⚠ CAUTION
No personnel or patients should be in the area of the gantry while scanning without adequate radiation safety precautions being utilized.

3.2 Required Conditions

Condition	Reference	Effectivity
Recommend procedure completion by GE Service trained personnel.	-	-

4 Procedure

1. Move table to longitudinal home position.
2. Select [DIAGNOSTICS] from Service Desktop.
3. Select [GENERATOR TOOL - JEDI], or [X-RAY GENERATION], [GENERATOR TOOL - JEDI].
4. Click [FILAMENT CAL].
5. Click [SCAN].
6. Press [START] on SCIM when it flashes.

   NOTE: If Filament Calibration fails, rerun. If Filament Calibration fails persistently, perform *Initialize Generator Database* and repeat this procedure.

7. Click [CANCEL] in *Generator Filament Calibration* window.
8. Click [DISMISS] in *Generator Tool - JEDI* window.

5 Finalization

No finalization steps.

Back to top