Proprietary to General Electric Company
**Direction** 5438996-8EN, **Rev#** 9
Brivo CT385 Series Service Methods (Adv)
**Module Version** 2.0, **Version Date** 7/15/13

# Gantry Rotation Safety Check

(Click Here for Summary Version)

## 1 Personnel Requirements

| Required Persons | Preliminary Reqs | Procedure | Finalization |
|---|---|---|---|
| 1 | Not Applicable | 10 min | Not Applicable |

## 2 Overview

Use DDC to Rotate the Gantry for 10 minutes, at the fastest allowed gantry speed.

## 3 Preliminary Requirements

### 3.1 Safety



**⚠WARNING**
**CRUSH HAZARD**
**EQUIPMENT COULD EJECT FROM GANTRY.**
**ENSURE THAT NO PERSONNEL ARE IN THE SAME ROOM/AREA AS THE GANTRY PRIOR TO AND DURING THE SCANS.**

## 4 Procedure

1. Make sure the “Axial Drive” and “HVDC” swiches on the service switch panel are off.
2. Manually rotate the gantry through a full rotation listening for an contact between stationary and rotating parts
   - Listen for an contact between stationary and rotating parts. Correct any issues found before continuing.
   - Watch and listen for any loose parts/cables and tighten them before continuing.
3. Turn on the “HVDC” and “Axial Drive” switches.
4. Start the axial functional diagnostic.
   a. Open the Common Service Desktop
   b. Select the [Diagnostics] Icon
   c. Select the [Axial Control] Folder and then [Axial Functional] menu item to start the diagnostic.



NOTICE
**Do NOT be present in the scan room while the gantry is rotating. Listen from the scan room door.**

5. Select a rotation speed of 2 seconds and run the test. This step should be run for a minimum of 30 seconds.

   Listen for an contact between stationary and rotating parts. Correct any issues found before continuing.

   **NOTE:** Be ready to click on [Stop] button on the menu immediately if you hear any problems. (This stops the gantry faster than the red emergency stop (E-stop) button)

6. Repeat Step 5 for rotation speeds of 1.0 second.
7. Wait 3 minutes after the gantry stops rotating before continuing to allow for axial drive cooling.

**NOTE:** Be ready to click on the Stop button on the menu immediately if you hear any problems. (This stops the gantry

faster than the E-off button)

8. If no issues arise, gantry rotation capability is safe for use.

## 5 Finalization

No finalization steps.

Back to top