

P591 Pico Update Instructions

Requirements:-

- Pico RMU
- RS422 connection to PC
- PC_loader.exe bootloader software
- P591_XvXXrXX[crc].hex update file

Sequence

- 1) Install the bootloader application software PC_loader.exe on a windows PC
- 2) Connect the Pico RMU to the PC via the RS422 cable
- 3) Launch the PC_loader.exe software. Select the RS422 Com Port from the pull-down list (use Device Manager to identify the correct port number if not known)
- 4) Select 'Connect' and quickly apply power to the Pico RMU (within 5 seconds). The PC bootloader application should connect to the Pico device.
- 5) Once connected, click 'Load Hex File' and select the update P591_XvXXrXX[crc].Hex file provided
- 6) Click 'Erase-Program-Verify'
- 7) Click 'Run Application' and check the red led ramps up and down