

Shenzhen Dudumiao Technology Co., Ltd.

smokefire Fire, Smoke & Smoking Detection

User Operation Manual

Document version: V1.0

Applicable software version: 1.0.0

Updated: 2026-08-03

Contents

Document information

3

1. System overview

3

2. First use

3

2.1 Open the system

3

2.2 Recommended first-use sequence

3

3. Live Wall

4

3.1 Camera states

4

3.2 Patrol focus

4

4. Camera Management

5

4.1 Identify the camera source first

5

4.2 Add a manual camera

5

4.3 Main fields

5

4.4 Edit, disable, and delete

6

4.5 Camera placement

6

4.6 Capacity notices

6

5. Event Center

6

5.1 Review and filter

6

5.2 Open details and playback

7

5.3 Handling actions

7

5.4 Heartbeat/recovery notices

7

6. Alert response

7

7. False-positive feedback

7

7.1 Mark a false positive

7

7.2 Download feedback

8

7.3 Clear feedback

8

8. Storage Management

8

8.1 Delete by time range	8
8.2 High-water status	8
9. Alert notifications	8
9.1 Configure a webhook	8
9.2 Notification points	8
9.3 Heartbeat fields	9
10. Daily operating routine	9
Start of shift	9
During alert handling	9
End-of-shift handover	9
11. Frequently asked questions	9
The preview is black but the camera is Online	9
The camera remains Reconnecting	10
Existing go2rtc has many feeds, but none appear automatically	10
The camera remains in Recording warm-up	10
There are too many alerts	10
There are no alerts	10
The event has no video	10
The webhook received nothing	10
Does deleting a camera delete historical events?	10
Do parameter changes require a restart?	10
12. Quick reference	10

Important

smokefire assists operators in finding visible fire, smoke, and smoking behavior in video. Every alert requires prompt human verification and response. The system does not replace statutory fire protection, human patrols, emergency procedures, or on-site verification. False alerts and missed events are possible.

Document information

Item	Value
Document	smokefire User Operation Manual
Audience	Duty operators, site administrators, and event reviewers
Default URL	http://127.0.0.1:8600
Main pages	Live Wall, Event Center, Camera Management
Project	https://github.com/newtv-ai/smokefire

1. System overview

The top navigation provides three principal pages:

Page	Purpose	Typical user
Live Wall	View live images, runtime status, and recent alerts	Duty operator
Event Center	Filter, review, play, and process alerts	Operator and reviewer
Camera Management	Add, edit, disable, and tune cameras and webhooks	Administrator

By default, the system samples one frame per second and requires four consecutive threshold-passing frames before creating an alert. It stores one second of evidence before and after the event. These are starting values only; validate them for each camera view and business requirement.

2. First use

2.1 Open the system

On the service host, open:

```
http://127.0.0.1:8600
```

Use the site URL supplied by the implementer when remote access has been configured. The application has no built-in login screen; access scope is controlled by the deployment environment.

2.2 Recommended first-use sequence

- 1 Open Camera Management. For an existing-go2rtc site, first confirm that main streams with the Upstream badge were imported automatically; add a camera manually only in the other modes.
- 2 Wait for Starting or Reconnecting to change to Online.
- 3 Open Live Wall and confirm the image, name, and camera view.
- 4 Trigger a controlled alert using authorized test material.
- 5 Open Event Center and verify the snapshot, clip, time, and camera name.
- 6 Test both Confirmed and Mark False Positive.
- 7 If integrating a third-party platform, configure the webhook and perform an end-to-end delivery test.

3. Live Wall

The wall automatically lays out cameras for the browser window. Use Previous and Next when there are more cameras than one page can display.

3.1 Camera states

State	Meaning	Recommended action
Online	AI detection and video processing are running	Continue normal patrol
Starting	The source and processing pipeline are initializing	Wait briefly
Reconnecting	The stream was interrupted and retry is in progress	Check network/RTSP if persistent
Recording warm-up	Video is available but the first closed recording segment is not ready	Wait for the first segment
Disabled	The camera is intentionally stopped	Enable it in Camera Management when needed
Error	The source or processing pipeline has failed	Record the message and contact an administrator

3.2 Patrol focus

- Confirm the image updates continuously rather than showing a frozen frame.
- Check that the camera name and physical location match.
- Investigate persistent Reconnecting or Recording warm-up states.
- Review the newest alert card promptly and open Event Center for evidence.
- Do not treat an Online badge as proof that detection quality is acceptable; image quality and target size still matter.

4. Camera Management

4.1 Identify the camera source first

Camera Management can contain two types of records:

- **Upstream cameras:** the implementer connected smokefire to the customer's existing go2rtc. All main streams are read automatically and show an Upstream badge. Users do not copy RTSP URLs one by one.
- **Manual cameras:** users add these in direct RTSP or bundled-go2rtc mode.

The synchronizer owns upstream camera names and source URLs. A new go2rtc main stream appears after the next sync; a missing stream is disabled and enabled again when it returns. Matching `_sub`, `-sub`, and `_sd` substreams are deduplicated when a main stream exists. Do not create a manual camera with the same name. If names or counts are wrong, ask the implementer to check go2rtc instead of re-entering every feed.

4.2 Add a manual camera

- 1 Select Add Camera.
- 2 Enter a unique, recognizable name.
- 3 Enter the full RTSP URL supplied by the camera or NVR administrator.
- 4 Enable Fire/Smoke and/or Smoking detection as required.
- 5 Confirm the sampling rate and evidence recording window.
- 6 Save and wait for Online.
- 7 Verify the image in Live Wall.

Example RTSP URL:

```
rtsp://user:password@192.168.1.20:554/stream1
```

4.3 Main fields

Field	Purpose	Guidance
Name	Identifies the camera in pages and alerts	Include building/floor/area where useful
RTSP URL	Video source	Copy exactly; credentials are case-sensitive
Enabled	Starts or stops processing	Disable cameras under maintenance
Fire/Smoke	Enables the fire/smoke model	Use for relevant camera views
Smoking	Enables the smoking model	Use where people are large enough in frame
Detection FPS	Sampling frequency	Higher values increase compute and may change alert behavior
Pre/Post seconds	Evidence around an alert	Increasing them consumes more storage

Field	Purpose	Guidance
Webhook	Per-camera notification target	Test real delivery after saving

4.4 Edit, disable, and delete

- Edit changes the source or detection settings.
- Disable preserves configuration and history but stops processing.
- Delete removes the camera configuration; historical events remain in Event Center until separately deleted.
- Record a change ticket before editing production camera URLs, thresholds, or sampling policy.

An upstream source URL is read-only, and its enabled state follows go2rtc synchronization. To rename or permanently remove it, change the customer go2rtc configuration and wait for the next sync; do not repeatedly override it in smokefire.

4.5 Camera placement

Keep the target area unobstructed and avoid severe backlight, glare, and rapid camera shake. The relevant target must occupy enough pixels: a high-resolution stream does not help if a person, cigarette, flame, or smoke plume is still very small in the scene.

4.6 Capacity notices

When the interface reports insufficient capacity, do not simply add more cameras. Reduce stream resolution/bitrate or detection rate only after a representative replay test, or move the workload to a more capable host.

5. Event Center

5.1 Review and filter

Filter by time, camera, capability, label, or handling status. Each event normally shows:

- camera and event time;
- fire, smoke, or smoking label;
- confidence from the triggering evidence;
- clean and annotated snapshots;
- evidence clip when available;
- notification and handling state.

5.2 Open details and playback

Open an event to compare the clean image with the annotated image and play the clip. Do not decide from the box alone. Check whether the visible object, motion, and surrounding context match a real event.

5.3 Handling actions

Action	Use when	Result
Pending	Evidence has not yet been reviewed	Keeps the event in the pending queue
Confirmed	A person verifies a real fire, smoke, or smoking event	Records the handling decision
Mark False Positive	The model detected a non-target scene	Archives feedback for later review

Only authorized reviewers should make final decisions. If evidence is unclear, follow the site's escalation procedure rather than guessing.

5.4 Heartbeat/recovery notices

The notification channel can send a heartbeat or recovery summary after interruptions. A heartbeat is not a new detection event. Use its counters and timestamps to understand whether notifications were delayed or recovered.

6. Alert response

Use the site's emergency procedure first. A recommended operational sequence is:

- 1 Open the event and verify the live view and evidence clip.
- 2 Identify the camera, location, time, and target class.
- 3 For suspected fire or smoke, immediately follow the approved fire response and escalation process.
- 4 For smoking, follow the site's safety and conduct procedure.
- 5 Do not delay a real emergency while adjusting software or replaying clips.
- 6 After the situation is controlled, mark the event and record the response outcome.

The software must never be the only path for reporting a dangerous condition.

7. False-positive feedback

7.1 Mark a false positive

Open the event, select Mark False Positive, choose or enter a reason, and confirm. Useful reasons describe what the model confused, for example steam, fog, reflection, welding, eating, or a handheld object.

7.2 Download feedback

Authorized administrators can export a feedback package for model analysis. Review the package before transferring it because images, clips, camera names, URLs, or site details may be sensitive.

7.3 Clear feedback

Clearing feedback is irreversible from the application. Export and verify the required package first, and follow the site's retention and approval process.

8. Storage Management

Storage Management displays evidence usage and allows deletion by time range.

8.1 Delete by time range

- 1 Confirm the required evidence has been backed up.
- 2 Select the exact time range.
- 3 Review the expected number of affected events.
- 4 Confirm deletion.
- 5 Recheck disk usage and a sample of retained events.

Deleting events removes associated evidence and should follow the site's authorization and retention policy.

8.2 High-water status

When disk use reaches the high-water threshold, recording or event commits may be restricted to protect service stability. Back up first, then delete approved old evidence or expand the data disk. Do not manually remove random files from the Docker volume.

9. Alert notifications

9.1 Configure a webhook

An administrator can set a global webhook during deployment or a per-camera webhook in Camera Management. Save the configuration and perform a controlled real delivery test.

9.2 Notification points

- The receiver should return a success response promptly.
- Receiver-side deduplication should use the event ID.
- Temporary failures may be retried; monitor pending, failed, and dead-letter counters.

- A successful HTTP response proves delivery, not human response.

9.3 Heartbeat fields

Heartbeat payloads summarize runtime and notification health. Treat `heartbeat` or recovery-type messages separately from detection events, and alert an administrator if queue or failure counts continue to rise.

10. Daily operating routine

Start of shift

- Open Live Wall and confirm all expected cameras are present.
- Check for persistent Reconnecting, warm-up, or Error states.
- Open Event Center and review pending events from the previous shift.
- Confirm recent clips can be played and disk status is normal.
- Verify the notification receiver when the site procedure requires it.

During alert handling

- Verify location and live conditions first.
- Follow emergency and escalation procedures.
- Record Confirmed or False Positive only after review.
- Add a useful false-positive reason when applicable.

End-of-shift handover

- Handover unprocessed events and camera faults.
- Record unusual false alerts, misses, stream interruptions, and notification issues.
- Do not change thresholds or sampling settings without an approved change record and replay validation.

11. Frequently asked questions

The preview is black but the camera is Online

Refresh once, then check whether the browser supports the stream and whether the first recording segment has closed. Report the camera name, time, and visible status to an administrator.

The camera remains Reconnecting

Confirm the camera/NVR is powered and reachable. An administrator should test the same RTSP URL on the service host and check credentials, port 554, and codec.

Existing go2rtc has many feeds, but none appear automatically

Confirm that existing-go2rtc mode is enabled and that the smokefire container can reach go2rtc API port 1984 and RTSP port 8554. On the same host, the container normally uses `host.docker.internal`, not `127.0.0.1`. Automatic sync imports main streams and deduplicates matching substreams; users should not enter every feed manually.

The camera remains in Recording warm-up

Wait for the first closed segment. If the state persists, check stream stability and FFmpeg logs.

There are too many alerts

Record representative false positives. Review camera angle, steam/fog/reflections, target size, and policy using both positive and negative samples. Do not broadly increase thresholds without measuring misses.

There are no alerts

Confirm the capability is enabled and the target is visible and large enough. Use authorized positive material. A live preview alone does not prove the model can recognize that view.

The event has no video

Check whether the source was stable, recording had finished warming up, and the data disk was writable. Preserve the event ID and time for troubleshooting.

The webhook received nothing

Check the saved URL, receiver logs, notification counters, network reachability, and receiver response time. Test with a controlled event.

Does deleting a camera delete historical events?

No. Historical events remain until separately removed through Storage Management.

Do parameter changes require a restart?

Per-camera settings saved in Camera Management normally apply live. Global `.env` changes require a service restart.

12. Quick reference

Task	Page	Action
Check all camera states	Live Wall	Review badges and image freshness
Add or edit a camera	Camera Management	Enter RTSP/settings, save, verify Online
Review an alert	Event Center	Compare snapshots, play clip, check live view
Confirm a real event	Event Center	Select Confirmed after site verification
Record a false alert	Event Center	Mark False Positive and enter a reason
Export feedback	Event Center / Feedback	Download and review the package
Clean old evidence	Storage Management	Back up, select time range, confirm deletion
Diagnose a camera	Live Wall + administrator logs	Record camera, time, state, and symptoms

Prepared by: Shenzhen Dudumiao Technology Co., Ltd. Project:
<https://github.com/newtv-ai/smokefire>