

ABC Electronics — Warranty, After-Sales Service & Troubleshooting

Overview

This document is the internal knowledge base for ABC Electronics warranty terms, service workflows, customer support channels, error codes, and troubleshooting guidelines. It is intended for use by customer service agents, field technicians, and the AI support assistant.

Warranty Coverage by Product Category

Washing Machines — Front-Load

Warranty element	Coverage
Product warranty	2 years from date of purchase
Motor warranty	10 years (BLDC motor)
Year 1	Parts, labour, and in-home service included
Year 2	Parts covered; labour chargeable
Years 3–10 (motor only)	Motor parts covered; gas, labour chargeable
Registration requirement	Within 30 days of purchase for full warranty activation
Transferability	Non-transferable; applies to original purchaser only

Key exclusions: Plastic panels, rubber parts, glass door, filters, lint catchers, and damage from improper power supply or water pressure.

Washing Machines — Top-Load

Warranty element	Coverage
Product warranty	2 years from date of purchase
Motor warranty	5 years (EcoInverter BLDC)
Year 1	Parts + labour included
Year 2	Parts covered; labour chargeable
Registration	Within 30 days
Transferability	Non-transferable

Air Conditioners

Warranty element	Coverage
------------------	----------

Product warranty	1 year comprehensive (parts + labour)
Extended warranty option	Additional 4 years on product available under ABC Extended Care scheme
Compressor warranty	5 years from date of purchase
PCB warranty	5 years (included in product warranty period; thereafter chargeable)
Year 1	Parts, labour, gas, and in-home service included
Years 2–5 (extended)	Parts covered under scheme; labour and gas chargeable
Registration	Within 15 days of installation for warranty activation
Installation	Professional installation mandatory; self-installation voids warranty

Key exclusions: Remote control, filters, drain pipe, cosmetic damage, rust due to corrosive environment, damage from voltage fluctuation without a stabilizer.

Refrigerators

Warranty element	Coverage
Product warranty	4 years machine warranty (eligible models)
Compressor warranty	10 years (additional 6 years after initial 4-year machine warranty)
Year 1	Parts, gas (where applicable), and labour included at no extra cost
Years 2–4	Parts covered; gas charging and labour become chargeable
Years 5–10 (compressor only)	Compressor parts covered; labour and gas chargeable
Spare-part support	Available for 10 years after purchase
Registration	Within 15 days of purchase via ABC Connect app, missed call, or customer care
Transferability	Non-transferable

Key exclusions: Plastic shelves, rubber gaskets, LED bulbs, glassware, environmental rusting, cosmetic damage.

Dishwashers

Warranty element	Coverage
Product warranty	2 years
Motor warranty	5 years
Year 1	Parts + labour included
Year 2	Parts; labour chargeable

Registration	Within 30 days
--------------	----------------

Microwave Ovens

Warranty element	Coverage
Product warranty	1 year comprehensive
Magnetron warranty	4 years (defect-based, not wear)
Year 1	Parts + labour + in-home service
Years 2–4 (magnetron)	Magnetron replacement only; labour chargeable

Commercial Laundry Equipment

Warranty element	Coverage
Product warranty	1 year (parts)
Labour	Included in Year 1 under AMC or installation-linked contract
Preventive maintenance	Recommended every 6 months; mandatory for warranty on high-usage sites
Spare-part availability	7 years from product discontinuation
On-site SLA	Next business day response for sites with active AMC
Registration	Mandatory at installation by authorised service partner

Service Network

Customer Support Channels

Channel	Details	Hours
Toll-free helpline	1800-XXX-XXXX	24/7
Email	support@abcelectronics.in	Response within 24 hours
ABC Connect App	Service booking, ticket tracking, product registration	24/7
Chat support	Via website and app	09:00–21:00 IST
Service request form	Available on website support portal	24/7

How to Register a Product

1. Download the ABC Connect app OR visit our support portal

2. Create or log in to your account
3. Enter product model number (found on the back or bottom of the appliance) and serial number
4. Upload purchase invoice
5. Confirmation is sent within 24 hours

Alternative registration: Give a missed call to our registration line and our team will call back to complete registration.

Authorised Service Centres

We have over 1,200 authorised service centres across India covering more than 500 cities and towns. To locate the nearest centre:

- Use the "Find Service Centre" feature on the ABC Connect app
- Use the store locator on our website
- Call the toll-free helpline

Response time targets:

- Metro cities (Tier 1): Same-day or next-day visit
- Tier 2 cities: Within 2 business days
- Tier 3 and remote: Within 4 business days (parts availability may vary)

Annual Maintenance Contracts (AMC)

We offer two AMC plans:

CareShield Basic:

- 1 preventive maintenance visit per year
- Discounted labour rates (30% off)
- Priority service scheduling
- Applicable to all consumer appliances after warranty

CareShield Plus:

- 2 preventive maintenance visits per year
- Parts coverage for wear-and-tear items (filters, belts, gaskets)
- Zero labour charges for in-warranty failures
- Priority 24-hour response SLA
- Ideal for washing machines, ACs, and refrigerators

Customer Support Workflow

Standard Flow

1. Customer contacts support via app, phone, chat, or email
2. Support agent verifies product registration and warranty status
3. If under warranty → book in-home technician visit at no charge (Year 1) or quote applicable charges (Year 2+)
4. If out of warranty → quote service charge before dispatch
5. Technician visits within SLA, diagnoses issue, and repairs or orders parts
6. Job card raised and customer signs off after repair
7. Customer receives feedback call within 48 hours

Out-of-Warranty Repair

- Minimum diagnostic charge: ₹350 (applicable even if repair not taken forward)
 - Diagnostic charge adjusted against repair bill if repair is authorized
 - Part and labour quote shared before work begins
 - Customer confirmation required before any chargeable repair
-

Error Code Reference

Front-Load Washing Machine Error Codes

Error Code	Meaning	Customer Action
E1	Water inlet timeout — not filling within set time	Check water supply tap is open; check inlet hose is not kinked
E2	Drainage timeout — not draining within set time	Check drain hose is not blocked or kinked; check filter
E3	Motor overload or drive fault	Stop machine, wait 15 minutes, restart. If recurring, call service
E4	Door not locked or door switch fault	Ensure door is properly closed; call service if persists
E5	Over-suds / excess detergent detected	Run rinse cycle without detergent; reduce detergent quantity next wash
E6	Water temperature sensor fault	Do not use machine; call service
E7	Unbalanced load	Open door, redistribute laundry, restart
E9	Water level sensor fault	Do not use machine; call service
F1	Communication fault between control board and motor	Restart machine; if recurring, call service

Air Conditioner Error Codes

Error Code	Meaning	Customer Action
E1	Indoor temperature sensor fault	Call service
E2	Outdoor temperature sensor fault	Call service
E3	Compressor protection — high pressure	Clean outdoor unit; check refrigerant level
E4	Compressor protection — low pressure	Check if outdoor unit is blocked; call service

E5	Communication error between indoor and outdoor unit	Check power; call service if persists
E6	Fan motor fault	Call service
F1	Refrigerant leak detected (AirSmart models)	Stop operation immediately; call service
H1	Defrost mode active	Normal operation; wait 10–15 minutes

Dishwasher Error Codes

Error Code	Meaning	Customer Action
E1	Water inlet fault	Check supply and inlet valve
E2	Drainage fault	Check drain hose; clean filter
E3	Heating element fault	Call service
E4	Overflow protection activated	Check for blockage; call service
E5	Door switch fault	Close door fully; call service if persists

Refrigerator Error Codes

Error Code	Meaning	Customer Action
Er1	Temperature sensor fault — fridge section	Call service
Er2	Temperature sensor fault — freezer section	Call service
Er4	Defrost sensor fault	Call service
Er6	Fan motor fault	Call service
dF	Defrost cycle active	Normal; display returns after 20–30 minutes

Common Troubleshooting Guides

Washing Machine — Not Starting

1. Confirm power supply is connected and socket is live
2. Confirm door is fully closed (machine will not start if door is ajar)
3. Check if child lock is activated — hold Child Lock button for 3 seconds to deactivate
4. Check if water supply tap is open
5. If display shows an error code, refer to error code table above
6. If no display at all, check fuse/circuit breaker

Washing Machine — Excessive Vibration or Noise

1. Ensure machine is level — adjust feet until machine does not rock
2. Remove transit bolts if newly installed (4 bolts at back of machine)
3. Check load is evenly distributed in drum
4. Ensure load weight is within rated capacity
5. Check for foreign objects (coins, bra wires) in drum or pump filter

Air Conditioner — Not Cooling

1. Check remote temperature setting — ensure it is set lower than room temperature
2. Clean air filter — dirty filter reduces cooling by up to 30%
3. Check that outdoor unit is not blocked by debris or shrubs
4. Check if cooling mode is selected (not fan-only or auto)
5. Check if room doors/windows are closed
6. If cooling is significantly reduced and filter is clean, refrigerant may need topping up — call service

Refrigerator — Not Cooling

1. Check temperature setting — fridge section should be set to 3–4, freezer to maximum
2. Check door gaskets are sealing properly (close door on a piece of paper — if paper slips out easily, gasket needs replacement)
3. Ensure vents inside are not blocked by overfilled shelves
4. Check condenser coils at back are dust-free
5. If compressor does not start (no humming sound), call service

Dishwasher — Dishes Not Clean

1. Check rinse aid level and top up if empty
2. Ensure spray arms are not blocked — remove and rinse under running water
3. Check water temperature — dishwasher requires minimum 55°C supply for best results
4. Do not pre-rinse plates excessively — sensors need soil to activate correct wash level
5. Use correct quantity of detergent for your water hardness level

Spare Parts Availability

Category	Spare-Part Support Period
Washing machines	7 years from production date
Air conditioners	7 years from production date
Refrigerators	10 years from production date
Microwave ovens	5 years from production date
Dishwashers	7 years from production date
Commercial laundry	7 years from product discontinuation

Genuine spare parts are available through:

- Authorised ABC Electronics service centres
- ABC Connect app (for consumables like filters and accessories)
- Authorised distributors in your city

Warning: Use of non-genuine parts voids warranty and may cause safety hazards. We do not support any claims arising from installation of counterfeit or third-party parts.

Warranty Registration Channels

Method	Steps
ABC Connect App	Download app → Register → Add product → Upload invoice
Website portal	Visit support page → Sign in → Add product
Phone	Call toll-free 1800-XXX-XXXX; agent will register while you are on the call
Missed call	Give missed call to registration line; our team calls back within 30 minutes

Important: Warranty activation requires registration within the specified period (15 days for refrigerators and ACs; 30 days for all other products). Failure to register within this period may result in standard 1-year warranty instead of the extended manufacturer warranty.