Hardware User Manual

AnyDIO Series

SIO-DB32P

AJINEXTEK AXT

Product Information

Full information about other AJINEXTEK products
is available by visiting our Web Site at:
www.ajinextek.com

Useful Contact Information

Customer Support Seoul
Tel : 82-31-389-1580~2 Fax: 82-31-389-1583
E-mail : marketing@ajinextek.com

Customer Support Daegu
Tel : 82-53-593-3700 Fax: 82-53-593-3703
E-mail : support@ajinextek.com

AJINEXTEK's sales team is always available to assist you in making your decision the final choice of boards or systems is solely and wholly the responsibility of the buyer. AJINEXTEK's entire liability in respect of the board or systems is as set out in AJINEXTEK's standard terms and conditions of sale

ⓒ Copyright 2001 AJINEXTEK Co.Ltd. All Rights Reserved.

Contents

1. Outline ____ 4

1.1. Introduction 4

1.2. Application 4

2. Features ____ 5

2.1. Module Specifications and Scheme 5

3. Installation ____ 7

3.1. Hardware Installation 7

3.2. Software Installation 7

4. Configuration ____ 8

4.1. Hardware Configuration and Description 8

4.2. Module Address Map 12

4.2.1. ADDRESS MAP 12

4.2.2. FUNCTIONAL DESCRIPTION 14

4.3. Pin Array and Description of SIO-DB32P Module Board Champ Connector 23

4.4. Pin Connection and Description of SIO-DB32P Module Board Terminal Block .. 25

5. Accessories (Optional Items) ____ 26

5.1. Module Accessories and Configuration 26

5.2. Device Connection 27

6. Ordering Information (Family) ____ 31

Revision History

Manual	PCB	Comments
Rev. 1.0 issue 1.0	Rev. 1.0	2001. 12. 18

1. Outline

1.1.Introduction

AnyDIO module board is loaded on the AnyBus Series board. It has an input module, output module and input-output module which can control digital signal's input-output, and it is composed of various product group providing up to 32 points of IO contacts per each module. Among the models of AnyDIO module boards, the SIO-DB32P module board provides 16 points input/ 16 points output (power TR output mode) of digital IO contacts.


1.2.Application

AnyDIO module board can interface the external digital I/O signals, and can be used on the factory automation, machine tool control, laboratory work, educational purpose, etc.

- Digital Monitoring
- Signal Conversion
- Optical Insulation between Computer and the Peripheral
- Automatic Test Equipment
- Equipment Monitoring
- Equipment Interface
- Process Control
- Industrial Measurement
- Data Acquisition of Sensor
- Signal Conversion
- Industrial Digital I/O Control
- Monitoring of 24V Signal

2. Features

2.1.Module Specifications and Scheme



Picture 1. Real Picture of SIO-DB32P Module Board

Table 1. Features of SIO-DB32P Module Board

Items	SIO-DB32P
Input	16 points
	16 points input can be accessed in bit and byte units.
	If a random bit inside of input bits was activated, a special interrupt is generated and the location where interrupt generated can be identified.
	Interrupt removal can be done by a library function.
Interrupt	Every input
Input Resistance	4.7㏀
Output	16 points
	Output 16 points can be written and read in bit and byte units.
Range of Output Voltage	12~24Vdc
Output Current	50 ㎃ (up to 68Pin CHAMP connector) Option : 50 ㎃ per each pin when using T36-PR terminal block. 500 ㎃ per each pin when using APC-EB36 terminal block.
Output Resistance	Open collector type
I/O Circuit	Sink (Negative logic)
	Every I/O port is electrically isolated with the external signal, so the external signals of 12V, 24V can be recognized or driven. Isolation makes use of a photo coupler.

Table 2. Specifications of SIO-DB32P Module Board

# of Input Channel	16 points
Input Range	External power license mode (12V ~ 24V)
Input Mode	Voltage
	Adopt noise prevention LPF per each input channel
Range of Input Voltage	Low (min : 0v ~ max : 12.0V)
	High (min : 12.5V ! max : 24V)
Input Load Current	Low (2mA – ON)
	High (2.1mA – OFF)
# of Output Channel	16 points
Output Range	External power license me (12V ~ 24V)
Output Method	Open collector type
Output Mode	Voltage
Turn ON/OFF Time	20μs and over
Active Indicator	2 LEDs for the license confirmation (5VDC, 3.3VDC)
Others	Isolated with photo coupler
	Characteristics of isolation: 2500VRMS

3. Installation

3.1.Hardware Installation


The loading direction of an AnyPack module (SIO-DB32P) in Add-On type varies according to the basic mode baseboard a user selected. Load a module properly with reference to 'Hardware Description' of the baseboard user manual and then install according to the order of 'Hardware Installation'.

3.2.Software Installation


Install EzConfig referring to the EzConfig 1.0 user manual. If an installation target folder is not assigned yet, it is presumed that installation of EzDioAgent program is normally completed when the EzDioAgent.exe executive file exists in the C:\Program Files\EzConfig. If the installation target folder is assigned separately, check whether the EzDioAgent.exe executive file exists in the assigned folder or not.

4. Configuration

4.1.Hardware Configuration and Description



Picture 2. Block Diagram of SIO-DB32P Module Board



Picture 3. Size of SIO-DB32P Board


Table 3. Environment in Use of SIO-DB32P Module Board

Board Size	120 x 45 mm
Working Voltage	3.3V, 5V, 24V (12V)

Depending on how you combine AnyDIO modules on the AnyBus board, the number of control IO contacts can be extended or modified by a simple operation in the control system using various IO devices.

If BPFR(PCI Full Size) is selected as a basic mode baseboard, it can compose up to 128 points with 4 AnyDIO

modules having 32 contacts. And it can be composed of 128 points input board, 64 points input/64 points output board and 128 points output board according to the selection of AnyDIO series. If SUB1 is used as a CPU slot on the BPFR board, it can get 96 DIO contacts by loading up to 32 points of AnyDIO on the 3 SUB slots. This configuration method can be changed into 96 points input (three SIO-DI32), 96 points output (three SIO-DO32P), 48 points input/48 points output (three SIO-DB32P), etc. depending on which AnyDIO module is used.




Picture 4. Configuration of SIO-DB32P

Picture 4 shows a control division (PLD), SUB module connector, photo coupler, output drive, indication LED, etc. of the SIO-DB32P.

There are three wide functions in the control division. First, it has a function to read and write 16 points input and 16 points output. Second, it controls a data flow between the basic mode baseboard and the local module board. The last, it has an interrupt processing function generated from the local bus. Therefore users can control hardware easily. The first function implies that IO control provides a buffer and a latch in order to read and write the external data of the basic mode baseboard so the external data can be exchanged smoothly. Second function is that it separates registers by internal functions through the decoder so it makes data transmission between the basic mode baseboard and the local module easy. Lastly, the interrupt processing division can process the special bit only with an interrupt mask, and also process the change of state of the external input signal individually or simultaneously at the rising edge and the falling edge. It generates interrupt and transmits to the control division of the basic mode baseboard then it finally helps the user to apply.


64 pin PMC(PCI Mezzanine Card) SUB module connectors of the A port and the B port are summarized in short as follows. The A port supplies 5V and 3.3V power to module from the AnyBus baseboard. The signal line of the A port is composed of data 8 bit, address 9 bit, read and write signals, selection signal of module, one interrupt request signal (IRQ) and so on. The B port receives the external power supply and 16 input/16 output digital IO contacts are connected with the 68 CHAMP connector. For the input, photo couplers are generally used where grounds are

hardly used in common or when sensors that send out the digital output are different from each other.




Picture 5. In Case of Using Input Signal's Photo Coupler

All the 16 points digital inputs are isolated with the photo coupler. Having a low pass filter (LPF) within each input circuit, it prevents malfunction or system damage from a noise or searching voltage and removes chattering generated when using mechanical contacts.




Picture 6. Output Signal's Photo Coupler

All the 16 points digital outputs are isolated with the external signals by the photo coupler.



Picture 7. Power Processing inside of the Module


Picture 7 shows the power process inside of module. Each port is composed of 8 bits. Port1 and Port3 are connected with the same power supply line, and so are port2 and port4. Therefore it is easy to separate from equipment or sensor that makes a lot of noise by using each different power supplier.



Picture 8. Power Indication LED

Two LEDs on the SIO-DB32P module board are attached in order to indicate getting a supply of 3.3V and 5V power from the AnyBus baseboard. The LED is turned on if power is supplied from the AnyBus base and turned off if power is not supplied.

4.2.Module Address Map



Picture 9. SIO-DB32P Information View Screen Using EzConfig Software

Table 4. Range of Address Allocated to Each SUB

Region	BIFR, BV6R, BPFR, BC6R (FULL SIZE / 6U)	BIHR, BV3R, BPHR, BC3R (HALF SIZE / 3U)	Remarks
	0000h – 1FFFh	0000h – 1FFFh	
0000h – 03FFh	Address space allocated to SUB1	Address space allocated to SUB1	1Kbyte
0400h – 07FFh	Address space allocated to SUB2	Address space allocated to SUB2	1Kbyte
0800h – 0BFFh	Address space allocated to SUB3	-	1Kbyte
0C00h – 0FFFh	Address space allocated to SUB4	-	1Kbyte

If you select BIFR (ISA Full Size) board as a basic mode baseboard and start viewing information of SIO-DB32P module loaded on the SUB3 by using EzConfig software, you can get information that an address of module3 is the initial address of SIO-DB32P.

Address = Base Address + 0800h(SUB 3 Offset Address)

If you press baseboard (B) tab on the information view dialog window, you can get information about the baseboard easily.

4.2.1. Address Map

Table 5. Address Map of SIO-DB32P Module Board


Offset	Function	Data	Length	Direction	Initial Value
00h	Preamble		8 bit	R	B6h
02h	ID		8 bit	R	99h (153)
04h	Version		8 bit	R	00h
06h	Software Reset	Bit0 : 1(ON) Software reset when Write	1 bit	R/W	00h
..0Fh	Reserved				
10h	Output port 1	Bit0..7 : 0(OFF)/1(ON)	8 bit	R/W	00h
12h	Output port 2	Bit0..7 : 0(OFF)/1(ON)	8 bit	R/W	00h
14h	Reserved				
16h	Reserved				
20h	Input port 1	Bit0..7 : 0(OFF)/1(ON)	8 bit	R	
22h	Input port 2	Bit0..7 : 0(OFF)/1(ON)	8 bit	R	
24h	Reserved				
26h	Reserved				
30h	Interrupt Flag port 1	Bit0..7 : 0(OFF)/1(ON) Clear when Write	8 bit	R	00h
32h	Interrupt Flag port 2	Bit0..7 : 0(OFF)/1(ON) Clear when Write	8 bit	R	00h
34h	Reserved				
36h	Reserved				
40h	Interrupt Rising edge port 1	Bit0..7 : 0=None / 1=Rising	8 bit	R/W	00h
42h	Interrupt Rising edge port 2	Bit0..7 : 0=None / 1=Rising	8 bit	R/W	00h
44h	Reserved				
46h	Reserved				
50h	Interrupt Falling edge port 1	Bit0..7 : 0=None / 1=Falling	8 bit	R/W	00h
52h	Interrupt Falling edge port 2	Bit0..7 : 0=None / 1=Falling	8 bit	R/W	00h
54h	Reserved				
56h	Reserved				
60h	Interrupt Enable control	Bit0 : 1(ON)=Enable 0(OFF)=Disable	1 bit	R/W	00h
62h	Interrupt status	Bit0 : 1(ON)=Occur, Automatic Clear when Clear the whole Flag Register	1 bit	R	00h

The SIO-DB32P address has a space of 1kbyte, and the actual space used is from 00h to 62h.

4.2.2. Functional Description


A. Preamble Register : Read Only(00h)

Preamble register arranged the combination of ‘0’ and ‘1’ and the value of ‘10110110’(0xB6) is read. This value is always read in this register address, so it is used on the automatic cognition of a module board together with the ID register.




B. ID Register : Read Only(02h)

Each module has its own ID(identifier), so this information can distinguish which module board was loaded on the current baseboard. The ID of a SIO-DB32P module board is ‘10011001’(0x99h).




C. Version Register : Read Only(04h)

The current information on the firmware and the hardware mounted on the current module board can be captured. If you read this register address, you can also read the version of SIO-DB32P.




D. Software Reset : Read Only(06h)

Using of a baseboard's reset switch or booting of a PC can initialize the state of the module board. And if you write '1' on the lowest rank bit D0 of the 06h address on the program, every register phase can be also fixed as the initial value listed in the table 5. That is, it functions as a reset switch of the baseboard.




E. Output Port1 Register : Read and Write(10h)

The user can generate a special data value from the outside only through this register. Since the user can read (read back) data wrote on the Output Port1 Register again, the value wrote can be confirmed.



F. Output Port2 Register : Read and Write(12h)

The user can generate a special data value from the outside only through this register. Since the user can read (read back) data wrote on the Output Port2 Register again, the value wrote can be confirmed.




G. Input Port1 Register : Read Only(20h)

This register showed the external Input Port1's data as it is. To read the status, read the address.




H. Input Port2 Register : Read Only(22h)

This register showed the external Input Port2's data as it is. To read the status, read the address.




I. Interrupt Flag Port1 : Read Only(30h)

Set up an interrupt on the special bit from the current module board. If the interrupt is occurred from the bit, the Interrupt Flag Port1 comes to show information about it and the interrupt occurred bit will be changed into '1'.




J. Interrupt Flag Port2 : Read Only(32h)

Set up an interrupt on the special bit from the current module board. If the interrupt is occurred from the bit, the Interrupt Flag Port2 comes to show information about it and the interrupt occurred bit will be changed into '1'.




K. Interrupt Rising edge Port1 : Read and Write(40h)

This register is set to detect interrupt from the rising edge of a bit the user wants. If the Interrupt Rising edge Port1 Register bit is '1' and the input of a bit equivalent to the Input Port1 Register is changed from '0' to '1', the appropriate bit of the Interrupt Flag Port1 is set as '1', and the interrupt occurs. (Only if interrupt is enabled)




L. Interrupt Rising edge Port2 : Read an Write(42h)

This register is set to detect interrupt from the rising edge of a bit the user wants. If the Interrupt Rising edge Port2 Register bit is '1' and the input of a bit equivalent to the Input Port2 Register is changed from '0' to '1', the appropriate bit of the Interrupt Flag Port2 is set as '1', and the interrupt occurs. (Only if interrupt is enabled)




M. Interrupt Falling edge Port1 : Read and Write(50h)

This register is set to detect interrupt from the falling edge of a bit the user wants. If the Interrupt Falling edge Port1 Register bit is '1' and the input of a bit equivalent to the Input Port1 Register is changed from '1' to '0', the appropriate bit of the Interrupt Flag Port1 is set as '1', and the interrupt occurs. (Only if interrupt is enabled)




N. Interrupt Falling edge Port2 : Read and Write(52h)

This register is set to detect interrupt from the falling edge of a bit the user wants. If the Interrupt Falling edge Port2 Register bit is '1' and the input of a bit equivalent to the Input Port2 Register is changed from '1' to '0', the appropriate bit of the Interrupt Flag Port1 is set as '1', and the interrupt occurs. (Only if interrupt is enabled)




O. Interrupt Enable Control : Read and Write(60h)


It has a function to enable/disable the whole interrupt. It is disabled when the register is '0' and enabled when it is '1'. A flag is generated according to the setting of Interrupt Rising edge Register and Interrupt Falling edge Register described above, and then it finally makes Interrupt (IRQ). Just for reference, a rising edge and a falling edge can be detected simultaneously if interrupt rising edge register and interrupt falling edge register are simultaneously set and used at the same bit.



P. Interrupt Status : Read Only(62h)

If any interrupt is occurred on the current module board, the Interrupt Status Register bit 0 will be turned into '1'. And if Interrupt Flag Port is all cleared, the Interrupt Status will be automatically cleared, too.





Picture 10. Flag Processing Block


For the full understanding, the interrupt process is illustrated as above. In picture 10, the line input is the data read from 20h and 22h, and selecting a change (rising edge, falling edge) in this data can generate interrupt. A rising edge and a falling edge can be chosen simultaneously. In this case, they are not sensed at the same time and interrupt is occurred according to the previously entered signal's status.

The interrupt will be occurred at the next signal, too. For instance, suppose the user selected both rising edge and falling edge. Interrupt occurs in IRQ when the falling edge signal enters to the input and it occurs again in IRQ when the rising edge signal enters to the input again.

Interrupter Enable Control (60h) should be activated to generate interrupt. That is, Interrupter Enable Control has a function to control the whole interrupt.

If interrupt is occurred, Interrupter Status (62h) should clear information on the current Flag Register to sense the next interrupt. In order to find out if any interrupt is occurred in the Flag Register, read Interrupter Status Register first. If the Flag Register is '1', clear all the current Flag Register and then wait for the next interrupt.


Picture 10 is simply expressed in picture 11.



Picture 11. Simplified Flag Processing and Interrupt Processing Block

4.3.Pin Array and Description of SIO-DB32P Module Board Champ Connector

SIO-DB32P is a digital IO board having 16 points input and 16 points output, and it is electrically isolated with the external power connected through the connector. When you connect the external device and the terminal block, be sure to refer to the following table.



Picture 12. In Case of Loading SIO-DB32P on the BIFR's SUB1


Picture 12 shows the case loaded with SIO-DB32P on the SUB1/CPU module socket of the BIFR board. The external IO interface division connected to the outside through the special or general purpose cable is composed of a 68pin CHAMP connector and a DCOM Port, a distributed master module connector, and each 68pin connector and DCOM Port are connected with the SUB module. DCOM Port is used when AnyField Series products are loaded, so this manual will not make the subject here.

Table 6. 68Pin CHAMP Connector Pin Array When SIO-DB32P Module is Loaded

J1	Pin Name	Dir.	Description	J1	Pin Name	Dir.	Description
1	P1-3_P24V		+24V Power of PORT1	35	P1-3_N24V		0V Power of PORT-3
2	P1_IN0	I	Inport 1, bit0	36	P3_OUT0	O	Outport 1, bit 0
3	P1_IN1	I	Inport 1, bit1	37	P3_OUT1	O	Outport 1, bit 1
4	P1_IN2	I	Inport 1, bit2	38	P3_OUT2	O	Outport 1, bit 2
5	P1_IN3	I	Inport 1, bit3	39	P3_OUT3	O	Outport 1, bit 3
6	P1_IN4	I	Inport 1, bit4	40	P3_OUT4	O	Outport 1, bit 4
7	P1_IN5	I	Inport 1, bit5	41	P3_OUT5	O	Outport 1, bit 5
8	P1_IN6	I	Inport 1, bit6	42	P3_OUT6	O	Outport 1, bit 6
9	P1_IN7	I	Inport 1, bit7	43	P3_OUT7	O	Outport 1, bit 7
10	P2-4_P24V		+24V Power of PORT2-4	44	P2-4_N24V		0V Power of PORT2-4
11	P2_IN0	I	Inport 2, bit8	45	P4_OUT0	O	Outport 2, bit 8
12	P2_IN1	I	Inport 2, bit9	46	P4_OUT0	O	Outport 2, bit 9
13	P2_IN2	I	Inport 2, bit10	47	P4_OUT0	O	Outport 2, bit 10
14	P2_IN3	I	Inport 2, bit11	48	P4_OUT0	O	Outport 2, bit 11
15	P2_IN4	I	Inport 2, bit12	49	P4_OUT0	O	Outport 2, bit 12
16	P2_IN5	I	Inport 2, bit13	50	P4_OUT0	O	Outport 2, bit 13
17	P2_IN6	I	Inport 2, bit14	51	P4_OUT0	O	Outport 2, bit 14
18	P2_IN7	I	Inport 2, bit15	52	P4_OUT0	O	Outport 2, bit 15

J1	Pin Name	Dir.	Description	J1	Pin Name	Dir.	Description
19	N.C			53	N.C		
20	N.C			54	N.C		
21	N.C			55	N.C		
22	N.C			56	N.C		
23	N.C			57	N.C		
24	N.C			58	N.C		
25	N.C			59	N.C		
26	N.C			60	N.C		
27	N.C			61	N.C		
28	N.C			62	N.C		
29	N.C			63	N.C		
30	N.C			64	N.C		
31	N.C			65	N.C		
32	N.C			66	N.C		
33	N.C			67	N.C		
34	N.C			68	N.C		

J1, J2, J3, J4 are connected with the SUB1, SUB2, SUB3, SUB4, respectively, and they are connected to the terminal block or the external device through a cable. Therefore, 68pin CHAMP connector J1's signals are arranged as table 6 when SIO-DB32P module is loaded on the SUB1 socket. Among the 68 pins, a total of 36 pins including 16 points input, 16 points output and 4 power sources are used only.



Picture 13. CHAMP Connector


Picture 13 shows the 68 CHAMP connector's pin connected to the SIO-DB32P module.

4.4.Pin Connection and Description of SIO-DB32P Module Board Terminal Block

Table 7. Pin Connection and Description of T36-PR, APC-EB36 Terminal Block

T36-PR APC-EB36	Pin Name	Dir.	Description	T36-PR APC-EB36	Pin Name	Dir.	Description
1	P1-3_P24V		+24V Power of PORT1-3	19	P1-3_N24V		0V Power of PORT1-3
2	P1_IN0	I	Inport 1, bit0	20	P3_OUT0	O	Outport 1, bit 0
3	P1_IN1	I	Inport 1, bit1	21	P3_OUT1	O	Outport 1, bit 1
4	P1_IN2	I	Inport 1, bit2	22	P3_OUT2	O	Outport 1, bit 2
5	P1_IN3	I	Inport 1, bit3	23	P3_OUT3	O	Outport 1, bit 3
6	P1_IN4	I	Inport 1, bit4	24	P3_OUT4	O	Outport 1, bit 4
7	P1_IN5	I	Inport 1, bit5	25	P3_OUT5	O	Outport 1, bit 5
8	P1_IN6	I	Inport 1, bit6	26	P3_OUT6	O	Outport 1, bit 6
9	P1_IN7	I	Inport 1, bit7	27	P3_OUT7	O	Outport 1, bit 7
10	P2-4_P24V		+24V Power of PORT3-4	28	P2-4_N24V		0V Power of PORT2-4
11	P2_IN0	I	Inport 2, bit8	29	P4_OUT0	O	Outport 2, bit 8
12	P2_IN1	I	Inport 2, bit9	30	P4_OUT1	O	Outport 2, bit 9
13	P2_IN2	I	Inport 2, bit10	31	P4_OUT2	O	Outport 2, bit 10
14	P2_IN3	I	Inport 2, bit11	32	P4_OUT3	O	Outport 2, bit 11
15	P2_IN4	I	Inport 2, bit12	33	P4_OUT4	O	Outport 2, bit 12
16	P2_IN5	I	Inport 2, bit13	34	P4_OUT5	O	Outport 2, bit 13
17	P2_IN6	I	Inport 2, bit14	35	P4_OUT6	O	Outport 2, bit 14
18	P2_IN7	I	Inport 2, bit15	36	P4_OUT7	O	Outport 2, bit 15

This table shows the pin connection and description from a viewpoint of terminal block when the SIO-DB32P module is loaded.



Picture 14. Definition of Terminal Block 36 Pin Connector Pin

5. Accessories (Optional Items)

5.1.Module Accessories and Configuration

The optional cable and terminal block used to connect the AnyDIO module and the external device are as follows.

Table 8. Terminal Block and Cable When AnyDIO Module is Loaded

Module Name	Terminal Block	Cable
SIO-DI32	APC-EI36 or T36-PR	C68/36TS
SIO-DO32P	APC-EO36 or T36-PR	C68/36TS
SIO-DB32P	APC-EB36 or T36-PR	C68/36TS
SIO-DI16 SIO-DO16T SIO-DB16T	Not in use	No private cable


A. Cable




Picture 15. C68/36TS

C68/36TS, an asymmetric cable, has a Pitch (pin interval) of 0.8mm and 1.27mm. This cable connects the external connector (J1,J2,J3,J4) of the AnyBus baseboard and the terminal block one-to-one. The twist pair consists of 68 pins, such as 1 and 35, 2 and 36, …., 34 and 68. Max. 50mA of current can be flowed per each pin. Each cable is 1m, 2m, 3m long in length, and it can be supplied up to 5m long on the user's demand.

B. Terminal Block



T36-PR One-to-One Terminal Block




APC-EB36 Digital I/O Terminal Block

Picture16. Types of Terminal Block – One-to-One Terminal Block (left) and High Quality I/O Terminal Block (right)

In the AnyDIO module, a terminal block (APC-EB36) with the current amplified circuit inside or a general terminal block (T36-PR) connected one-to-one can be used on the output edge.


T36-PR and APC-EB36 terminal blocks are designed to be able to load on the 35mm wide slide type DIN-Rail, so it is easy to take on/off in case of installation and wiring work.

5.2.Device Connection




Picture 17. Connection between SIO-DB32P Module Board and the Peripheral (Terminal Board)

Picture 17 shows the connection between C68/36TS cable and APC-EB36 terminal block that are used to connect the external devices when the SIO-DB32P module board is loaded on the real BIHR board. And a diagram shows the connectable sensors to the outside of a terminal block. In addition to the sensors illustrated above, some other sensors the user wants can be used.



Picture 18. Description of Terminal Block Pin


Picture 18 shows the pin name and location of the terminal block.



Input circuit Output circuit


Picture 19. I/O Circuit Diagram inside of Terminal Block

Picture 19 shows I/O circuit diagram of the terminal block.



Picture 20. Basic Configuration Using T36-PR Terminal Block


Picture 20 shows a wiring diagram between T36-PR terminal block and components. The lamp is connected to the PORT4 – OUT0, and the limit switch is connected to the PORT1 – IN3. T36-PR can send output current up to 50mA. Input and output are operated 7by sink (negative logic).



Picture 21. Basic Configuration Using APC-EB36 Terminal Block

Picture 21 shows a wiring diagram between APC-EB36 terminal block and components. The lamp is connected to the PORT4 – OUT1, and the limit switch is connected to the PORT1 – IN3. APC-EB36 terminal block has two power connectors outside, so power connection between terminal blocks can be used helpfully when terminal blocks are used a lot. The output current can pass up to 500mA per each pin, and input and output are operated by sink (negative logic).

6. Ordering Information (Family)



Picture 22. The Way of Reading AnyDIO Series Model Name

Table 9. AnyDIO Module's Product Group

Product Group	Description
SIO-DI32	(Centralized) 32 Points Digital Input Module
SIO-DI16	(Distributed) 16 Points Digital Input Module
SIO-DO32P	(Centralized) 32 Points Digital Output Module
SIO-DO16T	(Distributed) 16 Points Digital Output Module
SIO-DB32P	(Centralized) 16 Points Digital Output/ 16 Points Digital Input, Power TR (2803) Output
SIO-DB16T	(Distributed) 8 Points Digital Output/ 8 Points Digital Input, Power TR (2803) Output

The contents of this manual are subject to change without notice. Companies, organizations, products, characters and events used in the examples are not real data. We have no intention of correlating with any real companies, organizations, products, characters or events, and it is not allowed to analogize like that. It lies upon users to obey the applicable copyright law. In addition to the copyright's rights, any part of this manual cannot be reproduced for any kind of form, means (electrical and mechanical duplication, diskette copying, or other ways) or other purposes without Ajinextek's written acknowledgment. And besides it cannot be saved, introduced or transmitted on the retrieval system.

Ajinextek can possess patent rights, trademark rights, copyright or other intellectual proprietary rights related to this manual. According to the written contract of the usufructuary right, an offer of this manual does not allow you to have such patent rights, copyright or other intellectual proprietary rights except the rights provided clearly by Ajinextek.