T36-PR v1.0 & T36-PR v2.0

Number	Name	Description	Number	Name	Description
1	P24V	External +24V Power	19	N24V	External Power GND
2	PULS+	Pulse Output Signal (422+)	20	PULS-	Pulse Output Signal (422-)
3	DIR+	DIR Output Signal (422+)	21	DIR-	DIR Output Signal (422-)
4	SVON	Servo Drive ON Signal	22	INPO	Servo Inposition Signal
5	ALM	Servo Alarm Signal	23	ALMC	Servo Alarm Clear Signal
6	LGND	Logic GND	24	CLR	Servo Residual Pulse Removal Signal
7	ECA+	Encoder A-Phase Input (422+)	25	ECA-	Encoder A-Phase Input (422+)
8	ECB+	Encoder B-Phase Input (422+)	26	ECB-	Encoder B-Phase Input (422+)
9	ECZ+	Encoder Z-Phase Input (422+)		ECZ-	Encoder Z-Phase Input (422+)
10	IN2	Universal Input Pin 2	28	OUT2	Universal Output Pin 2
11	IN3	Universal Input Pin 3	29	OUT3	Universal Output Pin 3
12	IN4	Universal Input Pin 4	30	OUT4	Universal Output Pin 4
13	IN5	Universal Input Pin 5	31	OUT5	Universal Output Pin 5
14	X_EXPP	MPG EXPP(-) Input	32	X_EXMP	MPG EXMP(+) Input
15	X_MPG-	MPG EXMP/EXPP(-)	33	PELM	Forward Limit Location Emergency Stop
16	NELM	Backward Limit Location Emergency Stop	34	ORG	Original Sensor Signal (Universal Input 0)
17	EMGN	External Operation Cutoff (Emergency Stop)	35	TRIG	Trigger Generation at the Special Location
18	NC		36	NC	