amazon rme

AMAZON BASE BUILDING MAINTENANCE STANDARD

GLOBAL CENTRAL RME STANDARDS & COMPLIANCE

Task Title	DOCKS, 1 - 12
APM Object	DOCKS.01
APM EC	AMZ.DOCK.SUB
BBM Handbook Title	Dock System
General tasks always required	Follow safety procedures - e.g. 1MRA, LOTO, PPE, etc. Ensure that all WOs are carried out by qualified, certified staff with appropriate familiarisation and supervision as required Add notes for each observation and create a FWO if necessary to eliminate defects Use appropriate tools, chemicals and industry standard practices (RME policy permitting) Ensure relevant logs, readings and certification is uploaded to APM prior to WO closure These tasks are based on industry guidance, SME knowledge and HIE learning. Please ensure vendor specific requirements are followed. To suggest improvements please raise a SIM SIM - Link to SIM template

Last Update: (Version)	Sep-24	**Geo Applied:**	Intl APM Instance	**F-Gas**	Not Identified	**Activies may be covered by No-Go restrictions:**	TBC	**Special Certificaion Required:**	TBC	**Delivered By:**	TBC	**OCB:**	BBM
Evidence for CT:	YES	**Pricing template Position:**	12	**Related CT Areas:**	CT.WORK.DOCK			**Assets included in this PM:**	LOCK - DOOR - RAMP - SHELTER SURROUND - AIR BAG DOOR SEAL - BUMPER - (DOCKS) FAN - (DOCKS) LIGHT - TRAFFICLIGHT	**Schedule With:**	-		

Description of System / Technology (According to BBM Handbook)

DOCK DOOR: Dock doors are a type of loading dock which are usually raised in the air in order to be level with trucks carrying goods.
DOCK RAMP: Dock ramps act as a liaison between the warehouse and trucks, making up for differences in height and filling the gap between truck and building.
DOCK LOCK: The Lock locks trailers onto the loading bay By locking the rear wheel, the docked vehicles will no longer move away from the dock. Also, vehicle "creeping', caused by momentum incurred during the loading and unloading process is prevented. This guarantees optimal safety.
DOCK AIR BAG SEAL: Inflatable lining around the entrance of the Dock door which reduces airflow and dust particles entering in the warehouse when trailers are loading/unloading via the Dock door.

Additional Information

All sites with the above listed Base Building Asset should conduct routine maintenance and inspections according to this standard PM package. The Amazon maintenance standard supports compliance, reduces safety risks,improves asset reliability & efficiency.
Some maintenances captures several assets within one PM package -> Ensure that corrective/reactive maintenance for assets where proactive maintenance is contained under another asset is created against the original asset.
Note: Tasks are based on maintenance of an Expresso system, but can be applied on other vehicle restraint systems as well. Tasks are not relevant, you can mark them as N/A and names of the equipment used vary depending on the manufacturer.

Task Index	Component	Tasks	Tasks Nested for frequencies > weekly									
			Daily	Weekly	Monthly	3 Monthly	6 Monthly	12 Monthly	24 Monthly	36 Monthly	48 Monthly	60 Monthly
1	All components General	Is the unit operational & no alarms indicated				PM	PM	PM				
2	All components General	Are there any visual damage, missing / loose components or corrosion				PM	PM	PM				
3	All components General	Are the technical documentation & electrical drawings complete						PM				
4	All components Safety	Are all safety switches & other safety components functioning correctly				PM	PM	PM				
5	All components Safety	Are disconnecting devices lockable in the safe position (LOTO)				PM	PM	PM				
6	Dock Traffic light	Is the traffic light system functioning correctly				PM	PM	PM				
7	Dock Door	Is the electric wheel wedge functioning correctly				PM	PM	PM				
8	Dock Door	Test sliding clutch by holding the door in motion until the motor stops.						PM				
9	Dock Door	Is the manual emergency operation unit functioning correctly						PM				
10	Dock Door	Are all cables (flexible/spiral) free from damage & tightly connected				PM	PM	PM				
11	Dock Door	Does the limit switches deactivate the motor at endpoints						PM				
12	Dock Door	Are photo cells fitted correctly, beams are aligned & clean						PM				
13	Dock Door	Are the photocells activated when the beams are interrupted						PM				
14	Dock Door	Does the pass door switch disable the door from being operated						PM				
15	Dock Door	Can the door be moved when engaged to the motor						PM				
16	Dock Door	Is it possible to unlock the door from the motor (drive)						PM				
17	Dock Door	Is the motor fixed properly						PM				
18	Dock Door	Does the motor make unusual noise						PM				
19	Dock Door	Does the motor emit excessive hot during multiple runs						PM				
20	Dock Door	Is the power consumption as per design of the motor						PM				
21	Dock Door	Are all wires in the panel connected tightly						PM				
22	Dock Door	Can all remote control functions of the door be used properly						PM				
23	Dock Door	Are traction wire ropes securely fixed to the bottom bracket				PM	PM	PM				
24	Dock Door	Are all sealings free of damage & closing leaks as designed						PM				
25	Dock Door	Is the anti lifting device functioning properly						PM				
26	Dock Door	Is the pull down rope or chain functioning properly & free of damage						PM				
27	Dock Door	Functional cleaning and lubrication of roller & relevant equipment						PM				
28	Dock Door	Are the Roller blocks, roller holders and rollers seated correctly						PM				
29	Dock Door	Does the roller make unusual noise when operating manually & electrically						PM				
30	Dock Door	Are the roller in a good condition						PM				
31	Dock Door	Is the door leaf in balance and running straight						PM				
32	Dock Door	Is the bottom bracket free of damage						PM				
33	Dock Door	Are all locks aligned, closing smoothly & functioning properly						PM				
34	Dock Door	Are beam brackets, hangers or suspensions securely fixed						PM				
35	Dock Door	Are wall tracks fixed properly, free of damage & corrosion						PM				

36	Dock Door	Are roof tracks fixed securely to the suspension, free of damage & corrosion						PM					
37	Dock Door	Are bends connected securely to vertical & horizontal tracks						PM					
38	Dock Door	Carry out a functional cleaning of all tracks						PM					
39	Dock Door	Are all tracks in balance						PM					
40	Dock Door	Does the door run smoothly through the bends						PM					
41	Dock Door	Are track covers securely fixed to the track &are free of damage						PM					
42	Dock Door	Are pulley wheels fixed securely and working properly						PM					
43	Dock Door	Carry out a functional cleaning & lubrication of pulley wheels						PM					
44	Dock Door	Are rope roller fixed & functioning properly and free of damage						PM					
45	Dock Door	Are buffers free from damage & functioning properly						PM					
46	Dock Door	Are torsion springs balanced according to IOM						PM					
47	Dock Door	Are torsion springs connection between spring & winding sleeve correctly fixed						PM					
48	Dock Door	Are there any damage like hairline cracks at the torsion springs						PM					
49	Dock Door	Spring Break Device functioning correctly & free of damage						PM					
50	Dock Door	Is the shaft straight & there are no signs of wear & tear or damage						PM					
51	Dock Door	Are the shaft coupling centered correctly & fixed into place to retain the shaft						PM					
52	Dock Door	Does the safety pull set/rope have enough tension						PM					
53	Dock Door	Are there any signs of wear & tear or damage at the safety pull set/ropes						PM					
54	Dock Door	Are support bearings fitted correctly, secure & lubricated						PM					
55	Dock Door	Is the pneumatic safety device functioning correctly						PM					
56	Dock Door Operational cycles	Read operating cycles & at quantity into notes				PM	PM	PM					
57	Dock Door Operational cycles	Reset Service counter according to IOM recommendation Note: Use manufacturer recommended tools						PM					
58	Dock Door Final Check	Check the O&M manual and carry out additional required tasks						PM					
59	Dock Fan	Is the fan functioning properly, attached correctly free from debris & corrosion				PM	PM	PM					
60	Dock Fan	Is there any abnormal sound or vibration while the fan in running				PM	PM	PM					
61	Dock Light	Is the light functioning correctly, attached correctly, free from debris & corrosion				PM	PM	PM					
62	Dock Ramp	Check the correct function of safety devices -> e.g. end-, main- & emergency switches					PM	PM					
63	Dock Ramp	Lock the leveller for maintenance under the platform					PM	PM					
64	Dock Ramp	All necessary markings are present					PM	PM					
65	Dock Ramp	Check the gap seal for proper sealing, dirt & damage					PM	PM					
66	Dock Ramp	The leveller is free from damage deformation & welds free from cracks					PM	PM					
67	Dock Ramp	All moving parts are operating smoothly & doesn`t make unusual noise (Deck, lip, sliding lamel, central unit)					PM	PM					
68	Dock Ramp	Carry out a functional cealing of moving parts and lubricate -> e.g. bearings, joints, etc.					PM	PM					
69	Dock Ramp	There are no leaks at the hydraulic components					PM	PM					
70	Dock Ramp	Carry out a functional cleaning of the hydraulic components						PM					
71	Dock Ramp	Check hydraulic oil level -> Refill if necessary & eliminate the root cause (e.g., leakage)						PM					
72	Dock Ramp	Undertake oil sample analysis -> Create FWO if results determine oil replacement or hydraulic system servicing is required						PM					
73	Dock Ramp	The cables are routed and fixed properly						PM					
74	Dock Ramp	Electrical terminations are secure						PM					
75	Dock Ramp	Check motor/pump for unusual noise and too high powerconsumption						PM					
76	Dock Ramp	Lubricate bearings of Motor/pump (if applicable)						PM					
77	Dock Ramp Final Check	Check the O&M manual and carry out additional required tasks						PM					
78	Dock Lock	Verify the correct operation of all components Weekly only for Expresso systems		PM	PM	PM	PM	PM					
79	Dock Lock	Remove all items that may interfere with the proper operation of the system | Weekly only for Expresso systems		PM	PM	PM	PM	PM					
80	Dock Lock	Check the condition of all moving mechanical components and springs for signs of wear and tear | Weekly only for Expresso systems		PM	PM	PM	PM	PM					
81	Dock Lock	Check the condition of the locking arm (no cracks) Weekly only for Expresso systems		PM	PM	PM	PM	PM					
82	Dock Lock	Floor attachment -> Check if screws of all connected components are tight Weekly only for Expresso systems		PM	PM	PM	PM	PM					
83	Dock Lock	If movement is disrupted, lubricate carrier, rack, joints, locking rod, and other moving parts		PM									
83	Dock Lock	Lubricate carrier, rack, joints, the locking rod & additional moving parts Monthly & 3 monthly only for Expresso systems			PM	PM	PM	PM					
84	Dock Lock	Check the wear condition of the toothed rack, the carriage drive pinion and the locking rod.				PM	PM	PM					
84	Dock Lock	Check lubrication of the wearer (lubricating spray) and reapply if necessary			PM	PM	PM	PM					
84	Dock Lock	Apply white grease to the rack, articulation joints, and locking rod			PM	PM	PM	PM					
85	Dock Lock	Check the condition of the structural parts (welds, deformations) the system				PM	PM	PM					
86	Dock Lock	Check the oil level in the tanks of the hydraulic units						PM					
87	Dock Lock	Check the condition of the hoses (obvious leaks, cuts, blockages, friction, etc.)			PM	PM	PM	PM					
88	Dock Lock	Conduct an oil condition analysis on 30% of the equipment to verify oil quality and ensure reliable operation						PM					
88	Dock Lock	Replace hydraulic oil									PM		
89	Dock Lock	Check proper function of warning signals/lights			PM	PM	PM	PM					
90	Dock Lock	Check the operation of the emergency stop devices		PM	PM	PM	PM	PM					
91	Dock Lock	Check the operating cycles and plan extensive PM according to O&M If required prior to yearly PM cycle			PM	PM	PM						
92	Dock Lock	Check the cable carrier and the cables for cuts, crushing, etc.		PM	PM	PM	PM	PM					

93	Dock Lock	Clean the wheel detection sensors.			PM	PM	PM	PM				
94	Dock Lock Operational Cycles	Add the number of operational cycles			PM	PM	PM	PM				
95	Dock Lock Final Check	Check the O&M manual and carry out additional required tasks					PM	PM				
96	Dock Airbag seal	All components are properly fastened , free from damage and corrosion					PM	PM				
97	Dock Airbag seal	The airbags do not show any damage					PM	PM				
98	Dock Airbag seal	Check airbags for proper airtightness on occupied dock doors					PM	PM				
99	Dock Airbag seal	The fan is functioning correctly and doesn`t make any unusual noise					PM	PM				
100	Dock Airbag seal	Are all cables properly routed and fixed					PM	PM				
101	Dock Airbag seal	Are all electrical terminations secure					PM	PM				
102	Dock Airbag seal	Measure the power consumption of the fan and compare to manufacturer specification					PM	PM				
103	Dock Airbag seal	Lubricate bearings of fan & motor if possible7necessary						PM				
104	Dock Airbag seal	Carry out a functional cleaning of air intakes, outlets & dirty aomponents to maintain a reliable operation (e.g. airbags air intake, motor cooling air intake, etc.)					PM	PM				
105	Dock Airbag seal Final Check	Check the O&M manual and carry out additional required tasks					PM	PM				
106	Dock Shelter	All components are properly fastened, free from damage & corrosion					PM	PM				

Change Log

July 2023 - First issue in new format. Simplification of task scope, alignment with CT.