amazon rme

AMAZON BASE BUILDING MAINTENANCE STANDARD

GLOBAL CENTRAL RME STANDARDS & COMPLIANCE

Task Title	LIFTS, VEHICLE TO GROUND LIFTS - 12
APM Object	LIFTS.V2G
APM EC	AMZ.LIFTS.V2G
BBM Handbook Title	Vehicle to Ground Lift (V2G)
General tasks always required	Follow safety procedures - e.g. 1MRA, LOTO, PPE, etc. Ensure that all WOs are carried out by qualified, certified staff with appropriate familiarisation and supervision as required Add notes for each observation and create a FWO if necessary to eliminate defects Use appropriate tools, chemicals and industry standard practices (RME policy permitting) Ensure relevant logs, readings and certification is uploaded to APM prior to WO closure These tasks are based on industry guidance, SME knowledge and HIE learning. Please ensure vendor specific requirements are followed. To suggest improvements please raise a SIM SIM - Link to SIM template

Last Update: (Version)	Aug-24	**Geo Applied:**	Intl APM Instance	**F-Gas**	Not Identified	**Activies may be covered by No-Go restrictions:**	TBC	**Special Certificaion Required:**	TBC	**Delivered By:**	TBC	**OCB:**	BBM
Evidence for CT:	TBC	**Pricing template Position:**	12	**Related CT Areas:**	Not Identified			**Assets included in this PM:**	VEHICLE TO GROUND LIFT	**Schedule With:**	NO INFO		

Description of System / Technology (According to BBM Handbook)

Hydraulic lift to support the loading of various vehicle from ground level to double deck lorries.

Additional Information

Hydraulic lift to support the loading of various vehicle from ground level to double deck lorries.

Task Index	Component	Tasks	Tasks Nested for frequencies > weekly									
			Daily	Weekly	Monthly	3 Monthly	6 Monthly	12 Monthly	24 Monthly	36 Monthly	48 Monthly	60 Monthly
1	General	Is the technical documentation & blueprints of installed equipment available & complete						PM				
2	General	Are the technical documentation & electrical drawings complete						PM				
3	General	Are there any visual damage, missing / loose components or corrosion				SC	PM	PM				
4	Safety	Are all safety switches & other safety components functioning correctly					PM	PM				
5	Safety	Inspect all safety edges and light curtains to ensure they are functioning correctly and free from damage					PM	PM				
6	Safety	Ensure all warning and operational notices are correctly placed and accurate					PM	PM				
7	Safety	Verify that all safe working load signs are correctly placed and display the accurate information					PM	PM				
8	Safety	Check if artificial lighting levels are sufficient and meet required standards					PM	PM				
9	Safety	Ensure there are no sharp edges present that could pose a safety risk					PM	PM				
10	Electrical	Review the main control panel displays and check the fault logs for any errors or issues that need to be addressed				SC	PM	PM				
11	Electrical	Verify the equipment is functioning correctly and in a safe manner				SC	PM	PM				
12	Electrical	Check the settings of all motor overloaddevices, and inspect motor contactors to ensure tightened as per requirements						PM				
13	Electrical	Inspect cables for correct installation and check for any signs of damage						PM				
14	Electrical	Ensure that no live parts are exposed or accessible						PM				
15	Electrical	Verify that all metal parts are properly earthed to ensure safety and compliance with regulations						PM				
16	Electrical	Check all indicators and replace any lamps if necessary						PM				
17	Electrical	Verify that all platform/pod lights are functioning properly						PM				
18	Electrical	Inspect switches and sensors for proper function and overall condition						PM				
19	Electrical	Inspect the condition of all electrical enclosures and panels to ensure they are intact, secure, and free from damage or corrosion						PM				
20	Electrical	Verify the operation of traffic light systems and ensure that all displays are functioning correctly.					PM	PM				
21	Electrical	Inspect the condition of the tail lift transformer system to ensure it is functioning properly and free from any signs of						PM				
22	Electrical	Change air filter of the panel and check cooling fan for correct function and damage						PM				
23	Hydraulic	Inspect all hoses and pipework for any signs of wear, leaks, or damage, ensuring they are securely connected and in good condition						PM				
24	Hydraulic	Inspect all rams for any signs of damage, leaks, or wear, ensuring they are in good working condition						PM				
25	Hydraulic	Inspect valves, seals, and manifolds for proper operation, checking for any signs of wear, leaks, or damage						PM				
26	Hydraulic	Verify the tightness of all hydraulic connections to ensure they are secure and free from leaks						PM				
27	Hydraulic	Inspect the power-pack and motor fixings to ensure they are secure and free from any signs of wear or damage						PM				
28	Hydraulic	Check the hydraulic pump for proper function and inspect for any signs of damage						PM				
29	Hydraulic	Ensure all adjusters are properly locked off and securely tightened						PM				
30	Hydraulic	Verify that hydraulic fluid levels are within the recommended range and top up if necessary						PM				
31	Hydraulic	Check the efficiency of the oil filter and replace it if necessary						PM				
32	Mechanical	Check all grounding straps and cables for wear, corrosion, or damage					PM	PM				
33	Mechanical	Verify that all components of the grounding system, including clamps, bolts, and connectors, are free from signs of wear, loosening, or corrosion						PM				
34	Mechanical	Lubricate & grease all moving parts (follow manufacturer guideline)						PM				
35	Mechanical	Checkt all moving parts for signs of wear or damage						PM				

36	Mechanical	Check Pivot/Hinge Pins for signs of wear or damage						PM					
37	Mechanical	Verify correct operation of "rope failure devices"						PM					
38	Mechanical	Inspect ropes and chains for any signs of wear, and apply lubrication as needed						PM					
39	Mechanical	Inspect runners and rollers for any signs of wear or damage						PM					
40	Mechanical	Inspect pulleys and bearings for wear and overall condition						PM					
41	Mechanical	Inspect all welds and fixings for any signs of damage or corrosion						PM					
42	Mechanical	Check the condition of platform securing bolts and welds for any signs of wear, damage, or corrosion						PM					
43	Mechanical	Verify the alignment of the platform to ensure it is properly positioned and level						PM					
44	Mechanical	Inspect the platform gates for structural integrity and ensure they operate correctly						PM					
45	Mechanical	Inspect adjustable dock plates and ramps for proper tightness and ensure they are level						PM					
46	Mechanical	Verify that the load house is securely fixed to the ground						PM					
47	Mechanical	Ensure that the load house lid is securely fastened to the base frame						PM					
48	Mechanical	Confirm that the dock level is within acceptable tolerance, with a variation of no more than +/-10mm						PM					
49	Mechanical	Inspect the rubber/soft buffers for their condition and ensure that the mountings are secure						PM					
50	Mechanical	Inspect roller/mesh curtains for their condition and verify that they are properly in place						PM					
51	Mechanical	Check the condition of the wheel guides and ensure that all bolts are securely fastened						PM					
52	Mechanical	Inspect safety ladders for structural integrity, signs of wear, and secure attachment						PM					
53	Mechanical	Verify the proper operation of the safety locking system to ensure it functions correctly						PM					
54	Mechanical	Inspect the outer cladding/meshing for its condition and ensure that it is securely mounted						PM					
55	Mechanical	Check the operation and condition of the bridge plate to ensure it is functioning properly and is in good condition						PM					
56	Mechanical	Inspect the outer shutter door for proper operation and overall condition, ensuring it functions smoothly and is free from damage						PM					
57	Functional Cleaning	Clean the grounding points on both the vehicle and the ground connection to remove any dirt, debris, or oxidation that could impair the connection						PM					
58	Functional test	Verify that the operating time for the "up" and "down" functions is aligned with the manufacturer's guidelines						PM					
59	Functional test	Ensure that the hydraulic working pressure is within the manufacturer's recommended guidelines						PM					
60	Operating hours	Record the operating hours of the unit into the notes						PM					
61	Final Check	Check the O&M manual and carry out additional required tasks						PM					

Change Log

Aug 2024 - New PM on request from AGL RME field team