WINSON WAI-5780 (dung cho WAI-5770-USB): Trang 1 - USB Keyboard / USB COM / RS232 / USB HID

Quet truc tiep tu man hinh hoac in A4 (100% scale).

1

2

3

Quick Setting Manual

1. Open the package and check the appearance and accessories.

2. Getting Started Guide

Connect the barcode scanner to the host through wired. If the connect the method is correct, the scanner will has sound "beep beep". Applicable to WAI-5780.

3. Connection And Transmission Scheme

3.1 USB

Scanner connected with device/PC, scan"**USB Keyboard**"setting code, it can configure the device to USB keyboard mode. In the environment where the application software requires serial port, scan **"USB COM"** and identify it as USB COM type, which requires the user to install the driver (the default configuration of this barcode is 115200 baud rate, 8 data bits, no check bit, 1 stop bit).

USB Keyboard

USB COM

3.2 RS232

To connect the RS232 interface, need to scan the "**RS232**" setting code, add carriage return and line feed by default, and the relevant configuration of the serial port is: 115200 baud rate, 8-bit data, no check bit, 1-bit stop bit.

RS232

3.3 USB HID

USB HID

4. Restore Factory Default

4.1 After scan "Restore Factory Default",scanner interface will be USB Keyboard .

Restore Factory Default

4.2 Version Reading

Version Reading

5. Decoding Configuration

5.1 CR and LF

Add CR

Cancel CR

Add CR and LF

Cancel CR and LF

5.2 Automatic Detection Mode

In the automatic detection scanning mode, turn on the low illumination to detect whether there is a bar code. When bar code is detected, scanner will turn on illumination lighting to read the bar code.

Automatic detection mode

5.3 Continues Reading Mode

The scanning device will always be in working condition.

Continue reading mode

5.4 LED Illumination

Turn On Illumination

Turn Off Illumination

5.5 Aimer

Turn On Aimer

Turn Off Aimer

5.6 Decoding successful prompt tone volume

Only support inverted code

6.4 Alipay Invoicing Function

Alipay invoicing is divided into two setting methods: GBK and UNICODE according to the output format.

6.4.1 GBK format invoicing

WINSON WAI-5780 (dung cho WAI-5770-USB): Trang 2 - Auto detection / Continue reading

Quet truc tiep tu man hinh hoac in A4 (100% scale).

1

2

3

5.6 Decoding successful prompt tone volume

Low

Medium

High

Turn off

5.7 Time Interval

The reading delay of different barcodes when reading

No time interval

500ms

6. Function configuration

6.1 Barcode reversal

Not Support

Only support inverted code

All support

Scanner has been set to **Only support inverted code**, support normal code at the same time,scan the inverted code to support both.

All support

6.2 Safe Mode

Turn Off configuration code function

Turn on configuration code function

6.3 QR code URL barcode configuration

Turn Off URL

Turn On URL

6.4 Alipay Invoicing Function

Alipay invoicing is divided into two setting methods: GBK and UNICODE according to the output format.

6.4.1 GBK format invoicing

Turn on step 1

Turn on step 2

Turn on step 3

Turn off

6.4.2 UNICODE:

Turn on step 1

Turn on step 2

Turn on step 3

Turn Off

WINSON WAI-5780 (dung cho WAI-5770-USB): Trang 3 - Safe mode / QR URL / Alipay / Code ID

Quet truc tiep tu man hinh hoac in A4 (100% scale).

1

2

3

6.1 Barcode reversal

Not Support

Turn Off URL

Turn On URL

Turn on step 3

Turn Off

6.5 Code ID Prefix

Add number as prefix

7. Supplementary Barcode

When the content of the barcode contains English characters, need to scan the barcode below to set it.

English character switch