

check_pg_connectivity

NAME

check_pg_connectivity

Verifies physical connectivity of the power ground network.

SYNTAX

```
status check_pg_connectivity
    [-nets pg_nets]
    [-write_connectivity_file file_name]
    [-check_macro_pins one | all | none]
    [-check_block_pins one | all | none]
    [-check_pad_pins one | all | none]
    [-check_std_cell_pins one | all | none]
    [-max_floating_cluster_size size]
    [-error_view_name file_name]
```

Data Types

pg_nets	collection
file_name	string
size	integer

ARGUMENTS

-nets pg_nets

Specifies the power ground nets to be checked. By default, the command checks all power ground nets.

-write_connectivity_file file_name

Specifies the output file name. If specified, the tool writes detailed net connectivity information to the file.

-check_macro_pins one | all | none

Specifies how macro pins are checked for the specified nets. "one" means that a macro is connected if at least one pin shape of the net is connected. "all" means that a macro is connected only if all pin shapes of the net are connected. "none" means that macro pins are not checked. By default, the value is "one".

-check_block_pins one | all | none

Specifies how block pins are checked for the specified nets. "one" means that a block is connected if at least one pin shape of the net is connected. "all" means that a block is connected only if all pin shapes of the net are connected. "none" means that block pins are not checked. By default, the value is "all".

-check_pad_pins one | all | none

Specifies how pad pins are checked for the specified nets. "one" means that a pad is connected if at least one pin shape of the net is connected. "all" means that a pad is connected only if all pin shapes of the net are connected. "none" means that pad pins are not checked. By default, the value is "one".

-check_std_cell_pins one | all | none

Specifies how std cell pins are checked for the specified nets. "one" means that a std cell is connected if at least one pin shape of the net is connected. "all" means that a std cell is connected only if all pin shapes of the net are connected. "none" means that std cell pins are not checked. By default, the value is "one".

-max_floating_cluster_size size

Specify the maximum size of floating cluster to be returned by the command and reported by the error browser.

-error_view_name file_name

Specifies the error view name. If not specified, the default error view name will be "[block_name]_floatingPG.err".

DESCRIPTION

This command checks the physical connectivity of the power ground network. The command generates information for floating wires, vias, pads, macro pins, and standard cell pins. Those wires/vias of disjoint groups are all floating objects. The information can be viewed by using the error browser. More detailed info can also be written to a file. The command also returns a collection of floating vias and wires. You can easily remove these floating objects using remove_objects command.

EXAMPLES

The following example checks the connectivity of the VSS net, and checks whether all macro power ground pins are connected to the network.

```
prompt> check_pg_connectivity -nets VSS -check_macro_pins all
```

SEE ALSO

[check_pg_missing_vias\(2\)](#)
[compile_pg\(2\)](#)
[connect_pg_net\(2\)](#)

Version V-2023.12-SP5-6

Copyright (c) 2025 Synopsys, Inc. All rights reserved.

Man(1) output converted with [man2html](#)