HX-KIOSK-300 Firmware Update Guide

Synthetic sample document for demonstration purposes.

1. Overview

Firmware updates for the HX-KIOSK-300 are installed from the Service Menu. An update takes about 12 minutes and the kiosk is out of service while it runs. Schedule updates outside opening hours.

2. Before you update

1. Check the current version under Service Menu > Firmware > About. Versions below 3.2 must update to 3.2 first.
2. Make sure at least 2 GB of disk space is free. Clear logs from Service Menu > Maintenance if it is not.
3. Confirm the kiosk has a stable network link. An update interrupted by a network drop can fail with error K-7002.
4. Close any open customer session and take the kiosk out of service.

3. Installing the update

1. Open Service Menu > Firmware > Check for updates.
2. Select the offered version and choose Download. The download progress bar fills in about 4 minutes.
3. When the download is verified, choose Install. Do not power off the kiosk or unplug the network cable.
4. The kiosk restarts by itself once or twice. Wait until the attract screen appears.
5. Open Service Menu > Firmware > About and confirm the new version number.
6. Run the reader self test and the printer test print, then return the kiosk to service.

4. Version compatibility

Use the table to check that your peripherals support the version you are installing.

Firmware	Card reader	Touch panel	Notes
3.2	Rev B and later	Rev A and later	Minimum supported version
3.4	Rev B and later	Rev A and later	Adds cash acceptor diagnostics
3.6	Rev C and later	Rev B and later	Rev B readers must be replaced first

5. Rolling back a failed update

Roll back when the kiosk shows error K-7002 twice in a row, or restarts in a loop after an update.

1. Power the kiosk off, then power it on while holding the service key for 10 seconds to open the recovery menu.
2. Choose Restore previous version and confirm. The restore takes about 6 minutes.
3. When the kiosk starts, check the version under About. It should show the version from before the update.
4. Record the failed version and the time in the service ticket, and do not retry the update until level 2 support agrees.

6. Troubleshooting

Download stops at 40 percent. Check the network link and the disk space, then choose Download again. The download resumes from the last verified block.

Checksum error after download. The file is damaged. Choose Delete download, then download again. If it fails a second time, escalate to level 2 support.

Touchscreen unresponsive after the update. Recalibrate from Service Menu > Display > Calibrate. If the touch panel revision is not supported by the new firmware, roll back and replace the panel.