Short overview (A-Z)

The following table contains all error messages of the controller operating system in alphabetical order with the preset error response and – if available – the parameter for setting the error response.

Tip!

If you click on the cross-reference in the first column, you get to the detailed description of the corresponding error response in the following chapter "Cause & possible remedies".

Note!

Error message "Unknown error"

If the "Unknown error xxxx" error message is indicated in the logbook or in C00166, the reason for the missing plain text is that the error texts required have not been downloaded to the controller during the application download.

- This, for instance, is the case if a device module plugged into the controller has not been included in the Engineer project.
- Remedy: Include the device module, recompile and download the project.

hex	dec	Error message	Response (Lenze setting)	Adjustable in
0x0090000c	9437196	Disconnection in the case of par. storage	Error	–
0x007b001a	8060954	Absolute value encoder: Communication error	Error	–
0x006a0000	6946816	General error in the application	Error	–
0x007d0000	8192000	Analog input 1: master current < 4 mA	Error	C00598
0x00750001	7667713	Controller is enabled	Information	–
0x00750003	7667715	Controller in STO state	Information	–
0x007b0047	8060999	Controller: Clamp operation	Information	–
0x00750005	7667717	Controller: Pulse inhibit is active	Information	–
0x007b0035	8060981	Controller: Overload during acceleration phases	Error	–
0x006a0004	6946820	ApplicationTask: Overflow	Error	C02111
0x006a0013	6946835	Application has started	Information	–
0x006a000e	6946830	Application has stopped	Information	–
0x006a0014	6946836	Application has stopped	Information	–
0x008c000c	9175052	Application and device are incompatible	Error	–
0x006a0010	6946832	Faulty application parameter	Error	–
0x007b003f	8060991	A mains phase has failed	Error	–
0x007b002d	8060973	Failure of motor phase U	No response	C00597
0x007b002e	8060974	Failure of motor phase V	No response	C00597
0x007b002f	8060975	Failure of motor phase W	No response	C00597
0x00b8000c	12058636	Acceleration has been limited	Information	C02716/3
0x00910012	9502738	Block function in wrong MEC task	Error	–
0x006a000f	6946831	Breakpoint reached	Information	–
0x007b0040	8060992	Brake chopper: Ixt > C00570	Warning	C00569
0x007b001c	8060956	Brake transistor: Ixt overload	No response	C00573
0x007b0021	8060961	Brake transistor: Overcurrent	Error	–
0x007b0041	8060993	Brake resistor: I2t > C00572	Warning	C00571
0x007b001d	8060957	Brake resistor: I^2xt overload	Information	–
0x00b80014	12058644	Cam Data is corrupted	Warning locked	–
0x00b80016	12058646	Cam Data locked due to wrong password	Warning locked	–

0x00b80017	12058647	Cam Data locked due to wrong security key	Warning locked	–
0x00b80015	12058645	Cam Data restored	Error	–
0x00b80013	12058643	Cam data: serial number MM does not match	Warning locked	–
0x00b80034	12058676	Cam Data: Invalidated (due to change of mechanical data)	Warning	–
0x00b80035	12058677	Cam Data: Invalid product number	Information	–
0x00870008	8847368	CAN on board PDO manager: faulty configuration	Warning locked	–
0x00870000	8847360	CAN on board RPDO1: Telegram not received or faulty	No response	C00591/1
0x00870001	8847361	CAN on board RPDO2: Telegram not received or faulty	No response	C00591/2
0x00870002	8847362	CAN on board RPDO3: Telegram not received or faulty	No response	C00591/3
0x00870003	8847363	CAN on board RPDO4: Telegram not received or faulty	No response	C00591/4
0x00890000	8978432	CAN on board SDO client: Faulty configuration	Warning locked	–
0x00880000	8912896	CAN on board SDO server: Faulty configuration	Warning locked	–
0x00830002	8585218	CAN on board: Basic configuration invalid	Warning locked	–
0x00830000	8585216	CAN on board: Bus off	No response	C00595
0x00850000	8716288	CAN on board: Faulty emergency configuration	Warning locked	–
0x00840000	8650752	CAN on board: Heartbeat error index 1 ... 32	No response	C00613/1...32
0x00840020	8650784	CAN on board: Lifeguarding error	No response	C00614
0x00860020	8781856	CAN on board: Faulty NMT master configuration	Warning locked	–
0x00840021	8650785	CAN on board: Faulty NMT slave configuration	Warning locked	–
0x00860000	8781824	CAN on board: Node guarding error 1 ... 32	No response	C00612/1...32
0x00830001	8585217	CAN on board: Invalid node address 0	Warning	–
0x00a10008	10551304	CAN module (MXI1) PDO manager: Faulty configuration	Warning locked	–
0x00a10000	10551296	CAN module (MXI1) RPDO1: Telegram not received or faulty	No response	C13591/1
0x00a10001	10551297	CAN module (MXI1) RPDO2: Telegram not received or faulty	No response	C13591/2
0x00a10002	10551298	CAN module (MXI1) RPDO3: Telegram not received or faulty	No response	C13591/3
0x00a10003	10551299	CAN module (MXI1) RPDO4: Telegram not received or faulty	No response	C13591/4
0x00a10004	10551300	CAN module (MXI1) RPDO5: Telegram not received or faulty	No response	C13591/5
0x00a10005	10551301	CAN module (MXI1) RPDO6: Telegram not received or faulty	No response	C13591/6
0x00a10006	10551302	CAN module (MXI1) RPDO7: Telegram not received or faulty	No response	C13591/7
0x00a10007	10551303	CAN module (MXI1) RPDO8: Telegram not received or faulty	No response	C13591/8
0x00a30000	10682368	CAN module (MXI1) SDO client: faulty configuration	Warning locked	–
0x00a20000	10616832	CAN module (MXI1) SDO server: faulty configuration	Warning locked	–
0x009d0000	10289152	CAN module (MXI1): Bus off	Information	C13595
0x009f0000	10420224	Can module (MXI1): Faulty emergency configuration	Warning locked	–
0x009e0021	10354721	CAN module (MXI1): Faulty NMT slave configuration	Warning locked	–
0x009d0002	10289154	CAN module (MXI1): Basic configuration invalid	Warning locked	–
0x009e0000	10354688	CAN module (MXI1): Heartbeat error index 1 ... 32	No response	C13613/1...32
0x009e0020	10354720	CAN module (MXI1): Lifeguarding error	No response	C13614
0x00a00020	10485792	CAN module (MXI1): Faulty NMT master configuration	Warning locked	–
0x00a00000	10485760	CAN module (MXI1): node guarding error 1 ... 32	No response	C13612/1...32
0x009d0001	10289153	CAN module (MXI1): Invalid node address 0	Warning	–
0x00b00008	11534344	CAN module (MXI2) PDO manager: Faulty configuration	Warning locked	–
0x00b00000	11534336	CAN module (MXI2) RPDO1: Telegram not received or faulty	No response	C14591/1
0x00b00001	11534337	CAN module (MXI2) RPDO2: Telegram not received or faulty	No response	C14591/2
0x00b00002	11534338	CAN module (MXI2) RPDO3: Telegram not received or faulty	No response	C14591/3
0x00b00003	11534339	CAN module (MXI2) RPDO4: Telegram not received or faulty	No response	C14591/4
0x00b00004	11534340	CAN module (MXI2) RPDO5: Telegram not received or faulty	No response	C14591/5
0x00b00005	11534341	CAN module (MXI2) RPDO6: Telegram not received or faulty	No response	C14591/6
0x00b00006	11534342	CAN module (MXI2) RPDO7: Telegram not received or faulty	No response	C14591/7
0x00b00007	11534343	CAN module (MXI2) RPDO8: Telegram not received or faulty	No response	C14591/8
0x00b20000	11665408	CAN module (MXI2) SDO client: faulty configuration	Warning locked	–
0x00b10000	11599872	CAN module (MXI2) SDO server: faulty configuration	Warning locked	–
0x00ac0000	11272192	CAN module (MXI2): Bus off	Information	C14595
0x00ae0000	11403264	Can module (MXI2): Faulty emergency configuration	Warning locked	–

	11272194	CAN module (MXI2): Basic configuration invalid	Warning locked	-
0x00ad0000	11337728	CAN module (MXI2): Heartbeat error index 1 ... 32	No response	C14613/1...32
0x00ad0020	11337760	CAN module (MXI2): Lifeguarding error	No response	C14614
0x00af0020	11468832	CAN module (MXI2): NMT master configuration incomplete	Warning locked	-
0x00ad0021	11337761	CAN module (MXI2): NMT slave configuration incomplete	Warning locked	-
0x00af0000	11468800	CAN module (MXI2): Node guarding error 1 ... 32	No response	C14612/1...32
0x00ac0001	11272193	CAN module (MXI2): Invalid node address 0	Warning	-
0x00900008	9437192	Code number duplicated	Warning locked	-
0x00690000	6881280	Code refresh	System fault	-
0x008c001a	9175066	ConnectTable active	Information	-
0x00770008	7798792	CPU: Temperature > C00126	No response	C00589
0x0077000e	7798798	CPU: thermal detector is defective	Error	C00588
0x00770009	7798793	CPU: Overtemperature	Warning	-
0x008c0002	9175042	File DeviceCFG.dat is defective	Error	-
0x008c0005	9175045	File DeviceCFG.dat is missing	Error	-
0x008c0008	9175048	File DeviceCFG.dat is invalid	Error	-
0x008c0001	9175041	File ProjectList.dat is defective	Error	-
0x008c0004	9175044	File ProjectList.dat is missing	Error	-
0x008c0007	9175047	File ProjectList.dat is invalid	Error	-
0x008c0000	9175040	File ProjectSelection.dat is defective	Error	-
0x008c0003	9175043	File ProjectSelection.dat is missing	Error	-
0x008c0006	9175046	File ProjectSelection.dat is invalid	Error	-
0x00990003	10027011	DFIN (MXI1): Signal error enable/lamp control	Warning	C13041
0x00990000	10027008	DFIN (MXI1): Track error A-/A	Error	C13040
0x00990001	10027009	DFIN (MXI1): Track error B-/B	Error	C13040
0x00990002	10027010	DFIN (MXI1): Track error Z-/Z	Error	C13040
0x00990004	10027012	DFIN (MXI1): Supply cannot be corrected anymore	Warning	C13042
0x00aa0003	11141123	DFIN (MXI2): Signal error enable/lamp control	Warning	C14041
0x00aa0000	11141120	DFIN (MXI2): Track error A-/A	Error	C14040
0x00aa0001	11141121	DFIN (MXI2): Track error B-/B	Error	C14040
0x00aa0002	11141122	DFIN (MXI2): Track error Z-/Z	Error	C14040
0x00aa0004	11141124	DFIN (MXI2): Supply cannot be corrected anymore	Warning	C14042
0x00990005	10027013	DFOUT (MXI1): Maximum frequency reached	Warning	C13080
0x00aa0005	11141125	DFOUT (MXI2): Maximum frequency reached	Warning	C14080
0x006a0011	6946833	Division by zero	Error	-
0x006a0001	6946817	Faulty program download	Error	-
0x007b0012	8060946	Actual speed value outside tolerance (C00576)	No response	C00579
0x00680022	6815778	Real-time clock is defective	Warning locked	-
0x00680024	6815780	Real-time clock: No battery, time lost	Warning locked	-
0x00680023	6815779	Real-time clock: Change battery	Warning locked	-
0x007b0039	8060985	Electronic nameplate: Data outside parameter limits	Information	-
0x007b0030	8060976	Electronic nameplate: Data loaded	Information	-
0x0078000a	7864330	Electronic nameplate: Data are incompatible	Information	-
0x007b0032	8060978	Electronic nameplate: Encoder protocol unknown	Information	-
0x007b0033	8060979	Electronic nameplate: Encoder signal unknown	Information	-
0x0068001b	6815771	Electronic nameplate: Communication error	Warning	-
0x007b0031	8060977	Electronic nameplate: Not found	Information	-
0x0068001d	6815773	Electronic nameplate: Checksum error	Warning	-
0x007b001b	8060955	Encoder: Open circuit	Error	C00580
0x007b002c	8060972	EnDat encoder: Battery empty	Information	-
0x007b004f	8061007	EnDat encoder: Command error	Information	-
0x007b0026	8060966	EnDat encoder: Lamp error	Information	-
0x007b0050	8061008	EnDat encoder: Initial position error	Information	-
0x007b0028	8060968	EnDat encoder: Position error	Information	-

	8060967	EnDat encoder: Signal error	Information	–
0x007b0029	8060969	EnDat encoder: Overvoltage	Information	–
0x007b002b	8060971	EnDat encoder: Overcurrent	Information	–
0x007b004e	8061006	EnDat encoder: Transmission error	Information	–
0x007b002a	8060970	EnDat encoder: Undervoltage	Information	–
0x007b0011	8060945	Earth fault detected	Error	–
0x008c000b	9175051	Required license missing	Error	–
0x00750000	7667712	External error	Error	C00581
0x00680013	6815763	Incorrect safety module	System fault	–
0x00680012	6815762	Incorrect memory module	System fault	–
0x006a0002	6946818	Error during the update of inputs and outputs	Error	–
0x006a0017	6946839	Error in control configuration	System fault	–
0x00910011	9502737	Error during initialisation	System fault	–
0x0068001e	6815774	Firmware incompatible to control card	System fault	–
0x0068001a	6815770	Firmware has been changed	Information	–
0x007b003e	8060990	Encoder monitoring: Pulse deviation detected	No response	C00621
0x00780001	7864321	Device utilisation Ixt > 100 %	Error	–
0x00780000	7864320	Device utilisation Ixt > C00123	Warning	C00604
0x00790000	7929856	Incorrect device command transfer	System fault	–
0x00770011	7798801	Inside the device: fan is defective	Error	C00611
0x0077000b	7798795	Inside the device: thermal detector is defective	Error	C00588
0x00b8000b	12058635	Speed has been limited	Information	C02716/3
0x00910003	9502723	Heartbeat not periodic	System fault	–
0x007b003b	8060987	Hiperface encoder: Command error	Information	–
0x007b003c	8060988	Hiperface encoder: Unknown encoder	Information	–
0x007b003d	8060989	Hiperface encoder: Initial position error	Information	–
0x007b003a	8060986	Hiperface encoder: Transmission error	Information	–
0x006a0006	6946822	IdleTask: Overflow	Error	–
0x00b8001a	12058650	Int. overflow C02620 (manual jog: speed 1)	Error	–
0x00b8001b	12058651	Int. overflow C02621 (manual jog: speed 2)	Error	–
0x00b8001c	12058652	Int. overflow C02622 (manual jog: acc.)	Error	–
0x00b8001d	12058653	Int. overflow C02623 (manual jog: dec.)	Error	–
0x00b8002d	12058669	Int. overflow C02642 (home position)	Error	–
0x00b8002e	12058670	Int. overflow C02643 (homing: target position)	Error	–
0x00b8002f	12058671	Int. overflow C02644 (homing: speed 1)	Error	–
0x00b80030	12058672	Int. overflow C02645 (homing: acceleration 1)	Error	–
0x00b80031	12058673	Int. overflow C02646 (homing: speed 2)	Error	–
0x00b80032	12058674	Int. overflow C02647 (homing: acceleration 2)	Error	–
0x00b80033	12058675	Int. overflow C02670 (positioner: tol. for target position)	Error	–
0x00b80020	12058656	Int. overflow C02701/1 (positive software limit pos.)	Error	–
0x00b80021	12058657	Int. overflow C02701/2 (negative software limit pos.)	Error	–
0x00b80022	12058658	Int. overflow C02703 (maximum speed)	Error	–
0x00b80023	12058659	Int. overflow C02705 (maximum acceleration)	Error	–
0x00b80028	12058664	Int. overflow C02708/1 (decel. limited speed 1)	Error	–
0x00b80024	12058660	Int. overflow C02708/1 (limited speed 1)	Error	–
0x00b80029	12058665	Int. overflow C02708/2 (decel. limited speed 2)	Error	–
0x00b80025	12058661	Int. overflow C02708/2 (limited speed 2)	Error	–
0x00b8002a	12058666	Int. overflow C02708/3 (decel. limited speed 3)	Error	–
0x00b80026	12058662	Int. overflow C02708/3 (limited speed 3)	Error	–
0x00b8002b	12058667	Int. overflow C02708/4 (decel. limited speed 4)	Error	–
0x00b80027	12058663	Int. overflow C02708/4 (limited speed 4)	Error	–
0x00b8002c	12058668	Int. overflow C02713 (max. dist. manual control)	Error	–
0x008c001d	9175069	Internal error (CRC application)	Error	–
0x00690009	6881289	Internal error (event mechanism)	System fault	–

	6881290	Internal error (event mechanism)	System fault	–
0x00690002	6881282	Internal error (LDS instance data)	System fault	–
0x00690003	6881283	Internal error (LDS tasks)	System fault	–
0x0069000d	6881293	Internal error (file system lifetime)	Warning	–
0x00690007	6881287	Internal error (message queue)	System fault	–
0x00690006	6881286	Internal error (message memory)	System fault	–
0x00690008	6881288	Internal error (name database)	System fault	–
0x0069000b	6881291	Internal error (semaphores)	System fault	–
0x0069000c	6881292	Internal error (semaphores)	System fault	–
0x00690001	6881281	Internal error (memory area – logbook)	System fault	–
0x00690004	6881284	Internal error (memory blocks)	System fault	–
0x00690005	6881285	Internal error (task queue)	System fault	–
0x00910004	9502724	Internal error: See C00180	System fault	–
0x00910005	9502725	Internal error: See C00180	System fault	–
0x00910006	9502726	Internal error: See C00180	System fault	–
0x00910008	9502728	Internal error: See C00180	Error	–
0x00910009	9502729	Internal error: See C00180	Error	–
0x007b0034	8060980	Internal communication error (DMA)	System fault	–
0x007b0014	8060948	Internal communication error (host MCTRL)	System fault	–
0x007b0036	8060982	Internal communication error (MCTRL host)	System fault	–
0x00910002	9502722	No heartbeat signal detected	System fault	–
0x0090000a	9437194	No parameters for module in MXI1	Error	C00615/2
0x0090000b	9437195	No parameters for module in MXI2	Error	C00615/3
0x00680019	6815769	Combination MXI1/MXI2 not possible	System fault	–
0x0068001f	6815775	Combination of memory module/device not possible	System fault	–
0x00680020	6815776	Combination of module in MXI1/device not possible	System fault	–
0x00680021	6815777	Combination of module in MXI2/device not possible	System fault	–
0x007f0003	8323075	Communication with module in MXI1 interrupted	Information	–
0x007f0004	8323076	Communication with module in MXI2 interrupted	Information	–
0x00920001	9568257	Communication with safety module interrupted	Information	–
0x007f0002	8323074	Communication error between device and device module	No response	C01501
0x0091000e	9502734	Communication task: standstill > 3 s	Error	C01230
0x00770010	7798800	Heatsink: fan is defective	Error	C00610
0x00770000	7798784	Heatsink: temperature > C00122	Warning	C00582
0x0077000a	7798794	Heatsink: thermal detector is defective	Error	C00588
0x00770001	7798785	Heatsink: Overtemperature	Error	–
0x007b0023	8060963	Load encoder: Module selected in C00490 is not available	Error	–
0x006a000d	6946829	Run-time error	Error	–
0x0068000f	6815759	Power section incompatible	System fault	–
0x00680001	6815745	Power section is defective	System fault	–
0x00680009	6815753	Power section is defective	System fault	–
0x007b0042	8060994	Power section is defective	System fault	–
0x00680014	6815764	Power section has been changed	Information or warning locked if the hardware type has also changed.	–
0x00900001	9437185	Lenze setting loaded	Information	–
0x00900004	9437188	Loading of Lenze setting failed	Error	–
0x00720000	7471104	Read error service register	Error	–
0x00650001	6619137	Logbook: Reset (read error)	Information	–
0x00650002	6619138	Logbook: Reset (version error)	Information	–
0x00650000	6619136	Logbook: Overflow	Information	–
0x00b80010	12058640	Maximum speed exceeded	Information	C02716/3
0x00b80011	12058641	Maximum acceleration exceeded	Information	C02716/3
0x007b004c	8061004	Motor disconnected	No response	C00597

0x007b0007	8060935	Motor: rated current < rated magnetisation current	Information	–
0x007b0002	8060930	Motor: Calculated mutual inductance unrealistic	Information	–
0x007b000a	8060938	Motor: Calculated mutual inductance unrealistic	Information	–
0x007b0001	8060929	Motor: Calculated motor impedance unrealistic	Information	–
0x007b000c	8060940	Motor: Calculated rotor time constant unrealistic	Information	–
0x007b0019	8060953	Motor: Calculated leakage inductance unrealistic	Information	–
0x007b000b	8060939	Motor: Calculated e.m.f. factor unrealistic	Information	–
0x007b000d	8060941	Motor: Calculated flux factor unrealistic	Information	–
0x007b0009	8060937	Motor: Calculated rotor resistance unrealistic	Information	–
0x007b0020	8060960	Motor: actual speed > C00596	Error	C00607
0x007b0006	8060934	Motor: Device current too low for rated magnetisation	Information	–
0x007b0004	8060932	Motor: Phase resistance too high	Information	–
0x0077000f	7798799	Motor: PTC has triggered	No response	C00585
0x007b001e	8060958	Motor: actual current > C00620	Error	C00619
0x00770002	7798786	Motor: temperature > C00121	Warning	C00584
0x0077000c	7798796	Motor: thermal detector is defective	Error	C00594
0x00770003	7798787	Motor: Overtemperature	Error	C00583
0x00780003	7864323	Motor load I^2xt > C00120	Error	–
0x00780002	7864322	Motor load I^2xt > C00127	Warning	C00606
0x00b80004	12058628	Motor brake: Autom. activated after waiting time has elapsed	Information	–
0x00b80005	12058629	Motor brake: Status monitoring error	Quick stop by trouble	–
0x00b80003	12058627	Motor brake: Angular drift with closed brake too high	Quick stop by trouble	–
0x007b0003	8060931	Motor data are inconsistent	Information	–
0x007b0017	8060951	Motor data are inconsistent	Information	–
0x007b0024	8060964	Motor encoder: Module selected in C00495 is not available	Error	–
0x007b0038	8060984	Motor parameter identification cancelled	Error	–
0x007b0013	8060947	Motor control: Task overflow	System fault	–
0x007b0025	8060965	Motor temperature: Module selected in C01193 is not available	Error	–
0x008c0017	9175063	MXI1: CAN module is missing or incompatible	Error	C00615/2
0x008c0011	9175057	MXI1: Ethernet module is missing or incompatible	Error	C00615/2
0x00680010	6815760	MXI1: Wrong module	System fault	–
0x008c0015	9175061	MXI1: ICM module is missing or incompatible	Error	C00615/2
0x008c0013	9175059	MXI1: Digital frequency module is missing or incompatible	Error	C00615/2
0x008c000d	9175053	MXI1: Module is missing or incompatible	Error	–
0x0068000a	6815754	MXI1: Module is defective or missing	Error	–
0x00680004	6815748	MXI1: Module changed during operation	Warning locked	–
0x00680015	6815765	MXI1: Module has been changed	Information or warning locked if the hardware type has also changed.	–
0x008c000f	9175055	MXI1: PROFIBUS module is missing or incompatible	Error	C00615/2
0x008c0018	9175064	MXI2: CAN module is missing or incompatible	Error	C00615/3
0x008c0012	9175058	MXI2: Ethernet module is missing or incompatible	Error	C00615/3
0x00680011	6815761	MXI2: Wrong module	System fault	–
0x008c0016	9175062	MXI2: ICM module is missing or incompatible	Error	C00615/3
0x008c0014	9175060	MXI2: Digital frequency module is missing or incompatible	Error	C00615/3
0x008c000e	9175054	MXI2: Module is missing or incompatible	Error	–
0x0068000b	6815755	MXI2: Module is defective or missing	System fault	–
0x00680005	6815749	MXI2: Module changed during operation	Warning locked	–
0x00680016	6815766	MXI2: Module has been changed	Information or warning locked if the hardware type has also changed.	–
0x008c0010	9175056	MXI2: PROFIBUS module is missing or incompatible	Error	C00615/3
0x00b8000a	12058634	Negative direction of rotation limited	Information	C02716/1
0x00b80002	12058626	Negative limit switch has triggered	Quick stop by trouble	–
0x00b80008	12058632	Negative software limit switch overtravelled	Quick stop by trouble	C02716/2

0x00910001	9502721	Mains voltage is switched off	Information	–
0x00910000	9502720	Mains voltage is switched on	Information	–
0x006a0003	6946819	New applications loaded	Information	–
0x00900006	9437190	Saving of parameters failed	Error	–
0x00900000	9437184	Parameter set faulty	Error	–
0x00900003	9437187	Parameter set loaded	Information	–
0x00900002	9437186	Parameter set saved	Information	–
0x00900005	9437189	Parameter set restored	Error	–
0x00900009	9437193	Parameter set: type of standard device has been changed	Information	–
0x00900007	9437191	Parameter set: Version conflict	Error	–
0x006a0015	6946837	PDO mapping (MXI1): Faulty configuration	Error	–
0x006a0016	6946838	PDO mapping (MXI2): Faulty configuration	Error	–
0x007b004a	8061002	Pole position identification cancelled	Error	C00640
0x00910010	9502736	Position value faulty	Error	–
0x00b8000f	12058639	Position target outside the software limit positions	Quick stop by trouble	C02716/2
0x00b80009	12058633	Positive direction of rotation limited	Information	C02716/1
0x00b80001	12058625	Positive limit switch has triggered	Quick stop by trouble	–
0x00b80007	12058631	Positive software limit switch overtravelled	Quick stop by trouble	C02716/2
0x008c0009	9175049	Project not loaded	Error	–
0x008c000a	9175050	Project not available	Error	–
0x00b80019	12058649	Homing mode not allowed	Error	–
0x007b001f	8060959	Resolver: Calculated acceleration unrealistic	Information	–
0x007b0018	8060952	Resolver: Open circuit	Error	–
0x006a001a	6946842	Retain memory of the application faulty	Error	–
0x00b8000e	12058638	Jerk has been limited	Information	C02716/3
0x00680003	6815747	Safety module is defective or missing	System fault	–
0x0068000d	6815757	Safety module is defective or missing	System fault	–
0x00680007	6815751	Safety module has been removed	System fault	–
0x00680018	6815768	Safety module has been changed	Information or warning locked if the hardware type has also changed.	–
0x00920000	9568256	Safety module: Incompatible with setting in C00214	System fault	–
0x00650003	6619139	Memory module missing	Information	–
0x00680002	6815746	Memory module is defective or missing	Error	–
0x0068000c	6815756	Memory module is defective or missing	System fault	–
0x00680006	6815750	Memory module has been removed	System fault	–
0x00680017	6815767	Memory module has been changed	Information or warning locked if the hardware type has also changed.	–
0x0068001c	6815772	Memory module: Faulty file system	Error	–
0x007c0000	8126464	Memory module: file system has been formatted	Information	–
0x007c0001	8126465	Memory module: File system has been restored	Information	–
0x008c001e	9175070	Storage capacity for user parameters exceeded	Error	–
0x00b80000	12058624	PLC configuration invalid	Error	–
0x007d0001	8192001	PLC configuration invalid	Error	–
0x007b0037	8060983	PLC configuration invalid	Error	–
0x00750006	7667718	PLC configuration invalid	Error	–
0x0068000e	6815758	Control card incompatible	System fault	–
0x00680000	6815744	Control card is defective	System fault	–
0x00680008	6815752	Control card is defective	System fault	–
0x00780008	7864328	Control card is defective (UB18 neg.)	System fault	–
0x00780004	7864324	Control card is defective (UB24)	System fault	–
0x00780006	7864326	Control card is defective (UB8)	System fault	–
0x00780007	7864327	Control card is defective (VCC15 neg.)	System fault	–
0x00780005	7864325	Control card is defective (VCC15)	System fault	–

0x00780009	7864329	Control card is defective (VCC5)	System fault	-
0x006f0000	7274496	Control card: Supply voltage (24 V DC) too low	Fault	-
0x0091000a	9502730	System task 1: Task overflow	System fault	-
0x0091000b	9502731	System task 2: Task overflow	Information	-
0x0091000c	9502732	System task 3: Task overflow	System fault	-
0x0091000d	9502733	System task: Task overflow	Error	-
0x00b80012	12058642	Time-out torque feedforward control brake	Quick stop by trouble	-
0x007b0010	8060944	Overcurrent detected	Error	-
0x006a0005	6946821	UserTask: Overflow	Error	C02111
0x00790002	7929858	Violation of time slice	Error	-
0x00b8000d	12058637	Deceleration has been limited	Information	C02716/3
0x006a001b	6946843	Watchdog cycle is greater than task cycle	Error	-
0x006a0012	6946834	Pointer access in impermissible memory area	Error	-
0x00790001	7929857	Time error - controller interface	System fault	-
0x0077000d	7798797	DC-bus capacitor: thermal detector is defective	Error	C00588
0x007b000e	8060942	DC-bus overvoltage	Fault	C00600
0x007b000f	8060943	DC-bus undervoltage	Fault	-
0x0091000f	9502735	Cyclical task: standstill > 60 s	Information	-