Sync 3 Reset Instructions

Use these steps for a frozen or unresponsive system. Start with a soft reset. If the issue remains and you can use the Settings menu, try a master reset. A reset that does not help does not prove the hardware has failed.

Park safely before starting. If the engine is running, keep the vehicle outdoors. Do not perform these steps while driving.

1 / Soft reset - keeps your saved settings

Press and hold the radio **Power** and **Seek Up / Next Track** buttons together until the display goes black, then release. Allow the system time to restart (about 1-2 minutes). If the controls or behavior do not match, stop and contact us.

2 / Master reset - erases saved information

This deletes paired phones and personal settings. Note any saved information you need first and disconnect USB devices. If the screen is black or touch does not work, do not attempt to navigate the menu blindly. Tell us you cannot access it.

1. Select **Settings** on the bottom feature bar, then **General**.
2. Scroll to **Master Reset** and select it.
3. Review the warning and select **Continue** if you are ready to erase your saved information.
4. Wait for the reset and restart to finish. This can take several minutes. Pair your phone again and restore your preferences.

If the issue remains

Record whether the reset helped, made no difference, or helped only temporarily. Contact us with the vehicle year/model and your results.

Battery or APIM connector disconnection: contact us for vehicle-specific guidance before attempting a power-disconnection reset. Do not disconnect the battery or 54-pin APIM connector as a routine next step from this guide.

Need help?

simplymichigan.co/contact-us | nick@simplymichigan.co

Reference: Ford Sync 3 guidance. Menu appearance may vary by vehicle and software.