SEUSSICAL Board Operator Show Track

NOTES			House will go dark-warn appropiate parties.		Switch located by stage door.	Chan 1 @ FL Chan Check (softkey 5).	Group 999 @ FL		Check to make sure they can move, and intensity/iris can be controlled.		Cue 0.2		Cue 0.4		Submaster 1			Switch located by stage door.	House will go dark-warn appropiate parties.	3 switches on wall by curtain. From L to R, down, up, up.	Save to hard drive and potentially an external flash drive.	Don't forget the dust cover!	
IN CONJUNCTION WITH	UPON ARRIVAL									WHEN SM READY	Stage Manager	BEFORE HOUSE OPENS		END OF NIGHT									Stage Manager
WHERE		Board	Backstage SR	Backstage SR	Backstage SL	Board	Board	Spots	Spots		Board		Board		Board	Board	Spots	Backstage SL	Backstage SR	Backstage SR	Board	Board	House
WHAT		Power ON Console	Turn House Lights to DIMMER Position	Turn ON Company Switches	Turn OFF Work Lights	Channel Check	Stars Check	Turn ON Spotlights	Spotlight Check		Blackout Check		Go To Preshow Look		Turn ON House Lights	Go To Cue Out	Turn OFF Spotlights	Turn ON Work Lights	Turn OFF Company Switch	Turn House Lights To ON Position	Save the Show File	Power OFF Board	Check in wth teams