656. The space between the liquid level line to the inside top cover of the septic tank is called:

(a) Air space

(c) Overflow

(b) Freeboard

(d) Ventilation space

656. The space between the liquid level line to the inside top cover of the septic tank is called:

(a) Air space

(c) Overflow

(b) Freeboard

(d) Ventilation space