

[illegible]

This is the USB ESP32 programmer used to flash ESP32 boards via UART. Boot & Enable options are available in ESP32 uC documentation.

Test Pins

PWR References