Press the red emergency button to stop the conveyor immediately. The button is located on the left side of the control panel and is clearly marked in red. Operators must be trained before using the conveyor system on any shift.

Maintenance staff must inspect the guard rails every Monday morning and record any damage in the logbook kept beside the main entrance.

Installation begins by mounting the bracket on a flat wall surface using the four screws supplied in the box.

Connect the power cable only after the bracket screws are tightened. Never connect power while the cover is open, and always check that the fuse rating matches the label on the rear panel of the unit.