

Logix 5000 Controllers Structured Text

1756 ControlLogix, 1756 GuardLogix, 1769 CompactLogix, 1769 Compact GuardLogix, 1789 SoftLogix, 5069 CompactLogix, 5069 Compact GuardLogix, Studio 5000 Logix Emulate














Important user information

Read this document and the documents listed in the additional resources section about installation, configuration, and operation of this equipment before you install, configure, operate, or maintain this product. Users are required to familiarize themselves with installation and wiring instructions in addition to requirements of all applicable codes, laws, and standards.

Activities including installation, adjustments, putting into service, use, assembly, disassembly, and maintenance are required to be carried out by suitably trained personnel in accordance with applicable code of practice. If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited.

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.



WARNING: Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.



ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequence

Important:

Identifies information that is critical for successful application and understanding of the product.

Labels may also be on or inside the equipment to provide specific precautions.



SHOCK HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.



BURN HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.



ARC FLASH HAZARD: Labels may be on or inside the equipment, for example, a motor control center, to alert people to potential Arc Flash. Arc Flash will cause severe injury or death. Wear proper Personal Protective Equipment (PPE). Follow ALL Regulatory requirements for safe work practices and for Personal Protective Equipment (PPE).

Allen-Bradley, Rockwell Software, Rockwell Automation, and TechConnect are trademarks of Rockwell Automation, Inc.

 $Trademarks \ not \ belonging \ to \ Rockwell \ Automation \ are \ property \ of \ their \ respective \ companies.$

This manual includes new and updated information. Use these reference tables to locate changed information.

Grammatical and editorial style changes are not included in this summary.

Global changes

This table identifies changes that apply to all information about a subject in the manual and the reason for the change. For example, the addition of new supported hardware, a software design change, or additional reference material would result in changes to all of the topics that deal with that subject.

Subject	Reason
Throughout	Updates made to align with corresponding online help topics

Table of contents

Preface	Studio 5000 environment	8
	Legal Notices Chapter 1	δ
Program Structured Text	Structured Text Syntax	11
_	Structured Text Components: Assignments	
	Specify a non-retentive assignment	
	Assign an ASCII character to a string data member	15
	Character string literals	15
	Structured Text Components: Expressions	17
	Use arithmetic operators and functions	18
	Use relational operators	20
	Use logical operators	21
	Use bitwise operators	22
	Determine the order of execution	23
	Structured Text Components: Instructions	23
	Structured Text Components: Constructs	25
	IF_THEN	25
	CASE_OF	28
	FOR_DO	31
	WHILE_DO	34
	REPEAT_UNTIL	
	Structured Text Components: Comments	39
Index	-	

This manual shows how to program Logix 5000 controllers with structured text programming language.

This manual is one of a set of related manuals that show common procedures for programming and operating Logix 5000 controllers.

For a complete list of common procedures manuals, refer to the <u>Logix 5000</u> Controllers Common Procedures Programming Manual, publication 1756-PM001.

The term Logix 5000 controller refers to any controller based on the Logix 5000 operating system.

Studio 5000 environment

The Studio 5000 Automation Engineering & Design Environment® combines engineering and design elements into a common environment. The first element is the Studio 5000 Logix Designer® application. The Logix Designer application is the rebranding of RSLogix 5000® software and will continue to be the product to program Logix 5000™ controllers for discrete, process, batch, motion, safety, and drive-based solutions.



The Studio 5000° environment is the foundation for the future of Rockwell Automation° engineering design tools and capabilities. The Studio 5000 environment is the one place for design engineers to develop all elements of their control system.

Additional resources

These documents contain additional information concerning related Rockwell Automation products.

Resource	Description
LOGIX 5000 Controllers Program Parameters Programming Manual publication 1756-PM021	Describes how to use program parameters when programming Logix 5000 controllers.
LOGIX 5000 Controllers General Instructions Reference Manual , publication 1756-RM003	Describes the available instructions for a Logix 5000 controller.
LOGIX 5000 Controllers Process and Drives Instructions Reference Manual, publication 1756-RM006	Describes how to program a Logix 5000 controller for process or drives applications.
LOGIX 5000 Controllers Motion Instruction Set Reference Manual , publication MOTION-RM002	Describes how to program a Logix 5000 controller for motion applications.
Product Certifications website, http://ab.rockwellautomation.com	Provides declarations of conformity, certificates, and other certification details.

You can view or download publications at

<u>http://www.rockwellautomation.com/literature</u>
. To order paper copies of technical documentation, contact your local Rockwell Automation distributor or sales representative.

Legal Notices

Copyright Notice

Copyright © 2018 Rockwell Automation Technologies, Inc. All Rights Reserved. Printed in USA.

This document and any accompanying Rockwell Software products are copyrighted by Rockwell Automation Technologies, Inc. Any reproduction and/or distribution without prior written consent from Rockwell Automation Technologies, Inc. is strictly prohibited. Please refer to the license agreement for details.

End User License Agreement (EULA)

You can view the Rockwell Automation End-User License Agreement ("EULA") by opening the License.rtf file located in your product's install folder on your hard drive.

Open source licenses

The software included in this product contains copyrighted software that is licensed under one or more open source licenses. Copies of those licenses are

included with the software. Corresponding Source code for open source packages included in this product are located at their respective web site(s).

Alternately, obtain complete Corresponding Source code by contacting Rockwell Automation via the Contact form on the Rockwell Automation website: http://www.rockwellautomation.com/global/about-us/contact/contact.page Please include "Open Source" as part of the request text.

A full list of all open source software used in this product and their corresponding licenses can be found in the OPENSOURCE folder included with the Release Notes. The default installed location of these licenses is C:\Program Files (x86)\Common

Files\Rockwell\Help\<*Product*>\ReleaseNotes\OPENSOURCE\index.htm.

Trademark Notices

Allen-Bradley, ControlBus, ControlFLASH, Compact GuardLogix, Compact I/O, ControlLogix, CompactLogix, DCM, DH+, Data Highway Plus, DriveLogix, DPI, DriveTools, Explorer, FactoryTalk, FactoryTalk Administration Console, Factory Talk Alarms and Events, Factory Talk Batch, Factory Talk Directory, Factory Talk Security, Factory Talk Services Platform, Factory Talk View, Factory Talk View SE, FLEX Ex, FlexLogix, FLEX I/O, Guard I/O, High Performance Drive, Integrated Architecture, Kinetix, Logix 5000, Logix 5000, Logix5550, MicroLogix, DeviceNet, EtherNet/IP, PLC-2, PLC-3, PLC-5, PanelBuilder, PowerFlex, PhaseManager, POINT I/O, PowerFlex, Rockwell Automation, RSBizWare, Rockwell Software, RSEmulate, Historian, RSFieldbus, RSLinx, RSLogix, RSNetWorx for DeviceNet, RSNetWorx for EtherNet/IP, RSMACC, RSView, RSView32, Rockwell Software Studio 5000 Automation Engineering & Design Environment, Studio 5000 View Designer, SCANport, SLC, SoftLogix, SMC Flex, Studio 5000, Ultra 100, Ultra 200, VersaView, WINtelligent, XM, SequenceManager are trademarks of Rockwell Automation, Inc.

Any Rockwell Automation logo, software or hardware product not mentioned herein is also a trademark, registered or otherwise, of Rockwell Automation, Inc.

Other Trademarks

CmFAS Assistant, CmDongle, CmStick, CodeMeter, CodeMeter Control Center, and WIBU are trademarks of WIBU-SYSTEMS AG in the United States and/or other countries.

All other trademarks are the property of their respective holders and are hereby acknowledged.

Warranty

This product is warranted in accordance with the product license. The product's performance may be affected by system configuration, the application being performed, operator control, maintenance, and other related factors. Rockwell Automation is not responsible for these intervening factors. The instructions in this document do not cover all the details or variations in the equipment, procedure, or process described, nor do they provide directions for meeting every possible contingency during installation, operation, or maintenance. This product's implementation may vary among users.

This document is current as of the time of release of the product; however, the accompanying software may have changed since the release. Rockwell Automation, Inc. reserves the right to change any information contained in this document or the software at any time without prior notice. It is your responsibility to obtain the most current information available from Rockwell when installing or using this product.

Environmental Compliance

Rockwell Automation maintains current product environmental information on its website at

http://www.rockwellautomation.com/rockwellautomation/about-us/sustainability-ethics/product-environmental-compliance.page

Contact Rockwell

Customer Support Telephone — 1.440.646.3434

Online Support — http://www.rockwellautomation.com/support/

Program Structured Text

Structured Text Syntax

Structured text is a textual programming language that uses statements to define what to execute.

- Structured text is not case sensitive.
- Use tabs and carriage returns (separate lines) to make your structured text easier to read. They have no effect on the execution of the structured text.

Structured text is not case sensitive. Structured text can contain these components.

Term	Definition	Examples
Assignment	Use an assignment statement to assign values to tags. The := operator is the assignment operator. Terminate the assignment with a semi colon ';.'	tag := expression;
Expression	An expression is part of a complete assignment or construct statement. An expression evaluates to a number (numerical expression), a String (string expression), or to a true or false state (BOOL expression)	
Tag Expression	A named area of the memory where data is stored (BOOL, SINT, INT, DINT, REAL, String).	value1
Immediate Expression	A constant value	4
Operators Expression	A symbol or mnemonic that specifies an operation within an expression.	tag1 + tag2 tag1 >= value1
Function Expression	When executed, a function yields one value. Use parentheses to contain the operand of a function. Even though their syntax is similar, functions differ from instructions in that functions can be used only in expressions. Instructions cannot be used in expressions.	function(tag1)

Instruction	An instruction is a standalone statement.	instruction();
	An instruction uses parentheses to contain its operands.	instruction(operand);
	Depending on the instruction, there can be zero, one, or multiple operands.	instruction(operand1,
	When executed, an instruction yields one or more values that are part of a data structure. Terminate the instruction with a semi colon(;).	operand2,operand3);
	Even though their syntax is similar, instructions differ from functions in that instructions cannot be used in expressions. Functions can be used only in expressions.	
Construct	A conditional statement used to trigger structured	IFTHEN CASE FORDO WHILEDO
	text code (that is, other statements). Terminate the construct with a semi colon (;).	REPEATUNTIL
	Constitute with a serial colonia (j)	EXIT
Comment	Text that explains or clarifies what a section of structured text does.	//comment
	Use comments to make it easier to interpret the structured text.	(*start of comment end of comment*)
	Comments do not affect the execution of the structured text.	/*start of comment end of comment*/
	Comments can appear anywhere in structured text.	

See also

Structured Text Components: Assignments on page 13

Structured Text Components: Expressions on page 17

Structured Text Components: Instructions on page 23

Structured Text Components: Constructs on page 25

Structured Text Components: Comments on page 39

Structured Text Components: Assignments

Use an assignment to change the value stored within a tag. An assignment has this syntax:

tag := expression;

where:

Component	Description	Description	
Tag	Represents the tag that is getting the new valu STRING, or REAL.	Represents the tag that is getting the new value; the tag must be a BOOL, SINT, INT, DINT, STRING, or REAL.	
	Tip: The STRING tag is applicable to CompactLo Compact GuardLogix 5380, and GuardLogix 5580.	ogix 5380, CompactLogix 5480, ControlLogix 5580, 80 controllers only.	
:=	Is the assignment symbol		
Expression	Represents the new value to assign to the tag		
	If tag is this data type	Use this type of expression	
	BOOL	BOOL	
	SINT INT DINT REAL	Numeric	
	STRING (CompactLogix 5380, CompactLogix 5480, ControlLogix 5580, Compact GuardLogix 5380, and GuardLogix 5580 controllers only).	String type, including string tag and string literal (CompactLogix 5380, CompactLogix 5480, ControlLogix 5580, Compact GuardLogix 5380, and GuardLogix 5580 controllers only).	
;	Ends the assignment		

The tag retains the assigned value until another assignment changes the value.

The expression can be simple, such as an immediate value or another tag name, or the expression can be complex and include several operators and functions, or both. Refer to Expressions for more information.

Tip: I/O module data updates asynchronously to the execution of logic. If you reference an input multiple times in your logic, the input could change state between separate references. If you need the input to have the same state for each reference, buffer the input value and reference that buffer tag. For more information, see Logix 5000 Controllers Common Procedures, publication 1756-PM001.

You can also use Input and Output program parameters which automatically buffer the data during logix execution. See <u>LOGIX 5000 Controllers Program Parameters Programming Manual</u>, publication <u>1756-PM021</u>.

See also

Assign an ASCII character to a string data member on page 15

Specify a non-retentive assignment on page 14

Structured Text Components: Expressions on page 17

Character string literals on page 15

Specify a non-retentive assignment

The non-retentive assignment is different from the regular assignment described above in that the tag in a non-retentive assignment is reset to zero each time the controller:

- Enters the Run mode
- Leaves the step of an SFC if you configure the SFC for Automatic reset.
 This applies only if you embed the assignment in the action of the step or use the action to call a structured text routine by using a JSR instruction.

A non-retentive assignment has this syntax:

tag[:=] expression;

where:

Component	Description		
tag	Represents the tag that is getting the new value; the tag must be a BOOL, SINT, II DINT, STRING, or REAL.		
	Tip: The STRING tag is applicable toCompactLogix 5380, CompactLogix 5480, ControlLogix 5580, Compact GuardLogix 5380, and GuardLogix 5580 controllers only.		
[:=]	Is the non-retentive assignment symbol.		
expression	Represents the new value to assign to th	e tag.	
	If tag is this data type Use this type of exp		
	BOOL	BOOL	
	SINT	Numeric	
	INT		
	DINT		
	REAL		
	STRING (CompactLogix 5380, CompactLogix 5480, ControlLogix 5580, Compact GuardLogix 5380, and GuardLogix 5580 controllers only).	String type, including string tag and string literal CompactLogix 5380, CompactLogix 5480, ControlLogix 5580, Compact GuardLogix 5380, and GuardLogix 5580 controllers(only)	

See also

Assign an ASCII character to a string data member on page 15

Structured Text Components: Assignments on page 13

Assign an ASCII character to a string data member

Assign an ASCII character to a string data member

Use the assignment operator to assign an ASCII character to an element of the DATA member of a string tag. To assign a character, specify the value of the character or specify the tag name, DATA member, and element of the character. For example:

This is OK	This is not OK
string1.DATA[0] := 65;	string1.DATA[0] := A;
string1.DATA[0]:= string2.DATA[0];	string1 := string2; Tip: This assigns all content of string2 to string1 instead of just one character.

To add or insert a string of characters to a string tag, use either of these ASCII string instructions:

То	Use this instruction
Add characters to the end of a string	CONCAT
Insert characters into a string	INSERT

See also

Structured Text Components: Expressions on page 17

Character string literals on page 15

Character string literals

Character string literals include single byte or double byte encoded characters. A single-byte string literal is a sequence of zero or more characters that are prefixed and terminated by the single quote character ('). In single byte character strings, the three-character combination of the dollar sign (\$) followed by two hexadecimal digits is interpreted as the hexadecimal representation of the eight-bit character code as shown in the following table.

Tips:

- Character string literals are only applicable to the CompactLogix 5380, CompactLogix 5480, ControlLogix 5580, Compact GuardLogix 5380, and GuardLogix 5580 controllers.
- Studio 5000 only supports single byte characters.

Character string literals

No.	Description	Example
1a	Empty string (length zero)	п
1b	String of length one or character CHAR containing a single character	'A'
1c	String of length one or character CHAR containing the "space" character	11
1d	String of length one or character CHAR containing the "single quote" character	'\$"
1e	String of length one or character CHAR containing the "double quote" character	IIII
1f	Support of two character combinations	'\$R\$L'
1g	Support of a character representation with '\$' and two hexadecimal characters	'\$0A'

Two-character combinations in character strings

No.	Description	Example
1	Dollar sign	\$\$
2	Single quote	\$'
3	Line feed	\$L or \$I
4	Newline	\$N or \$n
5	Form feed (page)	\$P or \$p
6	Carriage return	\$R or \$r
7	Tabulator	\$T or \$t

Tips:

- The newline character provides an implementation-independent means of defining the end of a line of data for both physical and file I/O; for printing, the effect is that of ending a line of data and resuming printing at the beginning of the next line.
- The \$' combination is only valid inside single quoted string literals.

See also

Structured Text Components: Assignments on page 13

Structured Text Components: Expressions

An expression is a tag name, equation, or comparison. To write an expression, use any of the following:

- Tag name that stores the value (variable)
- Number that you enter directly into the expression (immediate value)
- String literal that you enter directly into the expression (CompactLogix 5380, CompactLogix 5480, ControlLogix 5580, Compact GuardLogix 5380, and GuardLogix 5580 controllers only)
- Functions, such as: ABS, TRUNC
- Operators, such as: +, -, <, >, And, Or

Follow these guidelines for writing expressions:

- Use any combination of upper-case and lower-case letter. For example, these variations of "AND" are acceptable: AND, And, and.
- For more complex requirements, use parentheses to group expressions
 within expressions. This makes the whole expression easier to read, and
 ensures that the expression executes in the desired sequence.

Use these expressions for structured text:

BOOL expression: An expression that produces the BOOL value of 1 (true) or 0 (false).

- A bool expression uses bool tags, relational operators, and logical operators to compare values or check if conditions are true or false. For example, tag1>65.
- A simple bool expression can be a single BOOL tag.
- Typically, use bool expressions to condition the execution of other logic.

Numeric expression: An expression that calculates an integer or floating-point value.

- A numeric expression uses arithmetic operators, arithmetic functions, and bitwise operators. For example, tag1+5.
- Nest a numeric expression within a BOOL expression. For example, (tag1+5)>65.

String expression: An expression that represents a string

• A simple expression can be a string literal or a string tag

Use this table to select the operators for expressions.

If	Use
Calculating an arithmetic value	Arithmetic operators and functions
Comparing two values or strings	Relational operators
Verifying if conditions are true or false	Logical operators
Comparing the bits within values	Bitwise operators

See also

Use arithmetic operators and functions on page 18

Use relational operators on page 20

<u>Use logical operators</u> on page 21

Use bitwise operators on page 22

Use arithmetic operators and functions

Combine multiple operators and functions in arithmetic expressions.

Operators calculate new values.

То	Use this operator	Optimal data type
Add	+	DINT, REAL
Subtract/negate	-	DINT, REAL
Multiply	*	DINT, REAL
Exponent (x to the power of y)	**	DINT, REAL
Divide	1	DINT, REAL
Modulo-divide	MOD	DINT, REAL

Functions perform math operations. Specify a constant, a non-Boolean tag, or an expression for the function.

For	Use this function	Optimal data type
Absolute value	ABS (numeric_expression)	DINT, REAL
Arc cosine	ACOS (numeric_expression)	REAL
Arc sine	ASIN (numeric_expression)	REAL
Arc tangent	ATAN (numeric_expression)	REAL
Cosine	COS (numeric_expression)	REAL
Radians to degrees	DEG (numeric_expression)	DINT, REAL
Natural log	LN (numeric_expression)	REAL
Log base 10	LOG (numeric_expression)	REAL
Degrees to radians	RAD (numeric_expression)	DINT, REAL
Sine	SIN (numeric_expression)	REAL
Square root	SQRT (numeric_expression)	DINT, REAL
Tangent	TAN (numeric_expression)	REAL
Truncate	TRUNC (numeric_expression)	DINT, REAL

The table provides examples for using arithmetic operators and functions.

Use this format	Example		
	For this situation	Write	
value1 operator value2	If gain_4 and gain_4_adj are DINT tags and your specification says:	gain_4_adj := gain_4+15;	
	'Add 15 to gain_4 and store the result in gain_4_adj'"		
operator value1	If alarm and high_alarm are DINT tags and your specification says: 'Negate high_alarm and store the result in alarm.'	alarm:= -high_alarm;	
function(numeric_expression)	If overtravel and overtravel_POS are DINT tags and your specification says: 'Calculate the absolute value of overtravel and store the result in overtravel_POS.'	overtravel_POS := ABS(overtravel);	
value1 operator (function((value2+value3)/2)	If adjustment and position are DINT tags and sensor1 and sensor2 are REAL tags and your specification says: 'Find the absolute value of the average of sensor1 and sensor2, add the adjustment, and store the result in position.'	position := adjustment + ABS((sensor1 + sensor2)/2);	

See also

Structured Text Components: Expressions on page 17

Use relational operators

Relational operators compare two values or strings to provide a true or false result. The result of a relational operation is a BOOL value.

If the comparison is	The result is
True	1
False	0

Use these relational operators.

For this comparison	Use this operator	Optimal data type
Equal	=	DINT, REAL, String type
Less than	<	DINT, REAL, String type
Less than or equal	<=	DINT, REAL, String type
Greater than	>	DINT, REAL, String type
Greater than or equal	>=	DINT, REAL, String type
Not equal	<>	DINT, REAL, String type


The table provides examples of using relational operators

Use this format	Example	
	For this situation	Write
value1 operator value2	If temp is a DINT tag and your specification says: 'If temp is less than 100· then'	IF temp<100 THEN
stringtag1 operator stringtag2	If bar_code and dest are string tags and your specification says: 'If bar_code equals dest then'	IF bar_code=dest THEN
stringtag1 operator 'character string literal'	If bar_code is a string tag and your specification says: 'If bar_code equals 'Test PASSED' then'	IF bar_code='Test PASSED' THEN
char1 operator char2 To enter an ASCII character directly into the expression, enter the decimal value of the character.	If bar_code is a string tag and your specification says: 'If bar_code.DATA[0] equals 'A' then'	IF bar_code.DATA[0]=65 THEN
bool_tag := bool_expressions	If count and length are DINT tags, done is a BOOL tag, and your specification says: 'If count is greater than or equal to length, you are done counting.'	Done := (count >= length);

How strings are evaluated

The hexadecimal values of the ASCII characters determine if one string is less than or greater than another string.

• When the two strings are sorted as in a telephone directory, the order of the strings determines which one is greater.



- Strings are equal if their characters match.
- Characters are case sensitive. Upper case "A" (\$41) is not equal to lower case "a" (\$61).

See also

Structured Text Components: Expressions on page 17

Use logical operators

Use logical operators to verify if multiple conditions are true or false. The result of a logical operation is a BOOL value.

If the comparison is	The result is
true	1
false	0

Use these logical operators.

For this comparison	Use this operator	Optimal data type
logical AND	&, AND	BOOL
logical OR	OR	BOOL
logical exclusive OR	XOR	BOOL
logical complement	NOT	BOOL

The table provides examples of using logical operators.

Use this format	Example	
	For this situation	Use
BOOLtag	If photoeye is a BOOL tag and your specification says: "If photoeye_1 is on then"	IF photoeye THEN
NOT BOOLtag	If photoeye is a BOOL tag and your specification says: "If photoeye is off then"	IF NOT photoeye THEN
expression1 & expression2	If photoeye is a BOOL tag, temp is a DINT tag, and your specification says: "If photoeye is on and temp is less than 100 then"	IF photoeye & (temp<100) THEN
expression1 OR expression2	If photoeye is a BOOL tag, temp is a DINT tag, and your specification says: "If photoeye is on or temp is less than 100 then".	IF photoeye OR (temp<100) THEN
expression1 XOR expression2	If photoeye1 and photoeye2 are BOOL tags and your specification says: "If: photoeye1 is on while photoeye2 is off or photoeye1 is off while photoeye2 is on then"	IF photoeye1 XOR photoeye2 THEN
BOOLtag := expression1 & expression2	If photoeye1 and photoeye2 are BOOL tags, open is a BOOL tag, and your specification says: "If photoeye1 and photoeye2 are both on, set open to true"	open := photoeye1 & photoeye2;

See also

Structured Text Components: Expressions on page 17

Use bitwise operators

Bitwise operators manipulate the bits within a value based on two values.

The following provides an overview of the bitwise operators.

For	Use this operator	Optimal data type
bitwise AND	&, AND	DINT
bitwise OR	OR	DINT
bitwise exclusive OR	XOR	DINT
bitwise complement	NOT	DINT

This is an example.

Use this format	Example		
	For this situation	Use	
value1 operator value2	If input1, input2, and result1 are DINT tags and your specification says: "Calculate the bitwise result of input1 and input2. Store the result in result1."	result1 := input1 AND input2;	

See also

Structured Text Components: Expressions on page 17

Determine the order of execution

The operations written into an expression perform in a prescribed order.

- Operations of equal order perform from left to right.
- If an expression contains multiple operators or functions, group the conditions in parenthesis "()". This ensures the correct order of execution, and makes it easier to read the expression.

Order	Operation
1	0
2	function ()
3	**
4	- (negate)
5	NOT
6	*,/,MOD
7	+,- (subtract)
8	<,<=,>,>=
9	=,<>
10	&,AND
11	XOR
12	OR

See also

Structured Text Components: Expressions on page 17

Structured Text Components: Instructions

Structured text statements can also be instructions. A structured text instruction executes each time it is scanned. A structured text instruction within a construct executes every time the conditions of the construct are true. If the conditions of the construct are false, the statements within the construct are not scanned. There is no rung-condition or state transition that triggers execution.

This differs from function block instructions that use EnableIn to trigger execution. Structured text instructions execute as if EnableIn is always set.

This also differs from ladder diagram instructions that use rung-condition-in to trigger execution. Some ladder diagram instructions only execute when rung-condition-in toggles from false to true. These are transitional ladder diagram instructions. In structured text, instructions execute when they are scanned unless pre-conditioning the execution of the structured text instruction.

For example, the ABL instruction is a transitional instruction in ladder diagram. In this example, the ABL instruction only executes on a scan when tag_xic transitions from cleared to set. The ABL instruction does not execute when tag_xic stays set or when tag_xic clears.



In structured text, if writting this example as:

IF tag_xic THEN ABL(0,serial_control);

END_IF;

The ABL instruction will execute every scan that tag_xic is set, not just when tag_xic transitions from cleared to set.

If you want the ABL instruction to execute only when tag_xic transitions from cleared to set, you have to condition the structured text instruction. Use a one-shot to trigger execution.

```
osri_1.InputBit := tag_xic;
OSRI(osri_1);

IF (osri_1.OutputBit) THEN
ABL(0,serial_control);
END_IF;
```

Structured Text Components: Constructs

Program constructs alone or nest within other constructs.

If	Use this construct
Doing something if or when specific conditions occur	IFTHEN
Selecting what to do based on a numerical value	CASEOF
Doing something a specific number of times before doing anything else	FORD0
Continuing doing something when certain conditions are true	WHILED0
Continuing doing something until a condition is true	REPEATUNTIL

Some Key Words are Reserved

These constructs are not available:

- GOTO
- REPEAT

Logix Designer application will not let you use them as tag names or constructs.

See also

IF_THEN on page 25

CASE_OF on page 28

FOR DO on page 31

WHILE_DO on page 34

REPEAT_UNTIL on page 36

IF_THEN

Use IF_THEN to complete an action when specific conditions occur.

Operands


IF bool_expression THEN

<statement>;

Operand	Туре	Format	Enter
Bool_	BOOL	Tag expression	BOOL tag or expression that evaluates to a BOOL value
expression			(BOOL expression)

Description

The syntax is described in the table.



To use ELSIF or ELSE, follow these guidelines.

To select from several possible groups of statements, add one or more ELSIF statements.

Each ELSIF represents an alternative path.

Specify as many ELSIF paths as you need.

The controller executes the first true IF or ELSIF and skips the rest of the ELSIFs and the ELSE.

To do something when all of the IF or ELSIF conditions are false, add an ELSE statement.

The table summarizes different combinations of IF, THEN, ELSIF, and ELSE.

If	And	Use this construct
Doing something if or when conditions are true	Do nothing if conditions are false	IF_THEN
	Do something else if conditions are false	IF_THEN_ELSE
Selecting alternative statements or groups of	Do nothing if conditions are false	IF_THEN_ELSIF
statements based on input conditions	Assign default statements if all conditions are false	IF_THEN_ELSIF_ELSE

Affects Math Status Flags

No

Major/Minor Faults

None.

Examples

Example 1

IF...THEN

If performing this	Enter this structured text
IF rejects > 3 then	IF rejects > 3 THEN
conveyor = off (0)	conveyor := 0;
alarm = on (1)	alarm := 1;
	END_IF;

Example 2

IF_THEN_ELSE

If performiing this	Enter this structured text
If conveyor direction contact = forward (1) then	IF conveyor_direction THEN
light = off	light := 0;
Otherwise light = on	ELSE
	light [:=] 1;
	END_IF;

The [:=] tells the controller to clear light whenever the controller does the following:

Enters the RUN mode.

Leaves the step of an SFC if you configure the SFC for Automatic reset. (This applies only if you embed the assignment in the action of the step or use the action to call a structured text routine via a JSR instruction.)

Example 3

IF...THEN...ELSIF

If performing this	Enter this structured text
If sugar low limit switch = low (on) and sugar high limit switch = not high (on) then	IF Sugar.Low & Sugar.High THEN
inlet valve = open (on)	Sugar.Inlet [:=] 1;
Until sugar high limit switch = high (off)	ELSIF NOT(Sugar.High) THEN
	Sugar.Inlet := 0;
	END_IF;

The [:=] tells the controller to clear Sugar. Inlet whenever the controller does the following:

Enters the RUN mode.

Leaves the step of an SFC if you configure the SFC for Automatic reset. (This applies only if you embed the assignment in the action of the step or use the action to call a structured text routine via a JSR instruction.)

Example 4

IF...THEN...ELSIF...ELSE

If performing this	Enter this structured text	
If tank temperature > 100	IF tank.temp > 200 THEN	
then pump = slow	pump.fast :=1; pump.slow :=0; pump.off :=0;	
If tank temperature > 200	ELSIF tank.temp > 100 THEN	
then pump = fast	pump.fast :=0; pump.slow :=1; pump.off :=0;	
Otherwise pump = off	ELSE	
	pump.fast :=0; pump.slow :=0; pump.off :=1;	
	END_IF;	

CASE_OF

Use CASE_OF to select what to do based on a numerical value.

Operands

CASE numeric_expression OF

selector1: statement;

selectorN: statement; ELSE


Structured Text

Operand	Туре	Format	Enter
Numeric_ expression	SINT INT DINT REAL	Tag expression	Tag or expression that evaluates to a number (numeric expression)
Selector	SINT INT DINT REAL	Immediate	Same type as numeric_expression

Important:	If using REAL values, use a range of values for a selector because a REAL value is more likely to be within a range of values than an exact match of one, specific value.
	one, specific value.

Description

The syntax is described in the table.



These are the syntax for entering the selector values.

When selector is	Enter	
One value	value: statement	
Multiple, distinct values	value1, value2, valueN: <statement></statement>	
	Use a comma (,) to separate each value.	
A range of values	value1valueN : <statement></statement>	
	Use two periods () to identify the range.	
Distinct values plus a range of values	valuea, valueb, value1valueN : <statement></statement>	

The CASE construct is similar to a switch statement in the C or C++ programming languages. With the CASE construct, the controller executes only the statements that associated with the first matching selector value. Execution always breaks after the statements of that selector and goes to the END_CASE statement.

Affects Math Status Flags

No

Major/Minor Faults

None

Example

If you want this	Enter this structured text
If recipe number = 1 then Ingredient A outlet 1 = open (1) Ingredient B	CASE recipe_number OF
outlet 4 = open (1)	1: Ingredient_A.Outlet_1 :=1; Ingredient_B.Outlet_4 :=1;
If recipe number = 2 or 3 then Ingredient A outlet 4 = open (1) Ingredient B outlet 2 = open (1)	2,3: Ingredient_A.Outlet_4:=1; Ingredient_B.Outlet_2:=1;
If recipe number = 4, 5, 6, or 7 then Ingredient A outlet 4 = open (1) Ingredient B outlet 2 = open (1)	4 to 7: Ingredient_A.Outlet_4 :=1; Ingredient_B.Outlet_2 :=1;
If recipe number = 8, 11, 12, or 13 then Ingredient A outlet 1 = open (1) Ingredient B outlet 4 = open (1)	8,1113 Ingredient_A.Outlet_1:=1; Ingredient_B.Outlet_4:=1;
Otherwise all outlets = closed (0)	ELSE
	Ingredient_A.Outlet_1 [:=]0; Ingredient_A.Outlet_4 [:=]0; Ingredient_B.Outlet_2 [:=]0; Ingredient_B.Outlet_4 [:=]0;
	END_CASE;

The [:=] tells the controller to also clear the outlet tags whenever the controller does the following:

Enters the RUN mode.

Leaves the step of an SFC if configuring the SFC for Automatic reset. This applies only embedding the assignment in the action of the step or using the action to call a structured text routine via a JSR instruction.

FOR_DO

Use the FOR_DO loop to perform an action a number of times before doing anything else.

When enabled, the FOR instruction repeatedly executes the Routine until the Index value exceeds the Terminal value. The step value can be positive or negative. If it is negative, the loop ends when the index is less than the terminal value. If it is positive, the loop ends when the index is greater than the terminal value.

Each time the FOR instruction executes the routine, it adds the Step size to the Index.

Do not loop too many times in a single scan. An excessive number of repetitions causes the controller watchdog to timeout and causes a major fault.

Operands

FOR count:= initial_value TO

final_value BY increment DO

<statement>;

END_FOR;

Operand	Туре	Format	Description	
count	SINT INT DINT	Tag	Tag to store count position as the FOR_DO executes	
initial_value	SINT INT DINT	Tag expression Immediate	Must evaluate to a number Specifies initial value for count	
final_value	SINT INT DINT	Tag expression Immediate	Specifies final value for count, which determines when to exit the loop	
increment	SINT INT DINT	Tag expression Immediate	(Optional) amount to increment count each time through the loop	
			If you don't specify an increment, the count increments by 1.	

Important:


Do not iterate within the loop too many times in a single scan.

The controller does not execute other statements in the routine until it completes the loop. A major fault occurs when completing the loop takes longer than the watchdog timer for the task.


Consider using a different construct, such as IF_THEN.

Description

The syntax is described in the table.



This diagrams illustrates how a FOR_DO loop executes, and how an EXIT statement leaves the loop early.



Affects Math Status Flags

No

Major/Minor Faults

A major fault will occur if	Fault type	Fault code
The construct loops too long.	6	1

Example 1

If performing the following,	Enter this structured text
Clear bits 031 in an array of BOOLs:	For subscript:=0 to 31 by 1 do
Initialize the subscript tag to 0.	array[subscript] := 0;
Clear i . For example, when subscript = 5, clear array[5]. Add 1 to subscript.	End for;
	Liu_ivi,
If subscript is \leq to 31, repeat 2 and 3.	
Otherwise, stop.	

Example 2

If performing the following,	Enter this structured text
ser-defined data type (structure) stores the following information about an	SIZE(Inventory,0,Inventory_Items);
item in your inventory:	For position:=0 to Inventory_Items - 1 do
Barcode ID of the item (String data type) Over the instance of the item (CNIT data type) Over the instance of the item (CNIT data type)	If Barcode = Inventory[position].ID then
 Quantity in stock of the item (DINT data type) An array of the above structure contains an element for each different item in your 	Quantity := Inventory[position].Qty;
inventory. You want to search the array for a specific product (use its bar code)	Exit;
and determine the quantity that is in stock.	End_if;
 Get the size (number of items) of the Inventory array and store the result in Inventory_Items (DINT tag). 	End_for;
Initialize the position tag to 0. 3. If Barcode matches the ID of an item in the array, then:	
Set the Quantity tag = Inventory[position].Qty. This produces the quantity in stock of the item.	
Stop.	
Barcode is a string tag that stores the bar code of the item for which you are searching. For example, when	
$position = 5, compare\ Barcode\ to\ Inventory [5]. ID.$	
4. Add 1 to position.	
 If position is ≤ to (Inventory_Items -1), repeat 3 and 4. Since element numbers start at 0, the last element is 1 less than the number of elements in the array. 	
Otherwise, stop.	

WHILE_DO

Use the WHILE_DO loop to continue performing an action while certain conditions are true.

Operands

WHILE bool_expression DO

<statement>;

Structured Text

Operand	Туре	Format	Description
bool_expression	BOOL	tag expression	BOOL tag or expression that evaluates to a BOOL value


Important:

Do not iterate within the loop too many times in a single scan.


The controller does not execute any other statements in the routine until it completes the loop. A major fault occurs when completing the loop takes longer than the watchdog timer for the task. Consider using a different construct, such as IF_THEN.

Description

The syntax is:



The following diagrams illustrate how a WHILE_DO loop executes, and how an EXIT statement leaves the loop early.



Affects Math Status Flags

No

Fault Conditions

A major fault will occur if	Fault type	Fault code
the construct loops too long	6	1

Example 1

If performing the following,	Enter this structured text	
The WHILE_DO loop evaluates its conditions	pos := 0;	
first. If the conditions are true, the controller then executes the statements within the loop.	While ((pos <= 100) & structarray[pos].value <> targetvalue)) do	
This differs from the REPEAT_UNTIL loop		pos := pos + 2;
because the REPEAT_UNTIL loop executes the statements in the construct and then		String_tag.DATA[pos] := SINT_array[pos];
determines if the conditions are true before executing the statements again. The statements in a REPEAT_UNTIL loop are always executed at least once. The statements in a WHILE_DO loop might never be executed.	end_while;	

Example 2

If performing the following,	Enter this structured text	
Move ASCII characters from a SINT array into a	element_number := 0;	
string tag. (In a SINT array, each element holds one character.) Stop when you reach the	SIZE(SINT_array, 0, SINT_array_size);	
carriage return.	While SINT_array[element_number] <> 13 do	
Initialize Element_number to 0.	String_tag.DATA[element_number] := SINT_array[element_number];	
Count the number of elements in SINT_array (array that contains the ASCII characters) and	element_number := element_number + 1;	
store the result in SINT_array_size (DINT tag).	String_tag.LEN := element_number;	
If the character at	If element_number = SINT_array_size then	
SINT_array[element_number] = 13 (decimal value of the carriage return), then stop.	exit;	
Set String_tag[element_number] = the	end_if;	
character at SINT_array[element_number].	end_while;	
Add 1 to element_number. This lets the controller check the next character in SINT_array.		
Set the Length member of String_tag = element_number. (This records the number of characters in String_tag so far.)		
If element_number = SINT_array_size, then stop. (You are at the end of the array and it does not contain a carriage return.)		

REPEAT_UNTIL

Use the REPEAT_UNTIL loop to continue performing an action until conditions are true.

Operands

REPEAT

<statement>;


Structured Text

Operand	Туре	Format	Enter	
bool_	BOOL	Tag expression	BOOL tag or expression that evaluates to a BOOL value	
expression			(BOOL expression)	

Important:	Do not iterate within the loop too many times in a single scan.
	The controller does not execute other statements in the routine until it completes the loop.
	A major fault occurs when completing the loop takes longer than the watchdog timer for the task.
	Consider using a different construct, such as IF_THEN.


Description

The syntax is:




The following diagrams show how a REPEAT_UNTIL loop executes and how an EXIT statement leaves the loop early.

While the bool_expression is false, the controller executes only the statements within the REPEAT_UNTIL loop.



To stop the loop before the conditions are false, use an EXIT statement.



Affects Math Status Flags

No

Fault Conditions

A major fault will occur if	Fault type	Fault code
The construct loops too long	6	1

Example 1

If performing the following,	Enter this structured text
The REPEAT_UNTIL loop executes the statements in the construct and then determines if the conditions are true before executing the statements again. This differs from the WHILE_DO loop because the WHILE_DO The WHILE_DO loop evaluates its conditions first. If the conditions are true, the controller then executes the statements within the loop. The statements in a REPEAT_UNTIL loop are always executed at least once. The statements in a WHILE_DO loop might never be executed.	pos:=-1;
	REPEAT
	pos := pos + 2;
	UNTIL ((pos = 101) OR (structarray[pos].value = targetvalue))
	end_repeat;

Example 2

If performing the following,	Enter this structured text
Move ASCII characters from a SINT array into a string tag. (In a SINT array, each	element_number := 0;
element holds one character.) Stop when you reach the carriage return.	SIZE(SINT_array, 0, SINT_array_size);
Initialize Element_number to 0. Count the number of elements in SINT_array (array that contains the ASCII	Repeat
characters) and store the result in SINT_array_size (DINT tag).	String_tag.DATA[element_number] := SINT_array[element_number];
Set String_tag[element_number] = the character at	element_number := element_number + 1;
SINT_array[element_number]. Add 1 to element_number. This lets the controller check the next character in	String_tag.LEN := element_number;
SINT_array.	If element_number = SINT_array_size then
Set the Length member of String_tag = element_number. (This records the	exit;
number of characters in String_tag so far.) If element_number = SINT_array_size, then stop. (You are at the end of the	end_if;
array and it does not contain a carriage return.)	Until SINT_array[element_number] = 13
If the character at SINT_array[element_number] = 13 (decimal value of the carriage return), then stop.	end_repeat;

Structured Text Components: Comments

To make your structured text easier to interpret, add comments to it.

- Comments let you use plain language to describe how your structured text works.
- Comments do not affect the execution of the structured text.

To add comments to your structured text:

To add a comment	Use one of these formats
on a single line	//comment
	(*comment*)
at the end of a line of structured text	/*comment*/
within a line of structured text	(*comment*)
	/*comment*/
that spans more than one line	(*start of commentend of comment*) /*start of commentend of comment*/

For example:

Format	Example
//comment	At the beginning of a line
	//Check conveyor belt direction
	IF conveyor_direction THEN
	At the end of a line
	ELSE //lf conveyor isn't moving, set alarm light
	light := 1;
	END_IF;
(*comment*)	Sugar.Inlet[:=]1;(*open the inlet*)
	IF Sugar.Low (*low level LS*)& Sugar.High (*high level LS*)THEN
	(*Controls the speed of the recirculation pump. The speed depends on the temperature in the tank.*)
	IF tank.temp > 200 THEN
/*comment*/	Sugar.Inlet:=0;/*close the inlet*/
	IF bar_code=65 /*A*/ THEN
	/*Gets the number of elements in the Inventory array and stores the value in the Inventory_Items tag*/ $$
	SIZE(Inventory,0,Inventory_Items);

arithmetic operators 18 ASCII character 15 assign ASCII character 15 В bitwise operators 22 C CASE 28 comments 39 E evaluation in structured text 20 evaluation of strings 20 F FOR?DO 31 functions 18 IF...THEN 25 logical operators 21 non-retentive 14 non-retentive assignment 14 R relational operators 20 REPEAT?UNTIL 36 S structured text 14, 18, 20, 21, 22, 23, 39

A

structured text assignment 15
Structured Text Components
Assignments 13
structured text expression 23

W

WHILE?DO 34

Rockwell Automation support

Rockwell Automation provides technical information on the web to assist you in using its products.

At http://www.rockwellautomation.com/support you can find technical and application notes, sample code, and links to software service packs. You can also visit our Support Center at https://rockwellautomation.custhelp.com for software updates, support chats and forums, technical information, FAQs, and to sign up for product notification updates.

In addition, we offer multiple support programs for installation, configuration, and troubleshooting. For more information, contact your local distributor or Rockwell Automation representative, or visit http://www.rockwellautomation.com/services/online-phone.

Installation assistance

If you experience a problem within the first 24 hours of installation, review the information that is contained in this manual. You can contact Customer Support for initial help in getting your product up and running.

United States or Canada	1.440.646.3434
Outside United States or Canada	Use the Worldwide Locator available at http://www.rockwellautomation.com/locations , or contact your local Rockwell Automation representative.

New product satisfaction return

Rockwell Automation tests all of its products to ensure that they are fully operational when shipped from the manufacturing facility. However, if your product is not functioning and needs to be returned, follow these procedures.

	Contact your distributor. You must provide a Customer Support case number (call the phone number above to obtain one) to your distributor to complete the return process.
Outside United States	Please contact your local Rockwell Automation representative for the return procedure.

Documentation feedback

Your comments will help us serve your documentation needs better. If you have any suggestions on how to improve this document, complete the feedback form, publication <u>RA-DU002</u>.

Rockwell Otomasyon Ticaret A.Ş., Kar Plaza İş Merkezi E Blok Kat: 6 34752 İçerenköy, İstanbul, Tel: +90 (216) 5698400

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444
Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640
Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Rockwell Automation Publication 1756-PM007H-EN-P - November 2018