$$I_{in} = \frac{V_{DD} - V_{GS,1}}{R_M} \qquad \downarrow I_{out}$$

$$V_{DD} = \frac{V_{DD} - V_{GS,1}}{R_M} \qquad \downarrow I_{out}$$