

Aurora X1 Field Handbook

1. Mounting

Mount the unit vertically, sensing face downward, at least three hundred millimetres from any metal surface. Horizontal mounting traps condensation against the sensing face. Keep two metres between neighbouring units and survey the radio signal from the intended position before drilling.

2. Calibration

Recalibrate after any ambient shift of more than five degrees Celsius, and at least once every ninety days. Place the unit on a level surface, hold the pairing pin for five seconds, and wait for the status ring to settle to steady green. Calibration takes roughly two minutes.

3. Cold-weather storage

Store spare units above minus ten degrees Celsius; colder storage shortens battery life sharply. After cold storage, let the unit rest at room temperature for two hours before calibration, so condensation can clear from the sensing face. Calibrating a cold unit bakes the temperature error into its offsets.