### **Pocket Operator PO-24 Office**

### Universal functions



Toggle write mode.



Play start/stop.



Select sound.



Switch between standard tempos.



Adjust swing.



Adjust tempo.



Adjust master volume.



Select pattern.



Clear current pattern.



Paste current pattern to slot and switch to it.



Chain patterns (and select first).



Cycle through sync modes.

## In write mode (playing or not)

Lights 1-16 show active steps for selected sound.



Toggle step to play selected sound.



Change and write sound parameters for that step.



Retrigger step. Cycle through 2. 3. 4. 6. 8. 1 times.

## When not in write mode (playing or not)



Change parameters of last sound played

## Default sound parameters (A, B)

60, 80	55, 80	55, 80	52, 80
52, 80	52, 76	52, 80	52, 80
52, 20	51, 75	51, 75	52, 75
51, 80	51, 80	50, 80	51, 80

## When playing (write mode on or off)



Change and write sound parameters over time.



Toggle solo for given sound(s).



Punch in effects over time.



Clear effects over time.

# When playing (in write mode)

Screen shows selected sound

## When playing (write mode off)

Lights 1-16 show notes being played, and current step. Screen shows current pattern.



Live play sound.



Live record given sound.

## When not playing (write mode on or off)



Activate effect for live playing (only greyed effects below).



Deactivate effect for live playing.

### Effects

Aliasing	Overdrive	Repeat 4	Repeat 2
LP filter	LP sweep	HP filter	HP sweep
Distort lo	Distort hi	Retrig	Retrig >>
Glitch	Glitch >>	Blinds	Noise

### Sync modes

	Input	Output
SY0	Stereo	Stereo
SY1	Stereo	Mono/Sync
SY2	Sync	Stereo
SY3	Sync	Mono/Sync
SY4	Mono/Sync	Stereo
SY5	Mono/Sync	Mono/Sync