## LEGEND:

(X) INDICATION LAMP
"X" DENOTED COLOUR AS FOLLOWS:
G – GREEN
R – RED
Y – AMBER
B – BLUE
W – WHITE

(X) PUSH BUTTON
"X" DENOTED COLOUR AS FOLLOWS:
G – GREEN
R – RED
Y – AMBER
B – BLUE
BK – BLACK

(E) MANUAL OVERRIDE SWITCH (MANUAL RESET TYPE)

BUZZER

(II) KEY SELECTOR SWITCH

[ ] NAME PLATE (WHITE WITH READ ENGRAVED WORDS)

## NOTES:

1. THE SUPERVISORY CONTROL PANEL FOR STAIRCASE PRESSURIZATION SHALL BE LOCATED ADJACENT TO FIRE CONTROL PANEL.
2. ALL SWITCHES AND INDICATORS SHALL BE CLEARLY LABELED (RED LETTERS ON WHITE BACKGROUND, NOT LESS THAN 3mm HIGH).
3. A FURTHER LABEL SHALL BE PROVIDED WITH LETTERS NOT LESS THAN 6mm HIGH STATING THAT THE CONTROLS SHALL BE OPERATED BY AUTHORIZED PERSONNEL.
4. ALL LABELS SHALL BE PERMANENT, LEGIBLE AND FIRMLY SECURED (ADHESIVE IS NOT SATISFACTORY) AND SHALL BE LETTERED IN BOTH ENGLISH AND CHINESE BY ENGRAVING OR SIMILAR.
5. SCHEMATIC DIAGRAM OF STAIRCASE PRESSURIZATION SYSTEMS SHALL BE PROVIDED ADJACENT TO THE SUPERVISORY CONTROL PANEL FOR STAIRCASE PRESSURIZATION SYSTEM.
7. VISUAL AND AUDIO ALARM AT SUPERVISORY CONTROL PANEL WILL BE "ON" ONCE THE MANUAL OVERRIDE BUTTON PROVIDED ON THE SUPERVISORY CONTROL PANEL IS PUSHED. THE STATUS OF THE FANS AND DAMPERS REMAIN UNCHANGED.
8. "AUTO/LOCAL" KEY SWITCH PROVIDED ON FAN LOCAL MOTOR CONTROL PANEL (LMCP) IS LOCKED IN "AUTO" POSITION. THE VISUAL AND AUDIO ALARM ON THE RESPECTIVE FAN AT THE SUPERVISORY CONTROL PANEL WILL BE "ON" ONCE "AUTO/LOCAL" SWITCH AT LMCP IS IN "LOCAL POSITION"
9. THE MANUAL OVERRIDE SWITCH ON THE SUPERVISORY CONTROL PANEL WILL NOT HAVE CONTROL TO THE CORRESPONDING FAN/MOTOR WHICH HAS BEEN SWITCHED TO "LOCAL" POSITION IN THE LMCP OR THE MOTOR EMERGENCY STOP BUTTON IS PUSHED EVEN RECEIPT OF FIRE SIGNAL.

SUPERVISORY CONTROL PANEL FOR STAIRCASE PRESSURIZATION SYSTEM (STAIRCASE ST–B1)
樓梯加壓系統主控制箱 (ST-B1 樓梯)

| | STAIRCASE PRESSURIZATION FAN (SPF–GF–01) 樓梯加壓風扇 (SPF-GF-01) | | LOBBY PRESSURIZATION FAN (LPF–GF–01) 電梯大堂加壓風扇 (LPF-GF-01) | | DUTY AIR RELEASE FAN (ARF–GF–01A) 排風主風扇 (ARF–GF–01A) | STANDBY AIR RELEASE FAN (ARF–GF–01B) 排風後備風扇 (ARF–GF–01B) |
|---|---|---|---|---|---|---|
| | DUTY MOTOR 主馬達 | STANDBY MOTOR 後備馬達 | DUTY MOTOR 主馬達 | STANDBY MOTOR 後備馬達 | | |
| POWER HEALTHY 電源正常 | Y | Y | Y | Y | Y | Y |
| POWER FAILURE 電源故障 | R | R | R | R | R | R |
| RUNNING 運行 | G | G | G | G | G | G |
| STOP 停止 | B | B | B | B | B | B |
| FAULT 故障 | R | R | R | R | R | R |
| E–STOP 急停 | R | R | R | R | R | R |
| MANUAL MODE 本控模式 | | Y | | Y | | Y |
| MANUAL ON 手動開啟 | | G | | G | G | G |
| MANUAL OFF 手動關閉 | | B | | B | B | B |

| | MFSD FOR STAIRCASE PRESSURIZATION INLET(ST–B1) 樓梯加壓入風防火閘 (ST-B1) | | MFSD FOR LOBBY PRESSURIZATION INLET (ST–B1) 電梯大堂加壓入風防火閘 (ST-B1) | | MFSD FOR AIR RELEASE FAN (ST–B1) 排風風扇防火閘 (ST-B1) | |
|---|---|---|---|---|---|---|
| | MFSD–SPF–GF–01 | | MFSD–LPF–GF–01 | | MFSD–ARF–GF–01A | MFSD–ARF–GF–01B |
| OPEN 開啟 | G | G | G | G | G | G |
| CLOSE 關閉 | B | B | B | B | B | B |

| | MMD–SPF–GF–01 旁路電閘 | MMD–LPF–GF–01 旁路電閘 | MMD–ARF–1F–01 旁路電閘 |
|---|---|---|---|
| OPEN 開啟 | G | G | G |
| CLOSE 關閉 | B | B | B |

LOBBY PRESSURIZATION MFSD
電梯大堂加壓防火閘

| | MFSD–LPG–B3–01 | MFSD–LPG–B2–01 | MFSD–LPG–B1–01 |
|---|---|---|---|
| OPEN 開啟 | G | G | G |
| CLOSE 關閉 | B | B | B |

AIR INTAKE PROBE DETECTOR TRIP (PTSD–SPF–GF–01) 入風口煙感器感應 — R
AIR INTAKE PROBE TRIP MANUAL OVERRIDE (PTSD–SPF–GF–01) 入風口煙感器手動凌駕 — E, Y
AIR INTAKE PROBE DETECTOR TRIP (PTSD–LPF–GF–01) 入風口煙感器感應 — R
AIR INTAKE PROBE TRIP MANUAL OVERRIDE (PTSD–LPF–GF–01) 入風口煙感器手動凌駕 — E, Y

AIR RELEASE MFSD
排風防火閘

| | MFSD–ARG–B3–01 | MFSD–ARG–B3–02 | MFSD–ARG–B2–01 | MFSD–ARG–B2–02 | MFSD–ARG–B1–01 | MFSD–ARG–B1–02 |
|---|---|---|---|---|---|---|
| OPEN 開啟 | G | G | G | G | G | G |
| CLOSE 關閉 | B | B | B | B | B | B |

| FIRE 火警警報 | RESET 重設 | BUZZER 警報器 | MUTE 警報靜音 | LAMP TEST 燈測試 | AUTO 自動 | MANUAL OVERRIDE 手動凌駕 | MANUAL OVERRIDE BUTTON 手動凌駕制 |
|---|---|---|---|---|---|---|---|
| R | BK | | BK | Y | B | Y | E |

THE CONTROLS SHALL BE OPERATED BY AUTHORIZED PERSONNEL
未經許可不得操控

SUPERVISORY CONTROL PANEL FOR ST–B1 STAIRCASE PRESSURIZATION SYSTEM AT G/F FIRE CONTROL CENTRE

FIRE SERVICE INSTALLATION PLANS AS CERTIFIED BY THE AUTHORIZED PERSON AND FIRE SERVICE INSTALLATION CONTRACTOR / CONSULTANT
Date 27 AUG 2026
Signed (FUNG Kam-wah)
for Director of Fire Services

LOO Kwan Wai
(RPE No.: RP0260258)

| NO. | DATE | REVISIONS | DRAFTED | CHECKED | DESIGNED | REVIEWED |
|---|---|---|---|---|---|---|
| A | 07/2025 | FSD SECOND SUBMISSION | HYH | WWC | HYH | TKL |
| 0 | 03/2025 | FSD FIRST SUBMISSION | HYH | WWC | HYH | TKL |

CLIENT:

NATION STAR DEVELOPMENT LIMITED
75/F, 8 Finance Street,
Central, Hong Kong

PROJECT ARCHITECT & AUTHORIZED PERSON:
RONALD LU & PARTNERS 呂元烽建築師事務所
33rd Floor, Wu Chung house, 213 Queen's Road East,
Wanchai, Hong Kong

STRUCTURAL/GEOTECHNICAL:
wsp
7/F, One Kowloon
1 Wang Yuen Street
Kowloon Bay, Hong Kong

BUILDING SERVICES ENGINEER:
wsp
7/F, One Kowloon
1 Wang Yuen Street
Kowloon Bay, Hong Kong

QUANTITY SURVEYOR:
ARCADIS
17/F, Two Harbour Square, 180 Wai Yip Street,
Kwun Tong, Kowloon
Hong Kong

FIRE SERVICES CONTRACTOR:
開創工程有限公司
GRAND CREATIVE ENGINEERS LIMITED
ELECTRICAL & MECHANICAL ENGINEERING SERVICES CONTRACTOR
MEC1 LICENSED PLUMBING DRAIN CONTRACTOR
EMB3 REGISTERED ELECTRICAL CONTRACTOR
陳廣開
Chan Kwong Hoi
Director
Unit D, 2/F, Cheong Wah Comm. Bldg., 900-904 Canton Road, Kowloon.
Mobile : 9015 9086 Tel : 3612 5782 Fax : 3612 5785
Email : info@grandcreative.com.hk

PROJECT:
PROPOSED DEVELOPMENT AT BAILEY STREET & WING KWONG STREET, TO KWA WAN, KOWLOON
INLAND LOT NO. 11279
(URA PROJECT KC–009)

TITLE:
STAIRCASE PRESSURIZATION SYSTEM – SUPERVISORY CONTROL PANEL FOR ST–B1

(3)

| DATE: 06/2026 | SCALE: NTS@A0 | | |
|---|---|---|---|
| DRAFTED: HYH | CHECKED: WWC | DESIGNED: HYH | REVIEWED: TKL |
| JOB NO. 2503373A | DRAWING NO. 2503373A/SPS/STB1/102 | REV. NO. A | |