

	61045001	CD-100A Phonograph Assembly (60 Hz)	Ref
	61045002	CD-100A Phonograph Assembly (50 Hz)	Ref.
	61035002	• Shell Assembly	1
	60927901	• Bracket-Cash Bag	1
	21451801	• Lock Spring	1
	30866905	• Protective Strap	2
	70240126	• Screen-Wire Mesh	1
	21537203	• Tee Nut	2
	20932601	• Tee Nut	6
	21750618	• Vent Tube	1
	21750616	• Vent Tube	1
2	40702808	• Skid Rail	2
3	30625701	• Hand Hold Cover	4
4	30634001	• Caster and Cup Assembly	4
5	30868402	• Enclosure Screen	1
6	20879501	• Power Cord Holder	2
7	21265203	• Tie Down Plate Assembly	1