



HP Poly Studio Mobile App User Guide

SUMMARY

HP Poly Studio Mobile App User Guide

Legal information

Copyright and license

© 2024, 2026, HP Development Company, L.P. The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Trademark credits

All third-party trademarks are the property of their respective owners. Bluetooth is a trademark owned by its proprietor and used by HP Inc. under license.

Privacy policy

HP complies with applicable data privacy and protection laws and regulations. HP products and services process customer data in a manner consistent with the HP Privacy Policy. Please refer to [HP Privacy Statement](#).

Open source software used in this product

This product contains open source software. You may receive the open source software from HP up to three (3) years after the distribution date of the applicable product or software at a charge not greater than the cost to HP of shipping or distributing the software to you. To receive software information, as well as the open source software code used in this product, contact HP by email at ipgoopensourceinfo@hp.com.

Table of contents

1 Getting started	1
Create an account	1
Log in	2
Log out	2
Explore Poly Studio Mobile as a guest	2
Send device data to improve your experience	3
Delete your account	3
Viewing device tutorials	3
Open device tutorials	3
View device onboarding page, quick guide, and user guide	4
Fit test for ear tips	4
Device documentation	4
View supported devices	5
Supported devices	5
Accessibility features	6
2 Using Poly Studio Mobile	8
View device information	8
Find your device	8
Configure device alerts	9
Remove a device	10
Contact Support	10
Send feedback to HP	10
3 Configuring your devices	11
Configure headset and speakerphone settings	11
Updating device software	12
Update device software from the device screen	12
Update device software from device settings	12
Updating Poly Voyager Free 60+ UC and touch-screen charge case	13
Update Poly Voyager Free 60+ UC and touch-screen charge case together	13
Enable NoiseBlockAI	14
Customize the audio equalizer settings	14
Rename your device	15
Clear trusted devices	15
Restore device settings to default	16
Select language for audio prompts and alerts	16

Select settings to display on the device screen	16
4 Configuring Poly Studio Mobile	17
Select Color Theme	17
Update Poly Studio Mobile	17
5 Frequently asked questions.....	18
General questions.....	18
Last Connected Location.....	19
Play Tone.....	19
6 Getting help.....	21
HP Inc. addresses.....	21
Document information.....	21

2 Using Poly Studio Mobile

Use Poly Studio Mobile to monitor and configure your devices and contact support.

To connect your Poly Bluetooth devices, set the device into pairing mode. After the device connects to your phone, Poly Studio Mobile displays your device. You can monitor and configure your device or access the device documentation page.

View device information

View your device's name, connection status, quick settings selections, battery level, software version, and release notes on the device screen in Poly Studio Mobile.

1. Connect your device to your phone.
2. Launch Poly Studio Mobile.
3. From the device screen, view the following information:
 - **Name:** The name of your device.
 - **Connection status:**
 - **Connected:** Indicates that the device is connected to your phone.
 - **Disconnected:** Indicates that the device isn't connected to your phone.
 - **Quick settings:** Shortcuts for up to three of your preferred settings based on your **Quick settings selection** choices.
 - **Battery:** Battery level and charging state if the device is charging.
 - **Software:** Current device software version.
 - **Software Update:** The software version that's available to upgrade your device.
 - **Release Notes:** The latest release notes for the device.

Find your device

Track your device using Poly Studio Mobile.

You must enable the location service option on your mobile phone to use this feature.

Poly Studio Mobile includes Play Tone and Last Connected Location technology.

- **Play Tone:** Use Play Tone technology to find devices that meet the following requirements:
 - The device is powered on and within Bluetooth range of your phone.
 - The device is connected to your phone.

- **Last Connected Location:** Last Connected Location technology lets you view a short history of a device's events (including where they took place), so that you may effectively retrace your steps and locate your device, even when it's not connected. You can use Last Connected Location when you're trying to find a device that may be in one of the following states:
 - Powered off
 - Disconnected from your phone
 - Out of Bluetooth range
1. Launch Poly Studio Mobile.
 2. Select **Menu** .
 3. Select **Find My Device**.
The **Find My Device** button is also on the device screen if the device is offline.
 4. (iOS only) Select **Not seeing your device?** to choose your device if the device is connected, but it doesn't show up under the **Find my device** list.
 5. Find the device using one of the following options:
 - Select the **Play** button to send a tone from your device.
 - View the device events history to help you find the device.

Configure device alerts

After you turn on device alerts, Poly Studio Mobile sends pop-up messages under certain conditions.

1. Launch Poly Studio Mobile.
2. Select **Menu** .
3. Select **General**.
4. Select **Notifications & Device Alerts**.
5. Select the **Notifications** toggle.



NOTE: If **Notifications** is toggled off, you must first turn on notifications in your phone settings to allow Poly Studio Mobile to send notifications.

6. Configure the following settings:
 - **Device Charging:** Your devices are charging.
 - **Device Disconnected:** Your devices are disconnected from your computer.
 - **Mute Alert:** You mute your microphone during a meeting or call.
 - **Device Unpaired:** A paired device is unpaired.
 - **Low Battery:** Your device has a low battery status.
 - **Device Software Update:** Software updates are available for connected devices.

Remove a device

Remove unused devices only when the device is offline.



NOTE: This action only removes the device from the app. If you plan to use the device with another phone, you can manually choose to forget it from the Bluetooth settings on the phone. To delete the list of connected devices stored on your headset, see [Clear trusted devices on page 15](#).

1. Launch Poly Studio Mobile.
2. From the device screen, select **...**.
3. Select **Delete device**.
4. Select **Yes**.

Contact Support

Contact Support for issues with your device or Poly Studio Mobile.

1. Launch Poly Studio Mobile.
2. Select **Menu**
3. Select **Support**.
4. Do one of the following:
 - Select **Device** if you have issues with your device.
 - Select **App** if you have issues with the application.
5. Take a screen shot of the details for your device or app.
6. Select **Go** to open the support page.
7. Log in with your HP account.
8. Call a support agent or go to the HP Support Community.

Send feedback to HP

Send feedback on Poly Studio Mobile to HP. Report a bug, comment on features, or send suggestions about the product.

1. Launch Poly Studio Mobile.
2. Select **Menu**
3. Select **Feedback** to open the **Poly Studio Mobile App Feedback** portal.
4. Select a feedback type and enter your feedback.
5. **Optional:** Enter your contact information.
6. Select **Send**.

3 Configuring your devices

Customize your user experience by configuring the settings for your connected devices from Poly Studio Mobile.



NOTE: If you associate your Poly Studio Mobile account with the Poly Lens service, any headset settings configured in Poly Lens save to your devices. You can't configure the settings from Poly Studio Mobile.

Configure headset and speakerphone settings

Configure your Poly Bluetooth headset and speakerphone behavior in Poly Studio Mobile.



NOTE: Poly headsets and speakerphones share the same setting categories.

Many, but not all, Poly headsets contain smart sensors. Smart sensors detect whether or not you're wearing the headset and enable the following options:

- Answer a call by putting on your headset.
- Mute your headset microphone when you remove your headset during a call.
- Transfer call audio between your mobile phone and headset.

If you aren't wearing your headset and you answer a call on your mobile phone, the audio routes to the phone. Put on the headset to transfer the active call audio to your headset.

If you're wearing your headset and answer an incoming call or initiate an outgoing call, the audio routes to your headset. Take off the headset to transfer audio to your mobile phone.

- Pause streaming media by removing the headset, and resume the media by putting your headset back on.
1. Connect your device to your phone.
 2. Launch Poly Studio Mobile.
 3. From the device screen, select
 4. Configure the following settings:



NOTE: A settings category only displays if it's applicable for your device.



NOTE: For some headsets, you may need to power off and power on the device for the changes to take effect.

- **Software**
- **User Guide**
- **Voice Prompts & Tones**
- **Ringtones & Volume**

- Sensors
- Find My Device
- Wireless
- General
- Advanced
- Language
- Reset Device
- ANC
- Multi-function Button
- Custom Button
- Custom Swipe Sensor
- Apps
- Quick settings selection

Updating device software

Use Poly Studio Mobile to update the software for your connected devices.

The application checks for a new software version from the server automatically for connected devices. If the application detects a new version, a **Software Update** option displays on the device screen.



IMPORTANT: You can't close Poly Studio Mobile during the update process.



IMPORTANT: You must keep the device connected and don't use it during the software update.

Update device software from the device screen

Update your device software from the device screen.

1. Connect your device to your phone.
2. Launch Poly Studio Mobile.
3. From the device screen, select **Software Update**.
4. Select **Continue**.
5. Select **Start Update**.
6. Follow the onscreen instructions to complete the software update.

Update device software from device settings

Update your device software from device settings.

1. Connect your device to your phone.

2. Launch Poly Studio Mobile.
3. From the device screen, select
4. Select **Software**.
5. Select **Update**.
6. Follow the onscreen instructions to complete the software update.

Updating Poly Voyager Free 60+ UC and touch-screen charge case

Use Poly Studio Mobile to update your Poly Voyager Free 60+ UC earbuds and touch-screen charge case.

Poly Studio Mobile checks for a new software version from the server automatically when your Poly Voyager Free 60+ UC earbuds connect to Poly Studio Mobile.

If the application detects a new version of the earbuds or touch-screen charge case, a **Software Update** button displays on the device screen.

- If the software for the Poly Voyager Free 60+ UC earbuds and touch-screen charge case isn't the latest version, you can upgrade your Poly Voyager Free 60+ UC earbuds and touch-screen charge case at the same time.
- If only the earbuds or touch-screen charge case isn't the latest version, you can upgrade the earbuds or touch-screen charge case separately. For more information, refer to [Update device software from device settings](#).
- To use this feature, the software of both the earbuds and touch-screen charge case must be on version 231.591.0.5039 or later.

If the earbuds' software version is earlier than 231.591.0.5039, follow [Update device software from the device screen](#) and [Update device software from device settings](#) to upgrade using Poly Studio Mobile.

If the touch-screen charge case software version is earlier than 231.591.0.5039, follow [Update your device software using Poly Studio Desktop](#) to upgrade.

Update Poly Voyager Free 60+ UC and touch-screen charge case together

Use Poly Studio Mobile to update your Poly Voyager Free 60+ UC earbuds and touch-screen charge case together.

Make sure to do the following before you start the update:

- Make sure the battery status for both Poly Voyager Free 60+ UC earbuds is above 50%. Check the battery status from the device screen. For more information, refer to [View Device Information](#).
- Pair both the earbuds with your mobile phone.

Note the following during the update:

- Make sure that both earbuds remain connected to Poly Studio Mobile during the entire update process.
- The earbuds disconnect from Poly Studio Mobile if you put them into the touch-screen charge case.

- Don't use the earbuds or any other connected Poly devices for a call or meeting during the update process.
1. Connect your device to your phone.
 2. Launch Poly Studio Mobile.
 3. Do one of the following:
 - From the device screen, select **Software Update**.
 - From the device screen, select **...** > **Software** > **Update**.
 4. Select **Update All**.
 5. Follow the onscreen instructions to complete the software update.

Poly Studio Mobile updates Poly Voyager Free 60+ UC and the touch-screen charge case to the latest software version.

Enable NoiseBlockAI

Enable NoiseBlockAI on your Poly Voyager Free 60+ UC.

1. Connect your device to your phone.
2. Launch Poly Studio Mobile.
3. From the device screen, select **...**.
4. Select **Advanced**.
5. Under **Close Conversation Limiting**, select one of the three NoiseBlockAI settings.



NOTE: **UC Noise Block** is the default setting.

During an active call, **Close Conversation Limiting** isn't available for selection or adjustment.

Customize the audio equalizer settings

Customize the audio equalizer settings on Poly Voyager Free 60+ UC, Poly Voyager Free 20, and Poly Voyager Surround Series devices. If you don't customize the audio equalizer settings, the device automatically uses the preset settings.

1. Connect your device to your phone.
2. Launch Poly Studio Mobile.
3. From the device screen, select **...**.
4. Select **EQ**.



NOTE: If your device firmware doesn't support audio equalizer customization, **EQ** displays under **General**.

5. Select **Custom** from the **Equalizer** drop-down menu, and toggle the settings according to your preferences.
6. Select **Save EQ**.

Rename your device

Name or rename your Poly Voyager Free 60 series, Poly Voyager Surround 80 series, or Poly Sync 20 device to identify it more easily.

You must meet the following requirements when you name or rename your device:

- Minimum of 1 character in length
- Maximum of 31 characters in length
- The following special characters are allowed:
! " # \$ % & ' () + , - . / : ; < = > ? @ [] ^ _ ` { | } ~ *
- English and non-English characters are allowed
- No emojis

1. Connect your device to your phone.
2. Launch Poly Studio Mobile.
3. From the device screen, select
4. Select **General**.
5. Select the device name.
6. Enter a name for your device in the **Rename your device** dialog.
7. Select **Done**.



NOTE: After you rename a device from the app, forget or unpair the device from the Bluetooth settings on your phone. Then, pair the device again with the new name.

Restoring the factory default settings for your device changes the name back to the default name.

Clear trusted devices

Clear all the devices connected to your headset.

This option removes all connected devices, including computers, mobile phones, or USB adapters from your headset or speakerphone's memory. If you want to continue to use the headset or speakerphone with your phone, you must pair it with your phone again manually.

1. Connect your device to your phone.
2. Launch Poly Studio Mobile.
3. From the device screen, select

4. Select **Reset Device**.
5. Select **Clear**.

Restore device settings to default

Restore the factory default settings for your device from Poly Studio Mobile.

1. Connect your device to your phone.
2. Launch Poly Studio Mobile.
3. From the device screen, select
4. Select **Reset Device**.
5. Select **Restore**.

Select language for audio prompts and alerts

Select the language that you want for all audio prompts and alerts.

1. Connect your device to your phone.
2. Launch Poly Studio Mobile.
3. From the device screen, select
4. Select **Language**, and then select the language from the list of supported languages.

Select settings to display on the device screen

Select shortcuts for up to three of your preferred settings to display on the device screen.

1. Connect your device to your phone.
2. Launch Poly Studio Mobile.
3. From the device screen, select
4. Select **Quick settings selection**.
5. Select the **Quick settings** toggle.
6. Select up to three of the settings that you want to display on the device screen.
7. Select **Save**.

4 Configuring Poly Studio Mobile

Update Poly Studio Mobile and configure the color theme.

Select Color Theme

Select a color theme for Poly Studio Mobile.

1. Launch Poly Studio Mobile.
2. Select **Menu** .
3. Select **Color Theme**.
4. Choose a theme.

Update Poly Studio Mobile

Update Poly Studio Mobile.

1. Launch Poly Studio Mobile.
2. Select **Menu**  > **General** > **About**.
3. Select **Update** to go to the application store to update Poly Studio Mobile.

5 Frequently asked questions

Find the answers to the questions that you may have when using Poly Studio Mobile.

General questions

Find the answers to the questions that you may have when using Poly Studio Mobile with your headset or speakerphone.

Why does my headset or speakerphone not show up in Poly Studio Mobile?

Poly Studio Mobile currently supports only a specific list of headsets and doesn't include some older models. This list changes over time as new headsets or speakerphones are released.

What does *paired* mean?

A headset or speakerphone *pairs* to a phone when the two devices are "introduced" so that they can recognize each other in the future and transfer information (for example, phone calls and music) back and forth.

You must pair a headset or speakerphone before it can connect to your device.

What does *connected* or *disconnected* mean?

Connected means that the headset or speakerphone and phone are now communicating with one another. You must first pair the headset or speakerphone with the phone and keep it within Bluetooth range, approximately 10 m (33 ft) for it to connect.

Disconnected means that the headset or speakerphone and phone aren't communicating with one another. This may be due to one or both of the devices being powered off or out of Bluetooth range.

Both of these events are logged in your **Last Connected Location** history to help you remember where and when you last used your headset.

Why didn't my device upgrade?

Sometimes your device has problems upgrading the firmware. To help resolve this problem, do the following:

- Check the following items before you try to upgrade your device again:
 - Fully charge your device; a low battery may interrupt the upgrade.
 - Keep Poly Studio Mobile open during the upgrade. Don't close the app or switch to other applications during the upgrade process.
 - Keep the device connected and near your phone.
 - Use a stable internet or cellular connection.
- Try to upgrade again:
 - Select **Retry** after an upgrade failure.

- Restart Poly Studio Mobile and upgrade your device again.
- Restart your device and upgrade again.
- Contact the support team if none of the solutions work for you.

Can I use this app on my iPad?

The app store allows you to download and install the app on your iPad. However, Poly recommends using it with an iPhone for the best user experience. Although the app works on an iPad, the UI displays the same as on an iPhone.

Why is my device not showing on the Find My Device list? What does it mean when I see the dialog *Try making this your Primary Device. If the issue continues, please contact Support?*

Go to the Bluetooth settings on your phone, and check how the device connects. For example, on an iPhone, select **Headphone** as the **Device Type**. On an Android phone, select **Headphones** as the **Audio device type**. In addition, you can enable the device for Calls, Audio, or both, based on your usage.

Last Connected Location

Find the answers to the questions that you may have when using the Last Connected Location technology.

Why is Last Connected Location unavailable?

On rare occasions, you may find that your Last Connected Location history is empty or displays **No Location Recorded** for your events.

- When you install the app after losing your device, the **Find My Device** feature has no record of past device events, since it wasn't running when they occurred.
- When **Location** is turned off in iOS settings or unavailable, Last Connected Location reports device events, but it can't record their locations. Turn on Location in iOS settings or Poly Studio Mobile to begin capturing future event location details.

What type of events are logged in Last Connected Location?

There are two types of device events logged in Last Connected Location:

- Device Connected
- Device Disconnected

Each event displays the time that it took place and the estimated location on the map where it occurred.

Play Tone

Find the answers to the questions that you may have when using Play Tone technology.

When do I use Play Tone?

Use Play Tone when your headset is powered on and within Bluetooth range of your phone, approximately 10 m (33 ft). Your headset must be connected for this feature to work.

Why is Play Tone unavailable?

The Play Tone technology doesn't work when your device is in one of the following states:

- Powered off.
- Out of battery charge.
- Out of Bluetooth range, approximately 10 m (33 ft).
- Not connected to your phone.

What if I can't hear the tone?

If you have tried the Play Tone feature and can't hear it coming from your device, try these tips:

- Confirm that you're searching for the right device.
- Check the volume. Turn up your phone's volume.
- Minimize background noise.

Why I can't play the tone on my device when multiple devices are connected to my iPhone?

If you have multiple devices connected to your iPhone, you may receive the **Try making this your primary device.** error message when you play the tone on one of your connected devices. Try the following steps to fix the issue:

1. Select **Not seeing your device?**
2. Select the device that you want to play the sound on.
3. Go back to the **Find my device** screen.
4. Select the device.
5. Select the **Play** button to send a tone from your device.

Is the tone dangerous to my hearing?

The tone is carefully calibrated to offer maximum probability of finding your headset while remaining below the safe upper threshold for headset or speakerphone volume levels.

 **CAUTION:** Avoid playing a tone if someone might be wearing the headset to avoid causing any hearing discomfort.

What if I can't find my device?

If you can't find your device, or if you locate it and discover that it's broken or damaged, visit the [HP | Poly website](#) to pick out a replacement device from our latest lineup of products.

6 Getting help

Poly is now a part of HP. The joining of Poly and HP paves the way for us to create the hybrid work experiences of the future. Information about Poly products has transitioned from the Poly Support site to the HP Support site.

The [Poly Documentation Library](#) is continuing to host the installation, configuration/administration, and user guides for Poly products in HTML and PDF format. In addition, the Poly Documentation Library provides Poly customers with information about the transition of Poly content from Poly Support to [HP Support](#).

The [HP Community](#) provides additional tips and solutions from other HP product users.

HP Inc. addresses

Contact HP at the following office locations.

HP US

HP Inc.
1501 Page Mill Road
Palo Alto, CA 94304
United States
Phone: +1 650-857-1501

HP Germany

HP Deutschland GmbH
HP HQ-TRE
71025 Boeblingen, Germany

HP Spain

HP Printing and Computing Solutions, S.L.U.
Cami de Can Graells 1-21 (Bldg BCN01)
Sant Cugat del Valles
Spain, 08174
902 02 70 20

HP UK

HP Inc UK Ltd
Regulatory Enquiries, Earley West
300 Thames Valley Park Drive
Reading, RG6 1PT
United Kingdom

Document information

Review the following document information.

Model ID: Poly Studio Mobile

Document part number:

Last update: January 2026

Email us at documentation.feedback@hp.com with queries or suggestions related to this document.

Getting started

HP Poly Studio Mobile App (formerly **Poly Lens Mobile**) allows users to configure, manage, and monitor Poly audio devices.

The app complements desktop management for Poly Bluetooth devices and provides essential features such as **Find My Device** to help locate connected devices.

Poly studio Menu > General

Create an account

Sign up for a Poly Lens account using single sign-on (SSO) or a personal account.

Creating an account is recommended to enable device management and allow Poly and your organization to improve your device experience.

Account details

The app collects your first and last name, email address, system IP address, and profile information (profile picture and nickname) when you sign in using a Microsoft or Google account.

Device metadata

The app collects device serial numbers and software version information.

Device usage

The app collects information about how long the device is used.

1. Launch **Poly Studio Mobile**.
2. When prompted, select **Allow** to enable device alerts.
 - If **Don't Allow** is selected, device alerts must be enabled later through the phone's system settings.
3. *(First-time use only)* Review and accept the **License Agreement** and **Privacy Policy**.
4. Select **Continue**.
5. *(First-time use only)* Select **Allow** to permit the app to discover, connect to, and determine the relative location of nearby devices.
6. Select **Login**.
7. Choose one of the following sign-in methods:
 - **Single Sign-On (SSO)**: Sign in using an existing Microsoft, Google, Apple, or HP account, or create a new account.
 - **Email and Password**: Create a local account by entering your email address, password, and first and last name, then select **Sign Up**.
8. Review the onscreen information and select **Get Started**.
9. *(First-time use only)* Enable **location tracking** to assist with locating your device.
10. *(First-time use only)* Review the onscreen instructions and select **Skip**.
11. Select **Continue** to complete the login process.

Log in

1. Launch Poly Studio Mobile.
2. Select Menu > General > Account.
3. Select login
4. choose one of the following:
 - Select the SSO option (Microsoft, Google, Apple, or HP) that you used to create your account and follow the onscreen instructions.
 - Enter your local account email address and password, then select Log In.
 - Include show password option for usability.
 - Offers password recovery flow.
 - Displays terms, Privacy & Developer agreement notice.
5. Accept the invitation from the Poly Lens service.
6. After successful login, User is navigated to poly studio menu.
7. Select General > account – account screen displays logged in user details such as name and email id.

Log out

Log out of Poly Studio Mobile from Account settings.

1. Launch Poly Studio Mobile.
2. Select Menu > General > Account.
3. Select logout

Note: After clicking **Log Out**, the session is terminated.

The Account screen updates to show: *"You aren't currently logged in."*

Log Out button changes to **Log In**.

Explore Poly Studio Mobile as a guest

If you don't create an account, you can still use Poly Studio Mobile to manage your devices

1. Launch Poly Studio Mobile.
2. Select Allow to receive device alerts from Poly Studio Mobile.
 - If you select Don't Allow, you must turn it on in your phone settings before enabling device alerts from Poly Studio Mobile.
3. *(First time only)* Select I consent to the License Agreement and Privacy Policy.
4. Select Continue.

5.(First time only) Select Allow to allow Poly Studio Mobile to find, connect to and determine the relative position of nearby devices.

6.Select Continue as Guest.

7.Select Share Data options to help improve your experience.

Share Data

- When the user selects **Share Data**:
 - (First-time use only) Enable **location tracking** to help find the device.
 - Select **Get Started**.
 - (First-time use only) Review the onscreen instructions and select **Skip**.
 - Select **Continue** to proceed.
- **System behaviour**:
 - Selecting **Share Data** in **General Settings** automatically turns the **Share Data toggle ON**.

Don't Share Data

- When the user selects **Don't Share Data**:
 - (First-time use only) Enable **location tracking** to help find the device.
 - Select **Get Started**.
 - (First-time use only) Review the onscreen instructions and select **Skip**.
 - Select **Continue** to proceed.
- **System behavior**:
 - Selecting **Don't Share Data** in **General Settings** automatically turns the **Share Data toggle OFF**.

8.Read the onscreen information and select Get started.

9. (First time only) Enable location tracking to help find your device.

10. (First time only) Read the onscreen instructions and select Skip.

11. Select Continue.

Log In (Continue as Guest)(First Time)(Email & Password)

1.Launch Poly Studio Mobile.

2.Select Allow to receive device alerts from Poly Studio Mobile.

3.If you select Don't Allow, you must turn it on in your phone settings before enabling device alerts from Poly Studio Mobile.

4.(First time only) Select I consent to the License Agreement and Privacy Policy.

5.Select Continue.

6.(First time only) Select Allow to allow Poly Studio Mobile to find, connect to and determine the relative position of nearby devices.

7.Click on Continue as Guest

8.(First time only)Select Allow Poly Studio to access this device location.

9.(First time only)Select Get Started

10.(First time only)Select Skip.

11.10.(First time only)Select Continue.

12.Select Menu = > General > Account.

13.Select Login.

14.Select Email and password: Create a local account by entering your email address, password, and first and last name.

15.Then select Sign Up.

Log In (Continue as Guest)(First Time)(SSO)

1.Launch Poly Studio Mobile.

2.Select Allow to receive device alerts from Poly Studio Mobile.

3.If you select Don't Allow, you must turn it on in your phone settings before enabling device alerts from Poly Studio Mobile.

4.(First time only) Select I consent to the License Agreement and Privacy Policy.

5.Select Continue.

6.(First time only) Select Allow to allow Poly Studio Mobile to find, connect to and determine the relative position of nearby devices.

7.Click on Continue as Guest

8.(First time only)Select Allow Poly Studio to access this device location.

9.(First time only)Select Get Started

10.(First time only)Select Skip.

11.(First time only)Select Continue.

12.Select Menu = > General > Account.

13.Select Login.

14.Select SSO: Use your existing Microsoft, Google, Apple, or HP account or create a new one.

Log In (Continue as Guest)(SSO)

1.Launch Poly Studio Mobile.

2.Select Menu = > General > Account.

3.Select Login.

4.Select SSO: Use your existing Microsoft, Google, Apple, or HP account or create a new one.

Log In (Continue as Guest)(Email & Password)

1. Launch Poly Studio Mobile.
2. Select Menu => General > Account.
3. Select Login.
4. Select Email and password: Create a local account by entering your email address, password, and first and last name.

Eula Popup

1. Launch Poly Studio Mobile.
2. Select Allow to receive device alerts from Poly Studio Mobile.
3. If you select Don't Allow, you must turn it on in your phone settings before enabling device alerts from Poly Studio Mobile.
4. (First time only) Select I consent to the License Agreement and Privacy Policy.
5. Select Continue.

Send device data to improve your experience

Send your device data to HP to improve your experience when you explore Poly Studio Mobile as a guest.

1. Launch Poly Studio Mobile.
2. Select Menu > General > Account.
3. Select the Share Data toggle to enable or disable the function.

Delete your account

Delete your Poly Lens account and all your personal data from Poly Studio Mobile.

1. Launch Poly Studio Mobile.
2. Select Menu > General > Account.
3. Select Delete.

Note: Your account and personal data are deleted from Poly Lens

About under General

The **About** section of the application provides important information regarding the current version and related documentation.

1. App Version

- Displays the **current installed version** of the application.
- This helps users verify whether they are using the latest release.

2. Release Notes

- A **"See Release Notes"** link is available in this section.
- Clicking this link redirects the user to the **Poly Lens documentation portal**, where the **HP Poly Studio Mobile Release Notes** are published.

Release Notes Page Details:

- Displays the **Article ID** (e.g., XXXXXXXX).
- Lists all **release versions**, such as:
 - Version 5.X.X (Android) – Release date
- Each version includes:
 - **What's New** – Details of newly implemented features.
 - **Fixes** – Information about issues resolved in that release.

This section ensures users can easily access version details, feature updates, and bug fixes for transparency and reference.

Notification and Device Alerts under General

Notifications (Master Toggle)

- Turn ON to receive device notifications.
- Turn OFF to stop all device notifications.
- When turned OFF, all other notification options will be automatically disabled.
- When turned ON, you can choose which notifications you want to receive.

Device Charging

- Get a notification when your device starts charging.

Device Disconnected

- Receive an alert if your device gets disconnected.

Device Unpaired

- Get notified if your device is unpaired from the app.

Battery Low

- Receive a warning when your device battery is running low.

Device Software Update

- Get notified when a new software or firmware update is available for your device.

Privacy Policy under General

1. When you click on Privacy option, a popup appears
2. View Basic Options
 - On this screen, you will see:
 - Accept → Allows all cookies
 - More Options → Opens detailed settings
 - Close (X) → Closes the popup
3. Click on "More Options"
 - When you click More Options, a new screen opens
 - This screen shows detailed cookie settings

- You will see different types of cookies:
- Strictly Necessary Cookies
 - Required for website
 - Always enabled
- Performance & Analytics Cookies
 - Helps improve website
- Personalization Cookies
 - Saves your preferences
- Targeting Cookies
 - Used for ads

Save Your Choice

You will see these buttons:

- Save Settings → Saves your selected options
- Reject All → Disables all optional cookies
- Allow All → Enables all cookies

Licenses under General

1. Select Licenses > Third-Party Software Screen

2. This screen lists all open-source libraries used in the application.

- Library name
- Source link → Redirects to the official source repository
- Apache License 2.0 link → Displays the license terms

Note:

- Version numbers are displayed on this screen.
- Versions must be verified from project dependency files (e.g., Gradle configuration).
- This page is strictly for legal attribution and compliance purposes

Poly studio Menu > Find My Device

Purpose: To locate Poly devices on a map; shows an empty state when no device is connected or discoverable.

- A map view is displayed to show the real-time or last known location of Poly devices.
- If no poly devices are connected a warning message informs the user:
“No devices were found. Connect your Poly device using Bluetooth and try again.”
- Indicates that Bluetooth connection is required for device discovery.
- Back navigation is available to return to the previous screen.

Poly studio Menu > User Guides

Viewing device tutorials

This section lets you view onboarding instructions and access user guides for supported devices.

Purpose: Enable device setup or access product documentation.

- Onboarding section → Select device to start Bluetooth setup/pairing.
- User Guides section → Access manuals and usage instructions for specific models.
- Other Devices button → Handles devices not listed.
- Back navigation available.

Note :

1. User can also select Supported Devices from the Home page by clicking on select device
2. You can see the Supported Devices option when no device is connected.

View device onboarding page, quick guide, and user guide (Not Applicable as devices are not available)

- Poly Studio Mobile provides **device-specific help content**, including onboarding instructions and user documentation.
- When a device is connected for the **first time**, the **onboarding page opens automatically**.
- The onboarding page and documents can also be accessed later from the **device overview screen**, even if the device is offline or reconnected.
- **Note:** This feature is supported on **Poly Voyager Free 60 Series** devices.

Steps:

1. Launch **Poly Studio Mobile**.
2. From the **device screen**, select the documentation option.
3. Choose one of the following:
 - **Quick Guide** – Basic steps to start using the device.
 - **User Guide** – Detailed device documentation.
 - **Onboarding** – Instructions to connect the device to Poly Studio Mobile.

Fit test for ear tips (Not Applicable as devices are not available)

- Poly Studio Mobile allows users to **test earbud fit** to ensure proper audio performance.
- This feature is supported on **Poly Voyager Free 60 Series** and **Poly Voyager Free 20** devices.

Steps:

1. Connect the device to the phone.
2. Launch **Poly Studio Mobile**.

3. From the **device screen**, select **Fit Test**.
4. Select **Start Test** to begin.

Tip:

- If the fit test fails for one or both earbuds, adjust the earbuds and retry the test.
- If needed, replace the ear tips with a different size provided in the device packaging.

[Device documentation](#)

The following table provides links to the documentation for products supported by Poly Studio Mobile.

Table 1-1 Supported products documentation

Device	Links
Poly Voyager Legend 50	Poly Voyager Legend 50 User Guide
Poly Voyager Legend 30	Poly Voyager Legend 30 User Guide
Poly Voyager Free 20	Poly Voyager Free 20 User Guide
Poly Voyager Surround 85	Poly Voyager Surround 85
Poly Voyager Surround 80 UC	Poly Voyager Surround 80 UC
Poly Voyager Free 60 Series	Poly Voyager Free 60+ User Guide Poly Voyager Free 60 UC User Guide Poly Voyager Free 60 User Guide
Poly Voyager Focus 2 UC Poly Voyager Focus 2 Office	Poly Voyager Focus 2 UC User Guide Poly Voyager Focus 2 Office User Guide
Poly Voyager Focus UC	Poly Voyager Focus UC User Guide
Poly Voyager 8200 UC	Poly Voyager 8200 UC User Guide
Poly Voyager 6200 UC	Poly Voyager 6200 UC Series User Guide
Poly Voyager 5200 Series	Poly Voyager 5200 UC Series User Guide
Poly Voyager 4320 Series	Poly Voyager 4300 UC Series User Guide
Poly Voyager 4310 Series	Poly Voyager 4300 UC Series User Guide
Poly Voyager 4240 Series	Poly Voyager 4200 UC Series User Guide
Poly Voyager 4220 Series	Poly Voyager 4200 UC Series User Guide
Poly Voyager 4210 Series	Poly Voyager 4200 UC Series User Guide
Poly Sync 40 Poly Sync 40-M	Poly Sync 40 User Guide
Poly Sync 20 Poly Sync 20-M	Poly Sync 20 User Guide

[View supported devices](#)

View all supported devices for Poly Studio Mobile when the app hasn't connected to any devices before.

1. Launch Poly Studio Mobile.
2. Select Supported Devices from the *Home* page.

[Supported devices](#)

Poly Studio Mobile supports Poly Bluetooth headsets and speakerphones.

IMPORTANT: You can only update the device software for Poly Voyager Focus UC headsets using Poly Studio Desktop. See [Update your device software](#) using Poly Studio Desktop.

Supported Poly headsets

- [Poly Voyager Legend 50](#)
- [Poly Voyager Legend 30](#)
- [Poly Voyager Free 20](#)
- [Poly Voyager Surround 85](#)
- [Poly Voyager Surround 80 UC](#)
- [Poly Voyager Free 60 Series](#)
- [Poly Voyager Focus 2 UC](#), [Poly Voyager Focus 2 Office](#)
- [Poly Voyager Focus UC](#)
- [Poly Voyager 8200 UC](#)
- [Poly Voyager 6200 UC](#)
- [Poly Voyager 5200 Series](#)
- [Poly Voyager 4320 Series](#)

- [Poly Voyager 4310 Series](#)
- [Poly Voyager 4240 Series](#)
- [Poly Voyager 4220 Series](#)
- [Poly Voyager 4210 Series](#)

Supported Poly USB/Bluetooth smart speakerphones

- [Poly Sync 40](#), [Poly Sync 40-M](#)
- [Poly Sync 20](#), [Poly Sync 20-M](#)

Supported Dell wireless headsets

- Dell Pro Wireless Headset WL5022
- Dell Premier Wireless ANC Headset WL7022

Poly studio Menu > Support

1. It helps users quickly identify and resolve issues related to their **device or app**.
2. To provide **quick assistance options** for users facing issues
3. To guide users to the **right support category**
4. What type of issues do you have? They can choose:

- **Device** → For hardware-related issues (battery, screen, network, etc.)

Since we don't have any previous connected devices, we can't check the exact info here.

- **App** → For software-related issues (crashes, login errors, bugs)

If you click on App, it will open popup window, here it will ask to **login or later**.

- If you click on **login**, it will go to the login page.
- If you click on **later**, it will close
- Both cases it shows the information like
- App Version
- Tenant Name
- Tenant ID
- User ID
- App ID
- Last Connected
- If click on **Go** option It will open new page, there we can see
- **How would you like to connect with us?**
- Helps users choose how they want to contact support.
- Displays the selected product (**Poly Lens Mobile App**).
- **Product Selection**
 - Shows current product.
 - Option to "Choose a different product" if needed.
- **Chat with an Agent (Recommended)**
 - Quick way to get help via chat.
 - Marked as *Recommended Option* for faster support.
- **Sign-in Requirement**
 - Users must sign in to start chat.
 - Options available:
 - **Sign in** (existing users)
 - **Create an account** (new users)
- **Call an Agent**
- Option to contact support via phone.
- Shows availability status (**Available now**).
- Displays support details:
- **HP Support Community**
- Let's users join discussions and ask questions.
- Useful for:
 - Finding solutions from other users
 - Getting expert advice

1. Help Guide

- Provides **self-help documentation**
- Step-by-step solutions for common problems
- Ideal for users who want to **fix issues on their own**

2. Product Support

- Connects users to **customer support**

- Used when the issue is not resolved via Help Guide
- May include chat, call, or ticket options

Accessibility features

Poly products include a number of features to accommodate users with disabilities.

Accessibility feature (limited support)	Description
Screen reader capable	Users who have limited or low vision can access the software using their phones' built-in accessibility features.
Software status indicators	Graphic and text information provide status and functionality in the software interface.
Find my device	Users can use this feature to keep track of their devices.
Color theme	Users can configure the app's dark or light mode in the way that's most comfortable for them.
Text size	Users can adjust text size of the software via their phones' text size feature.

➤ Screen reader

- Screen Reader Accessibility[for iOS]
 - 1.Open Phone Settings.
 - 2.Go to Accessibility.
 - 3.Tap VoiceOver.
 - 4.Toggle VoiceOver ON.
 - 5.Launch Poly Studio Mobile.
 - 6.Open Home Page
- Screen Reader Accessibility[for android]
 - 1.Open Phone Settings.
 - 2.Go to Accessibility.
 - 3.Tap Talkback.
 - 4.Toggle Talkback ON.
 - 5.Launch Poly Studio Mobile.
 - 6.Open Home Page.

Poly studio Menu > Color Theme

➤ Color theme

- Color Theme in System for iOS
 - 1.Open Phone Settings
 - 2.Go to Display
 - 3.Select Mode:
 - Light
 - Dark
 - 4.Launch Poly Studio Mobile.
 - 5.Select Menu = > Color Theme.
 - 6.Select Follow Phone Theme(mandatory)
- Color Theme in System for android
 - 1.Open Phone Settings
 - 2.Go to Display
 - 3.Select Mode:
 - Light
 - Dark
 - 4.Launch Poly Studio Mobile.
 - 5.Select Menu = > Color Theme.
 - 6.Select Follow Phone Theme(mandatory)
- Color theme in App
 - 1.Launch Poly Studio Mobile.
 - 2.Select Menu = > Color Theme.
 - 3.Choose:
 - Light Theme
 - Dark Theme
 - Follow Phone Theme

➤ Text Size

- Text size Accessibility [iOS]
 - 1.Open Phone Settings.
 - 2.Select Display
 - 3.Select Font Size
 - 4.Increase font size using the slider.
 - 5.Launch Poly Studio Mobile.
 - 6.Open Home Page.
- Text size Accessibility [android]

- 1.Open Phone Settings.
- 2.Select Display
- 3.Select Font Size
- 4.Increase font size using the slider.
- 5.Launch Poly Studio Mobile.
- 6.Open Home Page.

➤ Keyboard Accessibility

- Keyboard Accessibility [for iOS]
 - 1.Connect a Bluetooth external keyboard to the phone/tablet.
 - 2.Open Phone Settings.
 - 3.Select Accessibility.
 - 4.Tap VoiceOver.
 - 5.Toggle VoiceOver ON.
 - 6.Launch Poly Studio Mobile.
 - 7.Select Menu = > General > Account.
 - 8.Select Login.
 - 9.Choose one of the following:
 - SSO: Use your existing Microsoft, Google, Apple, or HP account or create a new one.
 - Email and password: Create a local account by entering your email address, password, and first and last name.
- Keyboard Accessibility [for Android]
 - 1.Connect a Bluetooth external keyboard to the phone/tablet.
 - 2.Open Phone Settings.
 - 3.Select Accessibility.
 - 4.Tap Talkback.
 - 5.Toggle Talkback ON.
 - 6.Launch Poly Studio Mobile.
 - 7.Select Menu = > General > Account.
 - 8.Select Login.
 - 9.Choose one of the following:
 - SSO: Use your existing Microsoft, Google, Apple, or HP account or create a new one.
 - Email and password: Create a local account by entering your email address, password, and first and last name.

Poly studio Menu > Feedback

Send feedback on Poly Studio Mobile to HP. Report a bug, comment on features, or send suggestions about the product.

1. Launch Poly Studio Mobile.
2. Select Menu
3. Select Feedback to open the Poly Studio Mobile App Feedback portal.
4. Select a feedback type and enter your feedback.
5. Optional: Enter your contact information.
6. Select Send.