



Poly Voyager Free 20 True Wireless Earbuds with Charge Case User Guide

SUMMARY

This guide provides task-based user information for the named product.

Legal information

Copyright and license

© 2026, HP Development Company, L.P. The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Trademark credits

All third-party trademarks are the property of their respective owners. Bluetooth is a trademark owned by its proprietor and used by HP Inc. under license.

Privacy policy

HP complies with applicable data privacy and protection laws and regulations. HP products and services process customer data in a manner consistent with the HP Privacy Policy. Please refer to [HP Privacy Statement](#).

Open source software used in this product

This product contains open source software. You may receive the open source software from HP up to three (3) years after the distribution date of the applicable product or software at a charge not greater than the cost to HP of shipping or distributing the software to you. To receive software information, as well as the open source software code used in this product, contact HP by email at ipgoopensourceinfo@hp.com.

Table of contents


Your earbud system	1
Earbud button controls	2
Charge case controls	3
Load software	4
Update your Poly device	4
Reset device in HP Poly Studio	5
Fit	6
Replace eartips	6
Charge	7
Check battery level	7
Quick charge	8
Wireless charging (Qi charging)	8
Power	10
Power on/off your earbud system	10
DeepSleep mode	10
Connect and pair	11
Pair to mobile device	11
Pair mode	11
The basics	13
Adjust the volume	13
Adjust earbud microphone volume (softphone)	13
Play or pause audio	13
Track forward	13
Track backward	13
ANC and Transparency Mode	14
Use sensors	14
Voice assistant (smartphone feature)	14
Make/Take/End Calls	16
Make a call	16
Answer or end a call	16
Mute	16
More Features	17

Customize your earbud	17
ANC and Transparency Mode settings	17
Choose EQ setting	18
Connect new earbud	18
Manual device reset	19
What's in the box	20
Safety warnings	21
Safety Instructions	21
Support	23

Your earbud system


Your earbud system easily connects to your mobile phone. The system includes:

- Wireless earbuds with wearing sensors
- Charge case with battery-status LEDs



Earbud button controls

Press an earbud button to control features on your earbud system. Control features using either earbud.




Icon	Control	Button action
	Answer call	Press once to answer
	End call	Press and hold for 2 seconds to end call
	Mute/unmute	Press once while on an active call
	Pause/play media *	Press once
	Track forward	Press 2 times
	Track backward	Press 3 times
	Bluetooth pairing	Press and hold for 4 seconds. For more, see Pair to mobile device on page 11 .
	ANC/Transparency mode	Press and hold for 2 seconds when earbuds are idle or streaming media. Modes cannot be switched during a call. For more, see ANC and Transparency Mode on page 14 .

NOTE: *Functionality varies by application. May not function with web-based apps.

Charge case controls

Your charge case has a button on the back and LEDs on the front. Use the charge case to pair your mobile device and check battery status.



Control	Button action
Bluetooth pairing	Press and hold for 4 seconds with case open and earbuds inside. For more, see Pair to mobile device on page 11 .
Check battery status	Press once. The center LED indicates the charge case battery level. Left and right LEDs show earbud battery level when earbuds are in the case.

Load software

Download HP Poly Studio to get the most out of your device. Some softphones require the installation of HP software to enable device call control (answer or end a call and mute) functionality.



NOTE: Administrative privileges may be required to download the desktop application. If you don't have administrator privileges on your system, contact your system administrator.

- Download the HP Poly Studio Desktop app at hp.com/studio.
- Download the HP Poly Studio Mobile app at hp.com/studio, the App Store, or Google Play.



Table 4-1 Supported features

Feature	HP Poly Studio Mobile app	HP Poly Studio Desktop app
Configure call control for softphones	Available for some softphones	✓
Change headset language	✓	✓
Enable features	✓	✓
Choose preferred Equalizer setting	✓	✓
Battery meter	✓	✓
Update device firmware	✓	✓
Manage notifications and alerts	✓	✓
Schedule wellbeing reminders		✓
View user guide	✓	✓
FindMyHeadset	✓	

Update your Poly device

Keep your firmware and software up-to-date to improve Poly device performance and add new features. Download the app at hp.com/studio.

1. Update earbuds
 - a. To update your earbuds, first open the case to automatically power them on.

- b. Go to HP Poly Studio Mobile on your paired mobile device or to HP Poly Studio Desktop on your connected computer.
- c. Select your earbuds from the device list in HP Poly Studio to view available updates.
- d. Click the update button to wirelessly update earbud firmware or software.

2. Update charge case



NOTE: This device update requires HP Poly Studio Desktop downloaded to your computer

- a. With HP Poly Studio Desktop downloaded, plug the charge case into your computer using the provided USB cable.
- b. Select your charge case from the device list in HP Poly Studio Desktop to view available updates.
- c. Click the update button to update charge case firmware or software.

Reset device in HP Poly Studio

Reset your case and earbuds in HP Poly Studio.


- Select your earbuds from the device list in HP Poly Studio and go to **Settings > Reset Device > Restore Defaults**.



IMPORTANT: If your device is not recognized in HP Poly Studio, reset your device manually. See [Manual device reset on page 19](#).

Fit

Place earbud in your ear. Rotate down and forward for an optimal fit and sound experience.




1. Try the 4 eartips to find which size fits you comfortably while blocking external noise.
2. Listen to music and select the eartip that gives you the most bass response.
3. You may prefer a different size eartip in each ear.


Replace eartips

Change your eartips and lock them in place.

1. REMOVE:
 - a. Fold down the eartip's outer cone to reveal the eartip base connection to the earbud.
 - b. Pinch the eartip's outer cone and pull to remove.




2. REPLACE:
 - a. Place the eartip base on the earbud microphone column and press into place for a secure fit.
 - b. The eartip base clicks when locked into place.



Charge

1. To charge your earbuds, place them in the charge case. Your earbuds begin charging when placed in the case.
2. To recharge the case, plug it into a computer or USB charging device using the supplied USB cable. Alternatively, recharge using a third-party Qi certified wireless charger (not included).

 **TIP:** For fastest charging, plug your charge case into a power outlet.



3. Your charge case LEDs blink every 10 seconds when charging and turn off when fully charged.

Table 6-1 Charge time

Device	Charge time
Charge case and earbuds	Approximately 3 hours
Earbuds only	Approximately 2 hours
Charge case only	Approximately 2 hours

 **NOTE:** The charge times listed above reflect charging with a USB cable and power outlet. Qi charging time may be longer.


Table 6-2 Listening time

Device	Listening time
Earbuds with ANC off	Up to 12 hours
Earbuds with ANC on	Up to 8 hours
Charge case	Up to 30 hours

Check battery level

Check your earbud system battery level.

- Check your earbud system battery level:
 - Listen to the battery level alert when you put on the earbuds.
 - View charge case LEDs. The center LED indicates the charge case battery level. Left and right LEDs show earbud battery level when earbuds are in the case.



 **NOTE:** To activate LEDs, open your case lid, press the case button, or connect/remove the charge case from a power source.

- View earbud and charge case battery level in HP Poly Studio. Download at hp.com/studio.

Voice alert	Charge case LEDs	Listening time
"Battery high"	Green	3 hours or more
"Battery medium"	Green	1 to 3 hours
"Battery low"	Yellow	10 minutes to 1 hour
"Battery critical"	Red	Less than 10 minutes

Quick charge


- Charge your earbuds for 5 minutes for up to a full hour of listening time.

Wireless charging (Qi charging)

Your charge case is compatible with third-party Qi certified wireless chargers.

- To charge wirelessly, place the earbuds in the charge case and place your case on your compatible wireless charger. Refer to your wireless charger user guide.

 **NOTE:** Your earbuds charge only when placed in the charge case. They do not charge if placed directly on the wireless charger.




Power

Power on/off your earbud system

Your earbuds and case power on and off automatically.


- Open your charge case to automatically power on the earbuds. Conversely, place your earbuds in the case and close the lid to automatically power your earbuds off and start charging them.



DeepSleep mode

If you leave your earbuds powered on but out of range of your paired device, they conserve power by entering DeepSleep mode after 90 minutes.

- To exit DeepSleep mode, power on by clicking each earbud button.




Connect and pair

Connect and pair your earbuds to your mobile devices.


Pair to mobile device

1. Choose from 2 ways to put your earbuds in pair mode.

- With your earbuds in the charge case, open the lid and press the charge case button for 4 seconds. The charge case LEDs flash white and blue.



- Press and hold your earbud button for 4 seconds until you hear "pairing." Control with either earbud.



2. Activate Bluetooth® on your phone and set it to search for new devices.

- *iPhone* **Settings > Bluetooth > On***
- *Android* **Bluetooth: On > Scan for devices***



NOTE: * Menus may vary by device.

3. Select "Poly VFree 20."

When your earbuds are successfully paired, you hear "pairing successful" and "phone connected."

Pair mode

Put your earbuds in pair mode to connect to a new device or to pair again.

- Choose from 2 ways to put your earbuds in pair mode.
 - Press and hold the charge case button for 4 seconds until the case LEDs flash white and blue.
 - Press and hold your earbud button for 4 seconds until you hear "pairing." Control with either earbud.

The basics

Control features using either earbud.

Adjust the volume

- Adjust the volume on your connected mobile device.

Adjust earbud microphone volume (softphone)

- Place a test call and adjust earbud volume and softphone volume accordingly.

Play or pause audio


Choose a method to pause or resume streaming audio

- Choose a method to pause or resume streaming audio:
 - With active sensors, remove one earbuds to pause streaming audio. Put on one or both earbuds to resume audio.*



NOTE: *Functionality varies by application.

- Press the earbud button. Control with either earbud.



Track forward

Play the next track while streaming audio.

- Press the earbud 2 times to play the next track.

Track backward

Play the previous track while streaming audio.

- Press the earbud 3 times to play the previous track.

ANC and Transparency Mode

Active Noise Canceling (ANC) reduces external noise and enhances your music and sound quality. Transparency Mode allows you to hear your surroundings while wearing your earbuds.

- To switch between ANC and Transparency mode, choose from one of the following:
 - Earbuds: With your earbuds idle, press your earbud's button for 2 seconds to switch between your selected ANC Mode and your selected Transparency Mode.
 - HP Poly Studio: Go to **Settings > ANC**: Tap to view and select your ANC Mode or Transparency Mode. For more about these settings, see [ANC and Transparency Mode settings on page 17](#).



NOTE: Your earbuds must be idle or streaming media to switch between modes. Modes cannot be switched during a call.

Use sensors

Smart sensors respond when you put on or take off your earbuds. Customize in HP Poly Studio. Below describes default settings.

With active sensors	Putting on earbuds will:	Taking off earbuds will:
Incoming call	Answer the incoming call	--
Music/streaming media	Resume music/media*	Pause music/media*




NOTE: *Functionality varies by application. May not function with web-based apps.

Voice assistant (smartphone feature)

- **Siri, Google Assistant™, Cortana** Press and hold the earbud button for 2 seconds to activate your smartphone's default voice assistant. Wait for the phone prompt to activate voice dialing, search, and other smartphone voice controls.



NOTE: Ensure VPA is the selected Custom button setting. For more, see [Customize your earbud on page 17](#).



Make/Take/End Calls

Manage calls with your earbuds. Control features using either earbud.


Make a call

- To make a call, dial using your connected mobile device.

Answer or end a call

1. To answer a call, do one of the following:

- Press once on the earbud.




- Put on one or both earbuds to answer a call (with smart sensors active).
- Use your connected mobile device.

2. To end a call, press and hold the earbud button for 2 seconds.

Mute

To mute your microphone during a call, do one of the following:

- Press once on the earbud button.



- Mute from your paired mobile device.


More Features

Configure and use additional earbud features.

Customize your earbud

Customize your earbud Custom button feature in HP Poly Studio.

Download the app: hp.com/studio. To configure in HP Poly Studio, go to **Settings** > **Custom button**.



- Press the earbud for 2 seconds to use your configured Custom button setting. Control feature with either earbud.

Choose from:

- ANC/Transparency mode **default**
- Launch default voice assistant (Siri, Google Assistant)

ANC and Transparency Mode settings

Choose your preferred settings for ANC (Active Noise Canceling) and Transparency Mode.

Choose settings in HP Poly Studio.

Category	Setting	Description
ANC	Adaptive (default)	• Detects differences in user fit or movement while wearing and automatically adjusts to provide the best ANC experience
ANC	Standard	• Optimized to reduce external noise for office • Provide a more natural audio experience and enhanced sidetone comfort
ANC	Off	• ANC powered off

Category	Setting	Description
Transparency Mode	Speech	Optimized for face-to-face communication while wearing your earbuds
Transparency Mode	Environment (default)	- Best for busy streets - Optimized to hear your surroundings while wearing your earbuds
Transparency Mode	Off	Transparency Mode powered off

Choose EQ setting

Configure your audio for music and media streaming with equalizer (EQ) settings. Select your preferred EQ setting in HP Poly Studio.



NOTE: EQ settings are inactive when in a call and don't affect call quality.


1. Open HP Poly Studio and go to **Settings > General > Equalizer**.
2. Try each EQ option while listening to music to find your preferred setting.

Option	Description
Bass	Amplifies low frequencies, enriching the audio with clear and powerful deep tones
Flat	A neutral balance across all frequencies without emphasizing any particular range
Bright	Elevates high-frequency components, best for enhancing clarity for crisp audio

Connect new earbud

Connecting a replacement new earbud to your existing system is easy.

1. To connect your new earbud to the existing one, place them both in the charge case.



-
2. Close the case lid and wait for 10 or more seconds to complete the connection.

Manual device reset

Reset your case and earbuds manually.

Reset earbuds

1. Remove earbuds from charge case.
2. While wearing the earbuds, press and hold each earbud button for 10 seconds to reset the earbuds. Earbuds power off.

Earbuds are reset when you hear "power on" and device status.

Reset charge case

1. Insert the USB cable into the case.
2. Press and hold the case button while connecting the USB cable to a power source.

The case is successfully reset when the case powers on and the LEDs display the battery status.

What's in the box

Contents may vary by product.

Figure 12-1 True wireless earbuds



Figure 12-2 Charge case



Figure 12-3 USB-C cable



Figure 12-4 Quick start guide



Safety warnings

Safety Instructions

To reduce the risk of fire, electric shock, injury to persons and damage to property, read all operating instructions and the following safety instructions before using your HP product. Operating, storage and charging temperature is 10°C to 40°C (50°F to 104°F).

- Only use those HP products and accessories designed for use with this product.
- If you experience a skin irritation after using this product, discontinue use and contact HP.
- CHILDREN. Never allow children to play with the product-small parts may be a choking hazard.
- Do not disassemble the product as this may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock or fire when the product is subsequently used.
- Unplug, discontinue use and contact HP if the product overheats or has a damaged outer casing, cord or plug.
- Exposure to high volume sound levels or excessive sound pressure may cause temporary or permanent damage to your hearing. Although there is no single volume setting that is appropriate for everyone, you should always use your headset/headphones with the volume set at moderate levels and avoid prolonged exposure to high volume sound levels. The louder the volume, the less time is required before your hearing could be affected. You may experience different sound levels when using your headset/headphones with different devices. The device you use and its settings affect the level of sound you hear. If you experience hearing discomfort, you should stop listening to the device through your headset/headphones and have your hearing checked by your doctor. To protect your hearing, some hearing experts suggest that you:
 1. Set the volume control in a low position before putting your headset/headphones on your ears and use as low a volume as possible.
 2. Avoid turning up the volume to block out noisy surroundings. Whenever possible, use your headset/headphones in a quiet environment with low background noise.
 3. Limit the amount of time you use headsets/headphones at high volume levels.
 4. Turn the volume down if the sound from the headset/headphones prevent you from hearing people speaking near you.

- If you use your headset/headphones while driving, check local laws regarding use of a mobile phone and headset, and ensure your attention and focus remain on driving safely. Use of a headset/headphones that covers both ears will impair your ability to hear other sounds and in most regions is illegal to use while operating a motor vehicle or riding a bicycle and may be a serious hazard for you and others.
- If this product includes earbuds/eartips, install and use them in accordance with the instructions provided. Do not force earbuds/eartips down the ear canal. Consult a doctor if they become lodged in the ear canal.
- Plug the mains adapter or charger into a socket-outlet that is near to the equipment and will be easily accessible.

Battery Warnings for Wireless Products

- If your product has an embedded, non-replaceable battery, do not attempt to open the product or remove the battery as this may cause injury and/or damage the product. If your product has a replaceable battery, use only the battery type supplied by HP. Remove a spent battery promptly.
- Replace rechargeable batteries after three years or 300 charge cycles, whichever occurs first.
- Do not dispose of the product or battery in a fire or heat above 40°C (104°F).
- Do not expose the battery to extremely high temperatures. It may result in an explosion or the leakage of flammable liquid or gas.
- Do not open, deform or mutilate the battery. There may be corrosive materials which can cause damage to eyes or skin and may be toxic if swallowed.
- Never put batteries in mouth. If swallowed, contact a physician or poison control center.
- Swallowing may lead to burns, perforation of soft tissue, and death. Severe burns can occur within 2 hours of ingestion.
- Always store batteries where children cannot reach them.
- Do not allow any battery or its holder to contact metal objects such as keys or coins.
- RECYCLING: The product battery must be recycled or disposed of properly. Contact your local recycling center for battery removal and proper disposal.
- Use only the charger supplied by HP to charge the product and follow the charging instructions provided. Alternatively, if your headset is designed to be charged with your cell phone charger, use only cell phone chargers approved and provided by your cell phone manufacturer. Do not use the charger for any other purpose. Ensure that the voltage rating corresponds to the power supply you intend to use.

Support

NEED MORE HELP?

support.hp.com/poly

HP Inc.

1501 Page Mill Road
Palo Alto, CA 94304, U.S.A.
650-857-1501

HP REG 23010, 08028

Barcelona, Spain

HP Inc UK Ltd

Regulatory Enquiries, Earley West
300 Thames Valley Park Drive
Reading, RG6 1PT
United Kingdom

台灣惠普資訊科技股份有限公司

臺北市南港區經貿二路 66 號 10 樓
電話: 02-37899900

RMN (Regulatory Model Number): Earbuds PBVF20 (PBVF2R, PBVF2L), charge case PCCVF20.